

CERIO Corporation

CS-3424G-24P

**PoE CS-3000 Series - 24 Port Gigabit Managed PoE+
L2/L3 Lite Switch with 4 Combo Gigabit Ports
(400Watt Power)**



User Manual

Default IP / Login Information

IP Address	192.168.2.200
User Name	root
Password	default

FCC Warning

This device has been tested and found to comply with limits for a Class A digital device, pursuant to Part 2 and 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiates radio frequency energy and, if not installed and used in accordance with the user's manual, may cause interference in which case user will be required to correct the interference at his own expense.

CE Mark Warning

This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

1.	Exterior	8
1.1	Front Panel.....	8
1.2	Rear Panel Layout	8
2.	Software Configuration.....	9
2.1	Example of Segment: (Windows OS)	9
2.2	System login username and password information.....	錯誤! 尚未定義書籤。
3.	Status.....	14
3.1	System Information.....	14
3.2	Logging Message	16
3.3	Port.....	17
3.3.1	Statistics.....	17
3.3.2	Error Disabled	19
3.3.3	Bandwidth Utilization	20
3.4	Link Aggregation	20
3.5	MAC Address Table.....	21
4.	Network.....	23
4.1	DNS.....	23
4.2	Host	25
4.3	System Time.....	26
5.	Port.....	29
5.1	Port setting	29
5.2	Error Disabled	31
5.3	Link Aggregation	32
5.3.1	Group Configuration.....	32
5.3.2	Port Setting	34
5.3.3	LACP	36
5.4	EEE.....	37
5.5	Jumbo Frame	39
6.	POE	39
6.1	POE Port Setting	39
6.2	POE Port Time Setting	41
7.	VLAN	42
7.1	VLAN.....	42
7.1.1	Create VLAN.....	42
7.1.2	VLAN Configuration	43
7.1.3	Membership	45
7.1.4	Port Setting	46
7.2	Voice VLAN.....	48
7.2.1	Property	48
7.2.2	Voice OUI	49
7.3	Protocol VLAN.....	51

7.3.1	Protocol Group	51
7.3.2	Group Binding	52
7.4	MAC VLAN	53
7.4.1	MAC Group	53
7.4.2	Group Binding	55
7.5	Surveillance VLAN	56
7.5.1	Property	56
7.5.2	Surveillance OUI	58
7.6	GVRP	59
7.6.1	Property	60
7.6.2	Member ship	61
8.	MAC Address Table	65
8.1	Dynamic Address	65
8.2	Static Address	66
8.3	Filtering Address	67
8.4	Port Security Address	68
9.	Spanning Tree	69
9.1	Property	69
9.2	Port Setting	71
9.3	MST Instance	73
9.4	MST Port Setting	75
9.5	Statistics	78
10.	ERPS	80
10.1	Propely	83
10.2	ERPS Instance Setting	84
11.	Discovery(LLDP)	90
11.1	Property	90
11.2	Port Setting	91
11.3	MED Network Policy	93
11.4	MED Port Setting	95
11.5	Packet View	97
11.6	Local Information	99
11.7	Neighbor	105
11.8	Statistics	108
12.	DHCP	110
12.1	Property	110
12.2	IP Pool Setting	111
12.3	VLAN IF Address Group Setting	114
12.4	Client List	115
12.5	Client Static Binding Table	116
13.	Multicast	117


13.1	General.....	117
13.1.1	Property.....	117
13.1.2	Group Address.....	118
13.1.3	Router Port.....	119
13.1.4	Forward All.....	122
13.1.5	Throttling.....	124
13.1.6	Filtering Profile.....	125
13.1.7	Filtering Binding.....	126
13.2	IGMP Snooping.....	128
13.2.1	Property.....	128
13.2.2	Querier.....	131
13.2.3	Statistics.....	132
13.3	MLD Snooping.....	134
13.3.1	Property.....	134
13.3.2	Statistics.....	137
13.4	MVR.....	138
13.4.1	Property.....	138
13.4.2	Port Setting.....	140
13.4.3	Group Address.....	141
14.	IP Configuration.....	143
14.1	IPv4 Management and Interfaces.....	143
14.1.1	IPv4 Interface & Default IP Configure.....	143
14.1.2	IPv4 Routes & Default Route Configure.....	147
14.1.3	ARP.....	154
14.2	IPv6 Management and Interfaces.....	156
14.2.1	IPv6 Interface.....	156
14.2.2	IPv6 Addresses.....	159
14.2.3	IPv6 Routers.....	161
14.2.4	IPv6 Neighbors.....	164
15.	Security.....	166
15.1	RADIUS.....	166
15.2	TACACS+.....	169
15.3	AAA.....	171
15.3.1	Method List.....	171
15.3.2	Login Authentication.....	174
15.4	Management Access.....	175
15.4.1	Management Service.....	175
15.4.2	Management ACL.....	176
15.4.3	Management ACE.....	177

15.5	Authentication Manager	180
15.5.1	Property	180
15.5.2	Port Setting	185
15.5.3	MAC-Based Local Account	190
15.5.4	WEB-Based Local Account	192
15.5.5	Sessions	193
15.6	Port Security	195
15.7	Protected Port	198
15.8	Storm Control	199
15.9	DoS	202
15.9.1	Property	202
15.9.2	Port Setting	204
15.10	Dynamic ARP Inspection	205
15.10.1	Property	205
15.10.2	Statistics	208
15.11	DHCP Snooping	209
15.11.1	Property	209
15.11.2	Statistics	210
15.11.3	Option82 Property	212
15.11.4	Option82 Circuit ID	213
15.12	IP Source Guard	215
15.12.1	Port Setting	215
15.12.2	IMPV Binding	217
15.12.3	Save Databases	218
16.	ACL	220
16.1	MAC ACL	220
16.2	MAC ACE	221
16.3	IPv4 ACL	224
16.4	IPv4 ACE	224
16.5	IPv6 ACL	229
16.6	IPv6 ACE	230
16.7	ACL Binding	234
17.	QoS	236
17.1	Property	236
17.2	Queue Scheduling	239
17.3	CoS Mapping	240
17.4	DSCP Mapping	242
17.5	IP Precedence to Queue Mapping	244
17.6	Rate Limit	246
17.6.1	Ingress / Egress Port	246


17.6.2	Egress Queue	247
18.	Diagnostics	250
18.1	Logging	250
18.1.1	Property	250
18.1.2	Remote Server	252
18.2	Mirroring	254
18.3	Ping	256
18.4	Traceroute	257
18.5	Copper Test	258
18.6	Fiber Module	259
18.7	UDLD	260
18.7.1	Property	260
18.7.2	Neighbor	262
19.	Management	264
19.1	User Account	264
19.2	Firmware	265
19.2.1	Upgrade / Backup	265
19.3	Configuration	267
19.3.1	Upgrade / Backup	267
19.3.2	Save Configuration	269
19.4	SNMP	270
19.4.1	View	270
19.4.2	Group	271
19.4.3	Community	274
19.4.4	User	276
19.4.5	Engine ID	278
19.4.6	Trap Event	280
19.4.7	Notification	282
19.5	RMON	285
19.5.1	Statistics	285
19.5.2	History	287
19.5.3	Event	289
19.5.4	Alarm	291

1. Exterior

1.1 Front Panel



1.2 Rear Panel Layout



Status LED lights for 24 Port 10/100/1000Mbps with 4 Gigabit Combo Ports

- Per Port : Link/Activity Status
- Per Port : 1000M/Gigabit Status
- Gigabit Combo Port : Link/Activity Status
- Gigabit Combo Port : 1000M/Gigabit Status
- Per Unit : PWR



- 1) AC Power On/Off Control Switch
- 2) AC input (100-240V/AC, 50-60Hz) UL Safety
- 3) Ground screw lock point

2. Software Configuration


CS-3424G-24P supports web-based configuration. Upon the completion of hardware installation, The Switch can be configured through a PC/NB by using its web browser such as Internet Explorer 6.0 or later.

Set the IP segment of the administrator's computer to be in the same range as **CS-3424G-24P** for accessing the system. Do not duplicate the IP Address used here with IP Address of **CS-3424G-24P** or any other device within the network. *Please refer to the following steps*

2.1 Example of Segment: (Windows OS)


Step 1 :

Please click on the computer icon in the bottom right window, and click “**Open Network and Sharing Center**”




Step 2 :

In the Network and Sharing Center page, click on the left side of “**Change adapter setting**” button




Step 3 :

In “Change adapter setting” Page, right click on Local LAN then select “Properties”




Step 4 :

In the “Properties” page, click the “Properties” button to open TCP/IP setting



Step 5 :

In Properties page for setting IP addresses, find “Internet Protocol Version 4 (TCP/IPv4)” and double click to open TCP/IPv4 Properties window




Step 6 :

Select “Use the following IP address”, and fix in IP Address to: 192.168.2.X

ex. The X is any number from 1 to 253

Subnet mask : 255.255.255.0


And Click "OK" to complete fixing the computer IP settings



Step 7 :

Open Web Browser

Without a valid certificate, users may encounter the following problem in IE7 when they try to access system's WMI (<http://192.168.2.200>). There will be a "Certificate Error", because the browser treats system as an illegal website.



System login Overview page will appear after successful login.

2.2 System login information and IP / Gateway Setting instructions

The **CS-3424G-24P** web switch default IP is 192.168.2.200

Into the management page as follows, please enter Username and password

- **Default IP Address:** 192.168.2.200
- **Default Username and Password**

Management Account	Root Account
Username	root
Password	default

After the authentication procedure, the home page will show up. Select one of the configurations by clicking the icon.

Default IP Configure:

Edit IPv4 Interface

Interface	VLAN 1		
Address Type	<input type="radio"/> Dynamic <input checked="" type="radio"/> Static		
IP Address	192.168.2.200		
Mask	<input checked="" type="radio"/> Network Mask	255.255.255.0	
	<input type="radio"/> Prefix Length		(8 - 30)
Roles	<input checked="" type="radio"/> primary <input type="radio"/> sub		

Note

If you want to change the default IP (VLAN IP) address of the POE switch, please refer to the chapter : 14.1.1. for " IP Configuration > IPv4 Interface & Default IP Configure >" (Please refer to page 143)

Layer 3 Default Route Configure: (This function is the same as the "Default Gateway Configure " of the Layer 2 switch)

Add IPv4 Static Route

IP Address	0.0.0.0		
	<input checked="" type="radio"/> Network Mask	0.0.0.0	
Mask	<input type="radio"/> Prefix Length		(0 - 32)
Next Hop Router IP Address	192.168.2.254		
Metric	1	(1 - 255, default 1)	

Apply Close

Note


If you want to make default Route IP address of the L3 POE switch, please refer to the chapter : 14.1.2. for " IP Configuration > Pv4 Routes & Default Route Configure >" (Please refer to page 147)

3. Status

3.1 System Information

Administrator can check this page shows switch panel, CPU utilization, Memory utilization and other system current information. It also allows user to edit some system information.

Note	In the Web UI, the left column shows the configuration menu. The top row shows the switch's current link status. Green squares indicate the port link is up, while black squares indicate the port link is down. Below the switch panel, you can find a common toolbar to provide useful functions for users. The rest of the screen area displays the configuration settings.
-------------	--



Field	Description
Model	Model name of the switch.
System Name	System name of the switch. This name will also use as CLI prefix of each line. ("Switch>" or "Switch#")
System Location	Location information of the switch.
System Contact	Contact information of the switch.
MAC Address	Base MAC address of the switch.

IPv4 Address	Current system IPv4 address.
IPv6 Address	Current system IPv6 address.
System OID	SNMP system object ID.
System Uptime	Total elapsed time from booting.
Current Time	Current system time.
Loader Version	Boot loader image version.
Loader Date	Boot loader image build date.
Firmware Version	Current running firmware image version.
Firmware Date	Current running firmware image build date.
Telnet	Current Telnet service enable/disable state.
SSH	Current SSH service enable/disable state.
HTTP	Current HTTP service enable/disable state.
HTTPS	Current HTTPS service enable/disable state.
SNMP	Current SNMP service enable/disable state.

Edit System Information

Administrator can click “Edit” button on the table title to edit following system information.

Edit System Information

System Name

Switch

System Location

default

System Contact

default

Apply

Close

- **System Name:** System name of the switch. This name will also use as CLI prefix of each line. (“Switch>” or “Switch#”).
- **System Location:** Location information of the switch.

- **System Contact:** Contact information of the switch.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

3.2 Logging Message

Administrator can use this tools page to Inspection of system RAM and Flash status.

Status → Logging Message

Logging Message Table

Viewing **RAM** Showing **All** entries Showing 1 to 5 of 5 entries

Log ID	Time	Severity	Description
1	Jan 01 2023 08:00:28	notice	AAA-0-CONNECT: New http connection for user root, source 192.168.101
2	Jan 01 2023 08:00:14	notice	PORT-5-LINK_UP: Interface GigabitEthernet25 link up
3	Jan 01 2023 08:00:13	notice	PORT-5-LINK_UP: Interface VLAN1 link up
4	Jan 01 2023 08:00:13	notice	PORT-5-LINK_UP: Interface GigabitEthernet27 link up
5	Jan 01 2023 00:00:13	notice	SYSTEM-5-COLDSTART: Cold startup

Clear Refresh First Previous

- **Viewing:** The logging view including:
 - **RAM:** Show the logging messages stored on the RAM.
 - **Flash:** Show the logging messages stored on the Flash.

Field	Description
Log ID	The log identifier.
Time	The time stamp for the logging message.
Severity	The severity for the logging message.
Description	The description of logging message.

Click the **“Clear”** button to clear this page or click the **“Refresh”** button to refresh the page .

3.3 Port

Display detailed port summary and status information for each port.

3.3.1 Statistics

Administration can choose to view displays standard counters on network traffic form the Interfaces, Ethernet-like and RMON MIB. Interfaces and Ethernet-like counters display errors on the traffic passing through each port. RMON counters provide a total count of different frame types and sizes passing through each port. The **“Clear”** button will clear MIB counter of current selected port.

Status → Port → Statistics

– Status

- System Information
- Logging Message
- Port
 - Statistics**
 - Error Disabled
 - Bandwidth Utilization
 - Link Aggregation
 - MAC Address Table

- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS
- Diagnostics
- Management

Port

GE1

MIB Counter

☒ All
☐ Interface
☐ Etherlike
☐ RMON

Refresh Rate

☐ None
☐ 5 sec
☒ 10 sec
☐ 30 sec

Clear

Interface

ifInOctets	0
ifInUcastPkts	0
ifInNUcastPkts	0
ifInDiscards	0
ifOutOctets	0
ifOutUcastPkts	0
ifOutNUcastPkts	0
ifOutDiscards	0
ifInMulticastPkts	0

Click the **“Clear”** button to clear this page.

Interface	
ifInOctets	1226044
ifInUcastPkts	8677
ifInNUcastPkts	343
ifInDiscards	0
ifOutOctets	2813449
ifOutUcastPkts	5587
ifOutNUcastPkts	194
ifOutDiscards	0
ifInMulticastPkts	226
ifInBroadcastPkts	117
ifOutMulticastPkts	194
ifOutBroadcastPkts	0

Etherlike	
dot3StatsAlignmentErrors	0
dot3StatsFCSErrors	0
dot3StatsSingleCollisionFrames	0
dot3StatsMultipleCollisionFrames	0
dot3StatsDeferredTransmissions	0
dot3StatsLateCollisions	0
dot3StatsExcessiveCollisions	0
dot3StatsFrameTooLongs	0
dot3StatsSymbolErrors	0
dot3ControlInUnknownOpCodes	0
dot3InPauseFrames	0
dot3OutPauseFrames	0

RMON	
etherStatsDropEvents	0
etherStatsOctets	1236728
etherStatsPkts	9117
etherStatsBroadcastPkts	117
etherStatsMulticastPkts	226
etherStatsCRCAlignErrors	0
etherStatsUnderSizePkts	0
etherStatsOverSizePkts	0
etherStatsFragments	0
etherStatsJabbers	0
etherStatsCollisions	0
etherStatsPkts64Octets	6502
etherStatsPkts65to127Octets	1080
etherStatsPkts128to255Octets	122
etherStatsPkts256to511Octets	1251
etherStatsPkts512to1023Octets	150
etherStatsPkts1024to1518Octets	12

- **Port** : Select one port to show counter statistics.
- **MIB Counter** : Select the MIB counter to show different counter type.
 - **All** : All counters.
 - **Interface** : Interface related MIB counters.
 - **Etherlike** : Ethernet-like related MIB counters.
 - **RMON** : RMON related MIB counters.
- **Refresh Rate** : Refresh the web page every period of "None , 5 sec , 10 sec , 30 sec "seconds base to get new counter of specified port.

3.3.2 Error Disabled

If administrator has set Error disabled functions then can monitor information in page.

Status → Port → Error Disabled

– Status

- System Information
- Logging Message
- Port
 - Statistics
 - Error Disabled**
 - Bandwidth Utilization
 - Link Aggregation
 - MAC Address Table
- Network
- Port
- POE Setting
- VLAN


Error Disabled Table

<input type="checkbox"/>	Port	Reason	Time Left (sec)
<input checked="" type="checkbox"/>	GE1	---	---
<input type="checkbox"/>	GE2	---	---
<input type="checkbox"/>	GE3	---	---
<input type="checkbox"/>	GE4	---	---
<input type="checkbox"/>	GE5	---	---
<input type="checkbox"/>	GE6	---	---
<input type="checkbox"/>	GE7	---	---

Field	Description
Port	Interface or port number.
Reason	<p>Port will be disabled by one of the following error reason:</p> <ul style="list-style-type: none"> BPDU Guard. UDLD. Self Loop. Broadcast Flood. Unknown Multicast Flood. Unicast Flood. ACL. Port Security Violation. DHCP rate limit. ARP rate limit.
Time Left (sec)	The time left in second for the error recovery.

3.3.3 Bandwidth Utilization

This page can display Tx / Rx Real-time bandwidth information of each port. (Instant used rate per port and this page will refresh automatically in every refresh period)



- **Refresh Rate:** Refresh the web page every period of seconds to get new bandwidth utilization Rate.
 - **2 :** Select the 2 second cycle from the drop-down menu to refresh the display page.
 - **5 :** Select the 5 second cycle from the drop-down menu to refresh the display page.
 - 10 :** Select the 10 second cycle from the drop-down menu to refresh the display page.

3.4 Link Aggregation

If administrator has set LACP function then this can display LACP information. This system have support 8 Link Aggregation group. Administrator can enable 8 LAG.

Status → Link Aggregation

- Status
 - System Information
 - Logging Message
 - Port
 - Statistics
 - Error Disabled
 - Bandwidth Utilization
 - Link Aggregation
 - MAC Address Table
- ↕ Network
- ↕ Port
- ↕ POE Setting
- ↕ VLAN
- ↕ MAC Address Table
- ↕ Spanning Tree

Link Aggregation Table

LAG	Name	Type	Link Status	Active Member	Inactive Member
LAG 1		---	---		
LAG 2		---	---		
LAG 3		---	---		
LAG 4		---	---		
LAG 5		---	---		
LAG 6		---	---		
LAG 7		---	---		
LAG 8		---	---		

Field	Description
LAG	LAG Name.
Name	LAG port description.
Type	The type of the LAG. <ul style="list-style-type: none"> • Static: The group of ports assigned to a static LAG are always active members. • LACP: The group of ports assigned to dynamic LAG are candidate ports. LACP determines which candidate ports are active member ports.
Link Status	LAG port link status.
Active Member	Active member ports of the LAG.
Inactive Member	Inactive member ports of the LAG.

3.5 MAC Address Table

The MAC address table page displays all MAC address entries on the switch including static MAC address created by administrator or auto learned from hardware.

The “**Clear**” button will clear all dynamic entries and “**Refresh**” button will retrieve latest MAC address entries and show them on page.

Status → MAC Address Table

- Status
 - System Information
 - Logging Message
 - Port
 - Statistics
 - Error Disabled
 - Bandwidth Utilization
 - Link Aggregation
 - MAC Address Table
- ✦ Network
- ✦ Port
- ✦ POE Setting
- ✦ VLAN
- ✦ MAC Address Table
- ✦ Spanning Tree
- ✦ ERPS
- ✦ Discovery
- ✦ DHCP
- ✦ Multicast
- ✦ IP Configuration
- ✦ Security
- ✦ ACL
- ✦ QoS
- ✦ Diagnostics
- ✦ Management

MAC Address Table

Showing entries Showing 1 to 23 of 23 entries

VLAN	MAC Address	Type	Port
1	8C:4D:EA:30:DD:53	Management	CPU
1	00:08:9B:D5:33:E4	Dynamic	GE27
1	00:11:32:11:76:30	Dynamic	GE27
1	00:1A:97:01:AD:B1	Dynamic	GE27
1	00:60:B9:BF:B6:74	Dynamic	GE27
1	00:E0:A0:10:04:6C	Dynamic	GE27
1	10:60:4B:8B:78:99	Dynamic	GE27
1	1C:6F:65:26:B9:13	Dynamic	GE27
1	1C:6F:65:41:52:73	Dynamic	GE27
1	40:B0:34:54:97:82	Dynamic	GE25
1	58:38:79:0D:1C:12	Dynamic	GE27
1	6C:B1:58:2E:38:67	Dynamic	GE27
1	6C:B1:58:2E:38:74	Dynamic	GE27
1	6C:B1:58:2E:3B:35	Dynamic	GE27
1	6C:F0:49:0A:85:C1	Dynamic	GE27
1	8C:4D:EA:04:F8:50	Dynamic	GE27
1	90:09:D0:25:A9:4F	Dynamic	GE27
1	94:DE:80:70:B4:CD	Dynamic	GE27
1	98:97:CC:3A:6A:0C	Dynamic	GE27
1	A4:5D:36:C7:4D:B3	Dynamic	GE27
1	E0:2A:82:A2:2D:40	Dynamic	GE27
1	F4:6D:2F:96:C8:77	Dynamic	GE27
1	F4:6D:2F:96:CC:7F	Dynamic	GE27

Field	Description
VLAN	VLAN ID of the mac address
MAC Address	MAC address
Type	<p>The type of MAC address</p> <ul style="list-style-type: none"> • Management: DUT's base mac address for management purpose • Static: Manually configured by administrator • Dynamic: Auto learned by hardware
Port	<p>The type of Port</p> <ul style="list-style-type: none"> • CPU: DUT's CPU port for management purpose • Other: Normal switch port

Click the **"Clear"** button to clear this page or click the **"Refresh"** button to refresh the page .

4. Network

4.1 DNS

DNS (Domain Name System) is for mapping a domain name to its corresponding IP address and vice versa. Use the DNS screen to configure and view the default DNS servers on the Switch.


Use these pages to configure information about which DNS servers your network uses and how the switch operates as a DNS client.

DNS service on this switch allows host names to be mapped to IP addresses using static table entries or by redirection to other name servers on the network. When a client device designates this switch as a DNS server, the client will attempt to resolve host names into IP addresses by forwarding DNS queries to the switch, and waiting for a response.

You can manually configure entries in the DNS table used for mapping domain names to IP addresses, configure default domain names, or specify one or more name servers to use for domain name to address translation.

You can use these pages to configure information about DNS servers the network uses and how the switch operates as a DNS client.

Use this page to configure global DNS settings and DNS server information.



The screenshot shows the 'Network → DNS' configuration page. On the left is a sidebar menu with options: Status, Network (selected), DNS, Hosts, System Time, Port, POE Setting, VLAN, MAC Address Table, Spanning Tree, ERPS, Discovery, DHCP, Multicast, IP Configuration, Security, and ACL. The main content area is titled 'DNS Configuration' and includes a 'DNS Status' section with radio buttons for 'Disable' and 'Enable' (selected). Below this is a 'DNS Default Name' text field containing 'cerio.co.tw' with a note '(1 to 255 alphanumeric characters)'. An 'Apply' button is present. The 'DNS Server Configuration' section features a search icon and a table with columns for a checkbox, Preference, and DNS Server. The table contains one entry with Preference '1' and DNS Server '192.168.101.100'. 'Add' and 'Delete' buttons are at the bottom.

DNS Configuration

Select the Disable or Enable button to specify whether to disable or enable the administrative state of the DNS client:

- **DNS Status:**
 - **Disable** : Prevent the switch from sending DNS queries.
 - **Enable** : Allow the switch to send DNS queries to a DNS server to resolve a DNS domain name.
- **DNS Default Name** : Enter the default DNS domain name to include in DNS queries.

Note	When the system is performing a lookup on an unqualified host name, this field is provides the domain name (for example, if default domain name is cerio.cc and the user enters oem, then "oem" is changed to oem.cerio.cc to resolve the name). The name must not be longer than 255 alphanumeric characters.
-------------	--

Click the **"Apply"** button to save your changes.

DNS Server Configuration

Administrator can configure this DNS Server Setting **"add"** and "Delete" function management.

Field	Description
Preference	The Preference field displays the server preference order. The preference is set in the order in which preferences were entered.
DNS Server	Shows the server is added to the list.


Note	The "preference" of the DNS server. The preferences are determined by the order in which they were entered. You can specify up to eight DNS servers.
-------------	--

- **Add** : To specify the DNS server to which the switch sends DNS queries, enter an IP address in standard IPv4 dot notation in the DNS Server Address and click Add. The server appears in the list below. You can specify up to eight DNS servers. The preference is set in the order created.
- **Delete** : To remove a DNS server from the list, select the check box next to the server you want to remove and click Delete. If no DNS server is specified, the check box is global and will delete all the DNS servers listed.

Administrator can configure this DNS Server Configuration **"Apply"** and **"Cancel"** on the screen and reset the data on the screen to the latest value of the switch.

4.2 Host

This page provide administrator to view Host Name to IP Address Information, Administrator can set this page to manually map host names to IP addresses or to view dynamic host mappings.




Click the “Clear” button to clear this page

DNS Host Configuration

Administrator can configure “add” and “Delete” for a static entry to the local dynamic host mapping Table function management.

Field	Description
Host	Show “host name” that for you assign to the specified IP address.
IPv4/IPv6 Address	The IP address associated with the “host name”.



- **Host:** Administrator can set the Host Name field, specify the static host name to add.

- **IPv4/IPv6 Address:** Enter the IP address to associate with the host name to this " IPv4/IPv6 Address" field, The entry is displayed in the list on the page after **"Apply"** creation.

Note	For Host Name field, Must be follow 1 to 255 alphanumeric characters, Its length cannot exceed 158 characters and it is a required field.
-------------	---

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

Dynamic Host Mapping

Administrator can clear all the dynamic host name entries from the list, click the Clear button.

The Dynamic Host Mapping table shows host name-to-IP address entries that the switch learned.

Field	Description
Host	Displays the lists the host name you assign to the specified IP address.
Total	Displays the amount of time since the dynamic entry was first added to the table.
Elapsed	Displays the amount of time since the dynamic entry was last updated.
Type	Displays the type of the dynamic entry.
IPv4/IPv6 Address	Displays the lists the IPv4 or IPv6 addresses associated with the host name.

Click the **"Apply"** button to save your changes or click the **"Clear"** button to refresh the page .

4.3 System Time

System time can be configured via this page. Administrator can select SNTP Server or from computer to update the system time or administration can use manual setting the system time.

Note. If administrator chooses SNTP Server to synchronization update time then must confirm system gateway and DNS is correct and switch system must be able to connect to the SNTP Server.

Network → System Time

<ul style="list-style-type: none"> ⌵ Status – Network <ul style="list-style-type: none"> DNS Hosts System Time ⌵ Port ⌵ POE Setting ⌵ VLAN ⌵ MAC Address Table ⌵ Spanning Tree ⌵ ERPS ⌵ Discovery ⌵ DHCP ⌵ Multicast ⌵ IP Configuration ⌵ Security ⌵ ACL ⌵ QoS ⌵ Diagnostics 	<table> <tr> <td>Source</td> <td> <input checked="" type="radio"/> SNTP <input type="radio"/> From Computer <input type="radio"/> Manual Time </td> </tr> <tr> <td>Time Zone</td> <td>UTC +8:00 ▾</td> </tr> </table> <div> SNTP <table> <tr> <td>Address Type</td> <td> <input type="radio"/> Hostname <input checked="" type="radio"/> IPv4 </td> </tr> <tr> <td>Server Address</td> <td>162.159.200.1</td> </tr> <tr> <td>Server Port</td> <td>123 (1 - 65535, default 123)</td> </tr> </table> </div> <div> Manual Time <table> <tr> <td>Date</td> <td>2023-03-21</td> <td>YYYY-MM-DD</td> </tr> <tr> <td>Time</td> <td>02:31:03</td> <td>HH:MM:SS</td> </tr> </table> </div> <div> Daylight Saving Time <table> <tr> <td></td> <td><input checked="" type="radio"/> None</td> </tr> </table> </div>	Source	<input checked="" type="radio"/> SNTP <input type="radio"/> From Computer <input type="radio"/> Manual Time	Time Zone	UTC +8:00 ▾	Address Type	<input type="radio"/> Hostname <input checked="" type="radio"/> IPv4	Server Address	162.159.200.1	Server Port	123 (1 - 65535, default 123)	Date	2023-03-21	YYYY-MM-DD	Time	02:31:03	HH:MM:SS		<input checked="" type="radio"/> None
Source	<input checked="" type="radio"/> SNTP <input type="radio"/> From Computer <input type="radio"/> Manual Time																		
Time Zone	UTC +8:00 ▾																		
Address Type	<input type="radio"/> Hostname <input checked="" type="radio"/> IPv4																		
Server Address	162.159.200.1																		
Server Port	123 (1 - 65535, default 123)																		
Date	2023-03-21	YYYY-MM-DD																	
Time	02:31:03	HH:MM:SS																	
	<input checked="" type="radio"/> None																		

System Time

- **Source:** Select the time source.
 - **SNTP:** Time sync from NTP server.
 - **From Computer:** Time set from browser host.
 - **Manual Time:** Time set by manually configure.
- **Time Zone:** Select a time zone difference from listing district.

SNTP

- **Address Type:** Select the address type of NTP server. This is enabled when time source is SNTP.
- **Server Address:** Input IPv4 address or hostname for NTP server. This is enabled when time Source is SNTP.
- **IPv6 Address:** Input NTP port for NTP server. Default is 123. This is enabled when time source is SNTP.

Manual Time

- **Date:** Input manual date. This is enabled when time source is manual.
- **Time:** Input manual time. This is enabled when time source is manual.

Daylight Saving Time

The Switch support Daylight saving time function, if administrator need enable and set the Daylight saving time function will can be enable this function.

Daylight Saving Time	
Type	<input checked="" type="radio"/> None <input type="radio"/> Recurring <input type="radio"/> Non-recurring <input type="radio"/> USA <input type="radio"/> European
Offset	<input type="text" value="60"/> Min (1 - 1440, default 60)
Recurring	From: Day <input type="text" value="Sun"/> Week <input type="text" value="First"/> Month <input type="text" value="Jan"/> Time <input type="text"/>
	To: Day <input type="text" value="Sun"/> Week <input type="text" value="First"/> Month <input type="text" value="Jan"/> Time <input type="text"/>
Non-recurring	From: <input type="text"/> YYYY-MM-DD <input type="text"/> HH:MM
	To: <input type="text"/> YYYY-MM-DD <input type="text"/> HH:MM
Operational Status	
Current Time	2023-03-17 14:33:02 UTC+8
<input type="button" value="Apply"/>	

- **Type:** Select the mode of daylight saving time.
 - **Disable:** Disable daylight saving time.
 - **Recurring:** Using recurring mode of daylight saving time.
 - **Non-Recurring:** Using non-recurring mode of daylight saving time.
 - **USA:** Using daylight saving time in the United States that starts on the second Sunday of March and ends on the first Sunday of November.
 - **European:** Using daylight saving time in the Europe that starts on the last Sunday in March and ending on the last.
- **Offset :** Specify the adjust offset of daylight saving time.
- **Recurring From:** Specify the starting time of recurring daylight saving time. This field available when selecting "Recurring" mode.
- **Recurring To:** Specify the ending time of recurring daylight saving time. This field available when selecting "Recurring" mode.
- **Non-recurring From:** Specify the starting time of non-recurring daylight saving time. This field available when selecting "Non-Recurring" mode.
- **Non recurring To:** Specify the ending time of recurring daylight saving time. This field available when selecting "Non-Recurring" mode.

Operational Status

Current Time: Display the current operating time

Click the **"Apply"** button to save your changes settings.

5. Port

5.1 Port setting

This page shows port current status and allow user to edit port configurations. Select port entry and click “Edit” button to edit port configurations.

Port → Port Setting																																																																																																																							
<ul style="list-style-type: none"> Status Network Port <ul style="list-style-type: none"> Port Setting Error Disabled Link Aggregation EEE Jumbo Frame POE Setting VLAN MAC Address Table Spanning Tree ERPS Discovery DHCP Multicast 	Port Setting Table <div> <input type="text"/> </div> <table> <tr> <th><input type="checkbox"/></th><th>Entry</th><th>Port</th><th>Type</th><th>Description</th><th>State</th><th>Link Status</th><th>Speed</th><th>Duplex</th><th>Flow Control</th></tr> <tr> <td><input type="checkbox"/></td><td>25</td><td>GE25</td><td>1000M Combo Copper</td><td>Managmentport</td><td>Enabled</td><td>Up</td><td>Auto (1000M)</td><td>Auto (Full)</td><td>Enabled (Off)</td></tr> <tr> <td><input type="checkbox"/></td><td>27</td><td>GE27</td><td>1000M Combo Copper</td><td></td><td>Enabled</td><td>Up</td><td>Auto (10M)</td><td>Auto (Full)</td><td>Disabled (Off)</td></tr> <tr> <td><input type="checkbox"/></td><td>1</td><td>GE1</td><td>1000M Copper</td><td></td><td>Enabled</td><td>Down</td><td>Auto</td><td>Auto</td><td>Disabled</td></tr> <tr> <td><input type="checkbox"/></td><td>2</td><td>GE2</td><td>1000M Copper</td><td></td><td>Enabled</td><td>Down</td><td>Auto</td><td>Auto</td><td>Disabled</td></tr> <tr> <td><input type="checkbox"/></td><td>3</td><td>GE3</td><td>1000M Copper</td><td></td><td>Enabled</td><td>Down</td><td>Auto</td><td>Auto</td><td>Disabled</td></tr> <tr> <td><input type="checkbox"/></td><td>4</td><td>GE4</td><td>1000M Copper</td><td></td><td>Enabled</td><td>Down</td><td>Auto</td><td>Auto</td><td>Disabled</td></tr> <tr> <td><input type="checkbox"/></td><td>5</td><td>GE5</td><td>1000M Copper</td><td></td><td>Enabled</td><td>Down</td><td>Auto</td><td>Auto</td><td>Disabled</td></tr> <tr> <td><input type="checkbox"/></td><td>6</td><td>GE6</td><td>1000M Copper</td><td></td><td>Enabled</td><td>Down</td><td>Auto</td><td>Auto</td><td>Disabled</td></tr> <tr> <td><input type="checkbox"/></td><td>7</td><td>GE7</td><td>1000M Copper</td><td></td><td>Enabled</td><td>Down</td><td>Auto</td><td>Auto</td><td>Disabled</td></tr> <tr> <td><input type="checkbox"/></td><td>8</td><td>GE8</td><td>1000M Copper</td><td></td><td>Enabled</td><td>Down</td><td>Auto</td><td>Auto</td><td>Disabled</td></tr> </table>									<input type="checkbox"/>	Entry	Port	Type	Description	State	Link Status	Speed	Duplex	Flow Control	<input type="checkbox"/>	25	GE25	1000M Combo Copper	Managmentport	Enabled	Up	Auto (1000M)	Auto (Full)	Enabled (Off)	<input type="checkbox"/>	27	GE27	1000M Combo Copper		Enabled	Up	Auto (10M)	Auto (Full)	Disabled (Off)	<input type="checkbox"/>	1	GE1	1000M Copper		Enabled	Down	Auto	Auto	Disabled	<input type="checkbox"/>	2	GE2	1000M Copper		Enabled	Down	Auto	Auto	Disabled	<input type="checkbox"/>	3	GE3	1000M Copper		Enabled	Down	Auto	Auto	Disabled	<input type="checkbox"/>	4	GE4	1000M Copper		Enabled	Down	Auto	Auto	Disabled	<input type="checkbox"/>	5	GE5	1000M Copper		Enabled	Down	Auto	Auto	Disabled	<input type="checkbox"/>	6	GE6	1000M Copper		Enabled	Down	Auto	Auto	Disabled	<input type="checkbox"/>	7	GE7	1000M Copper		Enabled	Down	Auto	Auto	Disabled	<input type="checkbox"/>	8	GE8	1000M Copper		Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	Entry	Port	Type	Description	State	Link Status	Speed	Duplex	Flow Control																																																																																																														
<input type="checkbox"/>	25	GE25	1000M Combo Copper	Managmentport	Enabled	Up	Auto (1000M)	Auto (Full)	Enabled (Off)																																																																																																														
<input type="checkbox"/>	27	GE27	1000M Combo Copper		Enabled	Up	Auto (10M)	Auto (Full)	Disabled (Off)																																																																																																														
<input type="checkbox"/>	1	GE1	1000M Copper		Enabled	Down	Auto	Auto	Disabled																																																																																																														
<input type="checkbox"/>	2	GE2	1000M Copper		Enabled	Down	Auto	Auto	Disabled																																																																																																														
<input type="checkbox"/>	3	GE3	1000M Copper		Enabled	Down	Auto	Auto	Disabled																																																																																																														
<input type="checkbox"/>	4	GE4	1000M Copper		Enabled	Down	Auto	Auto	Disabled																																																																																																														
<input type="checkbox"/>	5	GE5	1000M Copper		Enabled	Down	Auto	Auto	Disabled																																																																																																														
<input type="checkbox"/>	6	GE6	1000M Copper		Enabled	Down	Auto	Auto	Disabled																																																																																																														
<input type="checkbox"/>	7	GE7	1000M Copper		Enabled	Down	Auto	Auto	Disabled																																																																																																														
<input type="checkbox"/>	8	GE8	1000M Copper		Enabled	Down	Auto	Auto	Disabled																																																																																																														

Field	Description
Port	Display for Port Name.
Type	Display for Port media type.
Description	Display custom port description.
State	Display for Port admin state. <ul style="list-style-type: none"> Enabled: Enable the port. Disabled: Disable the port.
Link Status	Current port link status. <ul style="list-style-type: none"> Up: Port is link up. Down: Port is link down.
Speed	Current port speed configuration and link speed status.
Duplex	Current port duplex configuration and link duplex status.
Flow Control	Current port flow control configuration and link flow control status.

Administrator can set speed / Duplex / Flow Control by each port.

Please select port number in checkbox and click apply button to set speed / Duplex / Flow Control of each port.

Edit Port Setting

Port	GE25	
Description	<input type="text" value="Managmentport"/>	
State	<input checked="" type="checkbox"/> Enable	
Speed	<input checked="" type="radio"/> Auto	<input type="radio"/> 10M
	<input type="radio"/> Auto - 10M	<input type="radio"/> 100M
	<input type="radio"/> Auto - 100M	<input type="radio"/> 1000M
	<input type="radio"/> Auto - 1000M	
Duplex	<input checked="" type="radio"/> Auto	
	<input type="radio"/> Full	
	<input type="radio"/> Half	
Flow Control	<input type="radio"/> Auto	
	<input checked="" type="radio"/> Enable	
	<input type="radio"/> Disable	

- **Port:** Selected port list.
- **Description:** Custom port description
- **State:** Port admin state.
 - **Enabled:** Enable the port.
 - **Disabled:** Disable the port.
- **Speed:** Port speed capabilities.
 - **Auto:** Auto speed with all capabilities
 - **Auto-10M:** Auto speed with 10M ability only
 - **Auto-100M:** Auto speed with 100M ability only
 - **Auto-1000M:** Auto speed with 1000M ability only
 - **Auto-10M/100M:** Auto speed with 10M/100M abilities
 - **10M:** Force speed with 10M ability
 - **100M:** Force speed with 100M ability
 - **1000M:** Force speed with 1000M ability
- **Duplex:** Port duplex capabilities.
 - **Auto:** Auto duplex with all capabilities
 - **Half:** Auto speed with 10M and 100M ability only
 - **Full:** Auto speed with 10M/100M/1000M ability only
- **Flow Control:** Port flow control.
 - **Auto:** Auto flow control by negotiation
 - **Enabled:** Enable flow control ability
 - **Disabled:** Disable flow control ability

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

5.2 Error Disabled

This function can block of faulty operation, including EPDU Guard / UDLD / Self Loop / Broadcast Flood / Unknown Multicast Flood / Unicast Flood / ACL / Port Security / DHCP Rate Limit / ARP Rate Limit etc.

After administrator enable this functions, if occur error in table functions then system will auto immediate block of faulty operation until the after the set time, system will auto re-enable.

Recovery Interval	<input type="text" value="300"/> Sec (30 - 86400)
BPDU Guard	<input checked="" type="checkbox"/> Enable
UDLD	<input checked="" type="checkbox"/> Enable
Self Loop	<input checked="" type="checkbox"/> Enable
Broadcast Flood	<input checked="" type="checkbox"/> Enable
Unknown Multicast Flood	<input checked="" type="checkbox"/> Enable
Unicast Flood	<input checked="" type="checkbox"/> Enable
ACL	<input checked="" type="checkbox"/> Enable
Port Security	<input checked="" type="checkbox"/> Enable
DHCP Rate Limit	<input checked="" type="checkbox"/> Enable
ARP Rate Limit	<input checked="" type="checkbox"/> Enable

- **Recovery Interval:** Auto recovery after this interval for error disabled port.
- **BPDU Guard:** Enabled to auto shutdown port when BPDU Guard reason occur.
*This reason caused by STP BPDU Guard mechanism.
- **UDLD:** Enabled to auto shutdown port when UDLD violation occur.
- **Self Loop:** Enabled to auto shutdown port when Self Loop reason occur.
- **Broadcast Flood:** Enabled to auto shutdown port when Broadcast Flood reason occur.
*This reason caused by broadcast rate exceed broadcast storm control rate.
- **Unknown Multicast Flood:** Enabled to auto shutdown port when Unknown Multicast Flood reason occur. This reason caused by unknown multicast rate exceed unknown multicast storm control rate.
- **Unicast Flood:** Enabled to auto shutdown port when Unicast Flood reason occur.
*This reason caused by unicast rate exceed unicast storm control rate.
- **ACL:** Enabled to auto shutdown port when ACL shutdown port reason occur.
* This reason caused packet match the ACL shutdown port action.
- **Port Security:** Enabled to auto shutdown port when Port Security Violation reason occur.
*This reason caused by violation port security rules.
- **DHCP rate limit:** Enabled to auto shutdown port when DHCP rate limit reason occur.
*This reason caused by DHCP packet rate exceed DHCP rate limit.
- **ARP rate limit:** Enabled to auto shutdown port when ARP rate limit reason occur.
*This reason caused by DHCP packet rate exceed ARP rate limit.

Click the **"Apply"** button to save your changes settings.

5.3 Link Aggregation

Link Aggregation is also referred to as link aggregation, teaming port, and port trunk for 802.3ad (LACP, Link Aggregation Control Protocol). The Port Aggregation can aggregate multiple Ethernet ports together to form a logical aggregation group. To upper layer entities, all the physical links in an aggregation group are a single logical link.

5.3.1 Group Configuration

Administrator can select use MAC Address or IP-MAC address of load balance Algorithm.

This system default can set 8 LA group, administrator can select LAG number and click Edit button go to set LA used ports.

Port → Link Aggregation → Group

- Status
- Network
- Port**
 - Port Setting
 - Error Disabled
 - Link Aggregation
 - Group**
 - Port Setting
 - LACP
 - EEE
 - Jumbo Frame
 - POE Setting
 - VLAN
 - MAC Address Table
 - Spanning Tree
 - ERPS
 - Discovery
 - DHCP
 - Multicast
 - IP Configuration
 - Security
 - ACL

Load Balance Algorithm
☒ MAC Address
 ☐ IP-MAC Address

Apply

Link Aggregation Table

	LAG	Name	Type	Link Status	Active Member
<input checked="" type="radio"/>	LAG 1		---	---	
<input type="radio"/>	LAG 2		---	---	
<input type="radio"/>	LAG 3		---	---	
<input type="radio"/>	LAG 4		---	---	
<input type="radio"/>	LAG 5		---	---	
<input type="radio"/>	LAG 6		---	---	
<input type="radio"/>	LAG 7		---	---	
<input type="radio"/>	LAG 8		---	---	

Edit

➤ **Load Balance Algorithm:** LAG load balance distribution algorithm.

- **MAC Address:** Based on MAC address.
- **IP-MAC Address:** Based on MAC address and IP address.

Click the **"Apply"** button to save your changes settings.

Field	Description
LAG	LAG Name.
Name	LAG port description.
Type	<p>The type of the LAG.</p> <ul style="list-style-type: none"> • Static: The group of ports assigned to a static LAG are always active members. • LACP: The group of ports assigned to dynamic LAG are candidate ports. LACP determines which candidate ports are active member ports.
Link Status	LAG port link status.
Active Member	Active member ports of the LAG.
Inactive Member	Inactive member ports of the LAG.

Edit Link Aggregation Group

LAG	1	
Name	LAGGRPOUP-1	
Type	<input checked="" type="radio"/> Static <input type="radio"/> LACP	
Member	Available Port GE1 GE2 GE3 GE4 GE5 GE6 GE7 GE8	Selected Port

- **LAG:** Selected LAG group ID.
- **Name:** LAG port description.
- **Type:** The type of the LAG.
 - **Static:** The group of ports assigned to a static LAG are always active members.
 - **LACP:** The group of ports assigned to dynamic LAG are candidate ports. LACP determines which candidate ports are active member ports.
- **Member:** Select available port to be LAG group member port.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

5.3.2 Port Setting

This page shows LAG port current status and allow user to edit LAG port configurations. Select LAG entry and click “Edit” button to edit LAG port configurations.

Port → Link Aggregation → Port Setting

- ▼ Status
- ▼ Network
- ▼ Port
 - Port Setting
 - Error Disabled
 - Link Aggregation
 - Group
 - Port Setting
 - LACP
 - EEE
 - Jumbo Frame
 - ▼ POE Setting
 - ▼ VLAN
 - ▼ MAC Address Table
 - ▼ Spanning Tree
 - ▼ ERPS
 - ▼ Discovery

Port Setting Table

<input type="checkbox"/>	LAG	Type	Description	State	Link Status	Speed	Duplex	Flow Control
<input type="checkbox"/>	LAG 1		SalesDept	Enabled	Down	Auto	Auto	Enabled
<input type="checkbox"/>	LAG 2		ACCDept	Enabled	Down	Auto - 100M	Auto	Disabled
<input type="checkbox"/>	LAG 3		ENGDept	Enabled	Down	Auto - 1000M	Auto	Enabled
<input type="checkbox"/>	LAG 4			Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	LAG 5			Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	LAG 6			Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	LAG 7			Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	LAG 8			Enabled	Down	Auto	Auto	Disabled

[Edit](#)

Field	Description
LAG	Display for LAG Port Name.
Type	Display for LAG Port media type.
Description	Display custom LAG Port description.
State	LAG Port admin state. <ul style="list-style-type: none"> • Enabled: Enable the port. • Disabled: Disable the port.
Link Status	Current LAG port link status. <ul style="list-style-type: none"> • Up: Port is link up. • Down: Port is link down.
Speed	Current LAG port speed configuration and link speed status.
Duplex	Current LAG port duplex configuration and link duplex status.
Flow Control	Current LAG port flow control configuration and link flow control status.

Edit Port Setting

Port	LAG2
Description	<input type="text" value="RDDept"/>
State	<input checked="" type="checkbox"/> Enable
Speed	<input checked="" type="radio"/> Auto <input type="radio"/> 10M <input type="radio"/> Auto - 10M <input type="radio"/> 100M <input type="radio"/> Auto - 100M <input type="radio"/> 1000M <input type="radio"/> Auto - 1000M <input type="radio"/> Auto - 10M/100M
Flow Control	<input checked="" type="radio"/> Auto <input type="radio"/> Enable <input type="radio"/> Disable

- **Port:** Selected port list.
- **Description:** Custom LAG Port description.
- **State:** Port admin state.
 - **Enabled:** Enable the port.
 - **Disabled:** Disable the port.
- **Speed:** Port speed capabilities.
 - **Auto:** Auto speed with all capabilities
 - **Auto-10M:** Auto speed with 10M ability only
 - **Auto-100M:** Auto speed with 100M ability only
 - **Auto-1000M:** Auto speed with 1000M ability only
 - **Auto-10M/100M:** Auto speed with 10M/100M abilities
 - **10M:** Force speed with 10M ability
 - **100M:** Force speed with 100M ability
 - **1000M:** Force speed with 1000M ability
- **Flow Control:** Port flow control.
 - **Auto:** Auto flow control by negotiation
 - **Enabled:** Enable flow control ability
 - **Disabled:** Disable flow control ability

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

5.3.3 LACP

The LACP can aggregate multiple Ethernet ports together to form a logical aggregation group. To upper layer entities, all the physical links in an aggregation group are a single logical link.

Administrator can to configure LACP global and port configurations. Select ports and click “Edit” button to edit port configuration.

Port → Link Aggregation → LACP

- Status
- Network
- Port**
 - Port Setting
 - Error Disabled
 - Link Aggregation
 - Group
 - Port Setting
 - LACP**
 - EEE
 - Jumbo Frame
 - POE Setting
 - VLAN
 - MAC Address Table
 - Spanning Tree
 - ERPS
 - Discovery
 - DHCP
 - Multicast

System Priority

(1 - 65535, default 32768)

Apply

LACP Port Setting Table

Q

<input type="checkbox"/>	Entry	Port	Port Priority	Timeout
<input type="checkbox"/>	1	GE1	1	Short
<input type="checkbox"/>	2	GE2	2	Long
<input type="checkbox"/>	3	GE3	5	Short
<input type="checkbox"/>	4	GE4	5	Short
<input type="checkbox"/>	5	GE5	1	Long
<input type="checkbox"/>	6	GE6	1	Long
<input type="checkbox"/>	7	GE7	1	Long
<input type="checkbox"/>	8	GE8	1	Long

- **System Priority:** Administrator configures the LACP system priority on each switch running LACP. LACP uses the system priority with the switch MAC address to form the system ID and also during negotiation with other switches. This decides the system priority field in LACP PDU.

Click the “**Apply**” button to save your changes settings.

Note

The function with the lower system priority value determines which links between LACP partner devices are active and which are in standby for each LACP group. The device on the controlling end of the link uses port priorities to determine which ports are bundled into the aggregated bundle and which ports are put in standby mode. Port priorities on the other device (the no controlling end of the link) are ignored. In priority comparisons, numerically lower values have higher priority. Therefore, the system with the numerically lower value (higher priority value) for LACP system priority becomes the controlling system. If both devices have the same LACP system priority (for example, they are both configured with the default setting of 32768), the device MAC address determines which switch is in control.

Field	Description
Port	Port Name.
Port Priority	LACP priority value of the port.
Timeout	<p>The periodic transmissions type of LACP PDUs.</p> <ul style="list-style-type: none"> • Long: Transmit LACP PDU with slow periodic (30s). • Short: Transmit LACPP DU with fast periodic (1s).

- **Port:** Selected port list.
- **Port Priority:** Enter the LACP priority value of the port.
- **Timeout:** The periodic transmissions type of LACP PDUs.
 - **Long:** Transmit LACP PDU with slow periodic (30s).
 - **Short:** Transmit LACPP DU with fast periodic (1s).

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

5.4 EEE

Energy Efficient Ethernet (EEE) combines the MAC with a family of physical layers that support operation in a low power mode. It is defined by IEEE 802.3az Energy Efficient Task Force. Lower power mode enables both the send and receive sides of the link to disable some functionality for power savings when lightly loaded. Transition to low power mode does not change the link status. Frames in transit are not dropped or corrupted in transition to and from low power mode. Transition time is transparent to upper layer protocols and applications.

This switch support Energy-efficient Ethernet(EEE) function. Administrator can by ports to setting Enable or Disable for the EEE function. The default is “Disable”.

Port → EEE

- Status
- Network
- Port**
 - Port Setting
 - Error Disabled
 - Link Aggregation
 - Group
 - Port Setting
 - LACP
 - EEE**
 - Jumbo Frame
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery

EEE Setting Table

<input type="checkbox"/>	Entry	Port	State
<input type="checkbox"/>	1	GE1	Enabled
<input type="checkbox"/>	2	GE2	Enabled
<input type="checkbox"/>	3	GE3	Enabled
<input checked="" type="checkbox"/>	4	GE4	Enabled
<input type="checkbox"/>	5	GE5	Enabled
<input checked="" type="checkbox"/>	6	GE6	Disabled
<input type="checkbox"/>	7	GE7	Enabled
<input checked="" type="checkbox"/>	8	GE8	Disabled
<input type="checkbox"/>	9	GE9	Enabled
<input type="checkbox"/>	10	GE10	Disabled

Field	Description
Port	Port Name
State/Operational Status	Port EEE admin state. <ul style="list-style-type: none"> Enabled: EEE is enabled/ is operating Disabled: EEE is disabled/ is no operating

Edit EEE Setting

Port

GE3,GE7,GE9,GE12-GE13

State

☒ Enable

Apply

Close

- **Port:** Selected port list.
- **State:** Port EEE admin state.
 - **Enable:** Enable EEE
 - **Disable:** Disable EEE

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

5.5 Jumbo Frame

The administrator can set the Jumbo Frame size and display it on this page.

- **Jumbo Frame:** Enable or disable jumbo frame. When jumbo frame is enabled, switch max frame size is allowed to configure. When jumbo frame is disabled, default frame size 1522 will be used.

Note	<p>When jumbo frames are required, the maximum frame size (10000) of the switch is allowed to be configured.</p> <p>Uncheck to apply :</p> <p>When you click uncheck to “Apply” , The switch will back to default regular frame size "1522".</p>
-------------	---

Click the “**Apply**” button to save your changes settings.

6. POE

PoE or Power over Ethernet is an IEEE standard used to pass electrical power along with data over standard Ethernet Cable. Utilising 2 of the 4 pairs of an Ethernet Cable PoE provides up to 15.4W (IEEE 802.3af) or 25.5W (IEEE 802.3at) of power. PoE is used to power devices such as IP Cameras, Wireless Access Points and IP Phone. Being able to use a single cable to run both data and power saves in cabling costs, helps unclutter messy cables on your desk and is perfect for those environments where a power point is not able to be installed where your Ethernet equipment is needed.

The PoE switches are IEEE 802.3at compliant and can supply up to 25.5W per port.

Advanced features such as PoE Power scheduling, PoE priority and having the ability to allocate a particular amount of power per port are just some of the features that the PoE Switch support.

6.1 POE Port Setting

This page system can displayed PoE port is enable or disable and on /off , calculate used PoE type /PoE Level / Actual power(mW) / Power Voltage(V) / Current(mA), Refresh Rate None or 5/10/30sec information.

POE Setting → POE Port Setting

- ▼ Status
- ▼ Network
- ▼ Port
- ▼ POE Setting
 - POE Port Setting
 - POE Port Timer Setting
- ▼ VLAN
- ▼ MAC Address Table
- ▼ Spanning Tree
- ▼ ERPS
- ▼ Discovery
- ▼ DHCP
- ▼ Multicast
- ▼ IP Configuration
- ▼ Security
- ▼ ACL
- ▼ QoS
- ▼ Diagnostics
- ▼ Management

System info

System Power(W)	0
System Temperature(C)	35
Refresh Rate	<input type="radio"/> None <input type="radio"/> 5 sec <input checked="" type="radio"/> 10 sec <input type="radio"/> 30 sec

Port Setting Table

	Entry	Port	PortEnable	Status	Type	Level	Actual Power(mW)	Voltage(V)	Current(mA)
<input type="checkbox"/>	1	GE1	Disabled	Off	AF(N)	N/A	N/A	N/A	N/A
<input type="checkbox"/>	2	GE2	Disabled	Off	AF(N)	N/A	N/A	N/A	N/A
<input type="checkbox"/>	3	GE3	Enabled	Off	AF(N)	0	N/A	N/A	N/A
<input type="checkbox"/>	4	GE4	Enabled	Off	AF(N)	0	N/A	N/A	N/A
<input type="checkbox"/>	5	GE5	Disabled	Off	AF(N)	N/A	N/A	N/A	N/A
<input type="checkbox"/>	6	GE6	Enabled	Off	AF(N)	0	N/A	N/A	N/A
<input type="checkbox"/>	7	GE7	Enabled	Off	AF(N)	0	N/A	N/A	N/A
<input type="checkbox"/>	8	GE8	Disabled	Off	AF(N)	N/A	N/A	N/A	N/A
<input type="checkbox"/>	9	GE9	Enabled	Off	AF(N)	0	N/A	N/A	N/A
<input type="checkbox"/>	10	GE10	Enabled	Off	AF(N)	0	N/A	N/A	N/A

- **System Power(W)** : Display the POE system power (Watt).
- **System Temperature(C)** : Display the system temperature (°C).
- **Refresh Rate** : Refresh the web page every period of "None , 5 sec , 10 sec , 30 sec "seconds base to get new counter of specified POE port.

Field	Description
Port	Port Name.
Port Enable	Port admin state. <ul style="list-style-type: none"> • Enabled: POE Port is enabled. • Disabled: POE Port is disabled.
Status	Port POE admin state. <ul style="list-style-type: none"> • On: POE is operating. • Off: POE is no operating.
Type	Display the type of POE, including AF (Y) connected / AF (N) not connected / AT (Y) connected / AT (N) not connected.
Level	Display the Class level used by POE, displayed 0/1/2/3/4 as Class0 / Class1 / Class2 /Class3 / Class4.
Actual Power(mW)	Display the POE actual power used (mW).

Voltage(V) Display the POE Voltage used (V).

Current(mA) Display the POE Current used (mA).

Select the port form 1 - 24 port to be set, and click "Edit" to edit the settings.

Edit Port Setting

Port

GE1,GE3,GE7-GE8

PortEnable

☐ Enable
☒ Disable

Apply

Close

This section is used to enable/disable PoE on a per port basis, set the POE enable/disable per port on this PoE switches.

- **Port :** Will be displayed based on your selection.
 - **Enable :** PoE enabled for the port.
 - **Disable :** PoE disabled for the port.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

6.2 POE Port Time Setting

The PoE switch supports a PoE scheduling feature that allows administrators to turn off devices when they are not in use. This can be used as a power saving function, or as a power restart control for the PD device. At the same time, the power consumption of the switch can be effectively limited through the power time control.To configure the PoE Scheduling function via the Web Interface, Set the desired time for the device to power on by ticking and checkbox and modify for your configuration.

POE Setting → POE Port Timer Setting

Status

Network

Port

POE Setting

VLAN

MAC Address Table

Spanning Tree

ERPS

Discovery

DHCP

Multicast

IP Configuration

Port

GE1

GE1

GE2

GE3

GE4

Mon GE5

Tue GE6

Wed GE7

Thu GE8

Fri GE9

Sat GE10

Sun GE11

GE12

GE13

GE14

03

04

05

06

07

08

09

10

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

✓

- **Port** : Select one port to set time schedule.

Port
GE3

	00	01	02	03	04	05	06	07	08	09	10	11	12	13
Wed	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Tue	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Thu	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Sun	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Sat	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Mon	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Fri	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Apply

- **Mon/Tue/Wed/Thu/Fri/Sat/Sun** : Select POE start time based on Monday-Sunday and 00-23 hours.

Click the **“Apply”** button to save your changes settings.

7. VLAN

A virtual local area network, virtual LAN or VLAN, is a group of hosts with a common set of requirements that communicate as if they were attached to the same broadcast domain, regardless of their physical location. A VLAN has the same attributes as a physical local area network (LAN), but it allows for end stations to be grouped together even if they are not located on the same network switch.

The **CS-3424G-24P** adding Virtual LAN (VLAN) support to a Layer 2 switch offers some of the benefits of both bridging and routing. Like a bridge, a VLAN switch forwards traffic based on the Layer 2 header, which is fast, and like a router, it partitions the network into logical segments, which provides better administration, security and management of multicast traffic.

Administrator can set IEEE 802.1q Tag Based VLAN or Port Based VLAN. System default is VLAN1 Port based (PVID).

7.1 VLAN

7.1.1 Create VLAN

Administrator can select VLAN number in Available VLAN list, this VLAN number based on IEEE 802.1q standard. Available VLAN list can be multiple choices.

VLAN → VLAN → Create VLAN

- Status
- Network
- Port
- POE Setting
- VLAN**
 - VLAN
 - Create VLAN
 - VLAN Configuration
 - Membership
 - Port Setting
 - Voice VLAN
 - Protocol VLAN
 - MAC VLAN
 - Surveillance VLAN
 - GVRP
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration

Available VLAN

VLAN 2
VLAN 3
VLAN 4
VLAN 5
VLAN 6
VLAN 7
VLAN 8
VLAN 9

Created VLAN

VLAN 1
VLAN 4094

Apply

VLAN Table

Showing All entries Showing 1

	VLAN	Name	Type	VLAN Interface State
<input type="checkbox"/>	1	default	Default	Enabled
<input checked="" type="checkbox"/>	4094	VLAN4094	Static	Disabled

Edit Delete

- **VLAN:** Administrator can select VLANs number in "Available VLAN" table and move to "Created VLAN" table will complete the 802.1q VLAN.

Click the **"Apply"** button to save your changes settings.

VLAN Table: Administrator can checkbox VLAN to edit or delete, if check and click "Edit" button then administrator can manual modify name description for this VLAN.

Edit VLAN Name

Name

Apply Close

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

7.1.2 VLAN Configuration

Administrator can choose set Excluded / Forbidden / Tagged / Untagged function in membership table of the Port and LAG.

VLAN → VLAN → VLAN Configuration

- ▼ Status
- ▼ Network
- ▼ Port
- ▼ POE Setting
- ▼ **VLAN**
 - ⊕ VLAN
 - Create VLAN
 - VLAN Configuration**
 - Membership
 - Port Setting
 - ⊕ Voice VLAN
 - ⊕ Protocol VLAN
 - ⊕ MAC VLAN
 - ⊕ Surveillance VLAN
 - ⊕ GVRP
- ▼ MAC Address Table
- ▼ Spanning Tree
- ▼ ERPS
- ▼ Discovery
- ▼ DHCP

VLAN Configuration Table

VLAN VLAN4094 ▼

Entry	Port	Mode	Membership			PVID	Forbidden
1	GE1	Trunk	<input type="radio"/> Excluded	<input type="radio"/> Tagged	<input checked="" type="radio"/> Untagged	<input checked="" type="checkbox"/>	<input type="checkbox"/>
2	GE2	Trunk	<input type="radio"/> Excluded	<input type="radio"/> Tagged	<input checked="" type="radio"/> Untagged	<input checked="" type="checkbox"/>	<input type="checkbox"/>
3	GE3	Trunk	<input checked="" type="radio"/> Excluded	<input type="radio"/> Tagged	<input type="radio"/> Untagged	<input type="checkbox"/>	<input type="checkbox"/>
4	GE4	Trunk	<input checked="" type="radio"/> Excluded	<input type="radio"/> Tagged	<input type="radio"/> Untagged	<input type="checkbox"/>	<input type="checkbox"/>
5	GE5	Trunk	<input type="radio"/> Excluded	<input checked="" type="radio"/> Tagged	<input type="radio"/> Untagged	<input type="checkbox"/>	<input type="checkbox"/>
6	GE6	Trunk	<input type="radio"/> Excluded	<input checked="" type="radio"/> Tagged	<input type="radio"/> Untagged	<input type="checkbox"/>	<input type="checkbox"/>
7	GE7	Trunk	<input checked="" type="radio"/> Excluded	<input type="radio"/> Tagged	<input type="radio"/> Untagged	<input type="checkbox"/>	<input checked="" type="checkbox"/>
8	GE8	Trunk	<input checked="" type="radio"/> Excluded	<input type="radio"/> Tagged	<input type="radio"/> Untagged	<input type="checkbox"/>	<input checked="" type="checkbox"/>
9	GE9	Trunk	<input checked="" type="radio"/> Excluded	<input type="radio"/> Tagged	<input type="radio"/> Untagged	<input type="checkbox"/>	<input checked="" type="checkbox"/>
10	GE10	Trunk	<input checked="" type="radio"/> Excluded	<input type="radio"/> Tagged	<input type="radio"/> Untagged	<input type="checkbox"/>	<input type="checkbox"/>
11	GE11	Trunk	<input checked="" type="radio"/> Excluded	<input type="radio"/> Tagged	<input type="radio"/> Untagged	<input type="checkbox"/>	<input type="checkbox"/>
12	GE12	Trunk	<input checked="" type="radio"/> Excluded	<input type="radio"/> Tagged	<input type="radio"/> Untagged	<input type="checkbox"/>	<input type="checkbox"/>

Field	Description
VLAN	Select specified VLAN ID to configure VLAN configuration.
Port	Display the interface of port entry.
Mode	Display the interface VLAN mode of port.
Membership	Select the membership for this port of the specified VLAN ID. <ul style="list-style-type: none"> • Forbidden: Specify the port is forbidden in the VLAN. • Excluded: Specify the port is excluded in the VLAN. • Tagged: Specify the port is tagged member in the VLAN. • Untagged: Specify the port is untagged member in the VLAN.
PVID	Display if it is PVID of interface.
Forbidden	Forbidden: Specify the port is forbidden in the VLAN.

- **VLAN:** Administrator can click drop down menu to choose VLAN and set.
- **Excluded:** This interface is currently not a member of the VLAN. This is the default for all the ports and LAGs.
 - **Tagged:** This interface is a tagged member of the VLAN.
 - **Untagged:** This interface is an untagged member of the VLAN. Frames of the VLAN are sent untagged to the interface VLAN.
 - **PVID:** Check to set the PVID of the interface to the VID of the VLAN. PVID is a per-port setting.
 - **Forbidden:** Select for this specified port of the Forbidden.

7.1.3 Membership

Display all port setting information. Administrator can checkbox and click “**Edit**” button to modify VLAN type. *(Note: Number=VLAN number, F=Forbidden, T=Tagged, U=Untagged, P=PVID)*

When a port is forbidden default VLAN membership, that port is not allowed membership in any other VLAN. An internal VID of 4095 is assigned to the port. This PVID on the ports between the two devices must be the same if the ports are to send and receive untagged packets to and from the VLAN. Otherwise, traffic might leak from one VLAN to another.

VLAN → VLAN → Membership

- Status
- Network
- Port
- POE Setting
- VLAN**
 - VLAN
 - Create VLAN
 - VLAN Configuration
 - Membership**
 - Port Setting
 - Voice VLAN
 - Protocol VLAN
 - MAC VLAN
 - Surveillance VLAN
 - GVRP
- MAC Address Table
- Spanning Tree

Membership Table

	Entry	Port	Mode	Administrative VLAN	Operational VLAN
<input type="radio"/>	1	GE1	Trunk	1UP	1UP
<input type="radio"/>	2	GE2	Trunk	1UP	1UP
<input checked="" type="radio"/>	3	GE3	Trunk	1UP	1UP
<input type="radio"/>	4	GE4	Trunk	1UP	1UP
<input type="radio"/>	5	GE5	Trunk	1UP	1UP
<input type="radio"/>	6	GE6	Trunk	1UP	1UP
<input type="radio"/>	7	GE7	Trunk	1UP	1UP
<input type="radio"/>	8	GE8	Trunk	1UP	1UP
<input type="radio"/>	9	GE9	Trunk	1UP	1UP
<input type="radio"/>	10	GE10	Trunk	1UP	1UP

Field	Description
Port	Display the interface of port entry.
Mode	Display the interface VLAN mode of port.
Administrative VLAN	Display the administrative VLAN list of this port.
Operational VLAN	Display the operational VLAN list of this port. Operational VLAN means the VLAN status that really runs in device. It may different to administrative VLAN.

Edit Port Setting

Port	GE3		
Mode	Trunk		
Membership	<div>4094</div> <div></div>	<div>1UP</div> <div></div>	
	<div> <input type="radio"/> Forbidden <input type="radio"/> Excluded <input type="radio"/> Tagged <input checked="" type="radio"/> Untagged <input checked="" type="checkbox"/> PVID </div>		

Apply

Close

- **Port:** Display selected port number.
- **Mode:** Displays the port VLAN mode that was selected on the Interface Settings page.
- **Membership:** Move the VLAN IDs from the left list to the right list by using the arrow buttons. The default VLAN might appear in the right list if it is tagged, but it cannot be selected.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

7.1.4 Port Setting

Administrator can set Access / Trunk / Hybrid for VLAN mode.

VLAN → VLAN → Port Setting

- Status
- Network
- Port
- POE Setting
- VLAN**
 - VLAN
 - Create VLAN
 - VLAN Configuration
 - Membership
 - Port Setting
 - Voice VLAN
 - Protocol VLAN
 - MAC VLAN
 - Surveillance VLAN
 - GVRP
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery

Port Setting Table

	Entry	Port	Mode	PVID	Accept Frame Type	Ingress Filtering	Uplink	TPID
<input type="checkbox"/>	1	GE1	Trunk	1	All	Enabled	Disabled	0x8100
<input type="checkbox"/>	2	GE2	Trunk	1	All	Enabled	Disabled	0x8100
<input type="checkbox"/>	3	GE3	Hybrid	4094	Untag Only	Enabled	Disabled	0x8100
<input checked="" type="checkbox"/>	4	GE4	Hybrid	1	Tag Only	Disabled	Disabled	0x8100
<input checked="" type="checkbox"/>	5	GE5	Hybrid	1	Tag Only	Disabled	Disabled	0x8100
<input checked="" type="checkbox"/>	6	GE6	Hybrid	1	Tag Only	Disabled	Disabled	0x8100
<input checked="" type="checkbox"/>	7	GE7	Hybrid	1	Tag Only	Disabled	Disabled	0x8100
<input checked="" type="checkbox"/>	8	GE8	Hybrid	1	Tag Only	Disabled	Disabled	0x8100
<input checked="" type="checkbox"/>	9	GE9	Hybrid	1	Tag Only	Disabled	Disabled	0x8100
<input checked="" type="checkbox"/>	10	GE10	Hybrid	1	Tag Only	Disabled	Disabled	0x8100
<input type="checkbox"/>	11	GE11	Trunk	1	All	Enabled	Disabled	0x8100
<input type="checkbox"/>	12	GE12	Trunk	1	All	Enabled	Disabled	0x8100

Field	Description
Port	Display the interface.
Mode	Display the VLAN mode for Hybrid/Access/Trunk/Tunnel mode of port.
PVID	Display the Port-based VLAN ID of port.
Accept Frame Type	Display accept frame type of port.
Ingress Filtering	Display ingress filter status of port.
Uplink	Display uplink status.
TPID	Display TPID used of interface.

Edit Port Setting

Port	GE4-GE10
Mode	<input checked="" type="radio"/> Hybrid <input type="radio"/> Access <input type="radio"/> Trunk <input type="radio"/> Tunnel
PVID	<input type="text" value="1"/> (1 - 4094)
Accept Frame Type	<input type="radio"/> All <input checked="" type="radio"/> Tag Only <input type="radio"/> Untag Only
Ingress Filtering	<input type="checkbox"/> Enable
Uplink	<input type="checkbox"/> Enable
TPID	<input type="text" value="0x8100"/>

Apply
Close

- **Hybrid:** The interface can be a tagged or untagged member of one or more VLANs.
- **Access:** The interface is an untagged member of a single VLAN. A port configured in this mode is known as an access port.
- **Trunk:** The interface is an untagged member of one VLAN at most, and is a tagged member of zero or more VLANs. A port configured in this mode is known as a trunk port.
- **Tunnel:** This enables the user to use own VLAN arrangements (PVID) across the provider network.
- **PVID:** Enter the Port VLAN ID (PVID) of the VLAN to which incoming untagged and priority tagged frames are classified.
- **Accept Frame Type:** Select the type of frame that the interface can receive. Frames that are not of the configured frame type are discarded at ingress. These frame types are only available in General mode. As follow.

- **All:** The interface accepts all types of frames: untagged frames, tagged frames, and priority tagged frames.
- **Tag Only:** The interface accepts only tagged frames.
- **Untag Only:** The interface accepts only untagged and priority frames.
- **Ingress Filtering:** Administrator can check **Enable** to enable ingress filtering. When an interface is ingress filtering enabled, the interface discards all incoming frames that are classified as VLANs of which the interface is not a member. Ingress filtering can be disabled or enabled on general ports. It is always enabled on access ports and trunk ports.
- **Uplink:** Administrator can check **Enable** to set the interface as an uplink port.
- **TPID:** If Uplink is enabled, select the Modified Tag Protocol Identifier (TPID) value for the interface.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

7.2 Voice VLAN

Voice VLAN allows you to enhance VoIP service by configuring ports to carry IP Voice traffic from IP phones on a specific VLAN. VoIP traffic has a preconfigured OUI prefix in the source MAC address. Administrator can set VLAN ID in the range of 1 to 4094.

7.2.1 Property

VLAN → Voice VLAN → Property

- Status
- Network
- Port
- POE Setting
- VLAN**
 - VLAN
 - Create VLAN
 - VLAN Configuration
 - Membership
 - Port Setting
 - Voice VLAN
 - Property**
 - Voice OUI
 - Protocol VLAN
 - MAC VLAN
 - Surveillance VLAN
 - GVRP
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast

State

☒ Enable

VLAN

VLAN4094

CoS / 802.1p
Remarking

☒ Enable

5

Aging Time

1440

Min (30 - 65536, default 1440)

Apply

Port Setting Table

	Entry	Port	State	Mode	QoS Policy
<input type="checkbox"/>	1	GE1	Disabled	Auto	Voice Packet
<input type="checkbox"/>	2	GE2	Disabled	Auto	Voice Packet
<input type="checkbox"/>	3	GE3	Disabled	Auto	Voice Packet
<input type="checkbox"/>	4	GE4	Disabled	Auto	Voice Packet
<input type="checkbox"/>	5	GE5	Disabled	Auto	Voice Packet
<input type="checkbox"/>	6	GE6	Disabled	Auto	Voice Packet

Click the **"Apply"** button to save your changes settings.

Field	Description
Port	Display port entry.
State	Display enable/disabled status of interface.
Mode	Display voice VLAN mode.
QoS Policy	Display voice VLAN remark will effect which kind of packet.



- **State:** Administrator can choose Enable or Disable this function.
- **VLAN:** Administrator can choose VLAN.
- **CoS / 802.1P Remark:** Administrator can set CoS 802.1p priority level for the VLAN.
- **Port Aging Time:** Administrator can set aging time for this rule.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

7.2.2 Voice OUI

Organizationally Unique Identifiers (OUI) is the first three bytes of a MAC Address, while the last three bytes contain a unique station ID. Administrator can add a specific manufacturer with the OUI. Once the OUI is added, all traffic received on voice VLAN ports from the specific IP phone with a listed OUI is forwarded on the voice VLAN. Unlike the telephony OUI mode that detects voice devices based on telephony OUI, Auto Voice VLAN mode depends on auto smart port to dynamically add the ports to the voice VLAN. The default has set 8 companies for the voice phone.

VLAN → Voice VLAN → Voice OUI

- ▼ Status
- ▼ Network
- ▼ Port
- ▼ POE Setting
- ▼ VLAN
 - ▼ VLAN
 - Create VLAN
 - VLAN Configuration
 - Membership
 - Port Setting
 - ▼ Voice VLAN
 - Property
 - Voice OUI
 - ▼ Protocol VLAN
 - ▼ MAC VLAN
 - ▼ Surveillance VLAN
 - ▼ GVRP

Voice OUI Table

Showing All entries

<input type="checkbox"/>	OUI	Description
<input checked="" type="checkbox"/>	00:E0:BB	3COM
<input checked="" type="checkbox"/>	00:03:6B	Cisco
<input type="checkbox"/>	00:E0:75	Veritel
<input type="checkbox"/>	00:D0:1E	Pingtel
<input type="checkbox"/>	00:01:E3	Siemens
<input type="checkbox"/>	00:60:B9	NEC/Philips
<input type="checkbox"/>	00:0F:E2	H3C
<input type="checkbox"/>	00:09:6E	Avaya

Field	Description
OUI	Display OUI MAC address.
Description	Display description of OUI entry.

Edit Voice OUI

OUI

00:03:6B

Description

Cisco

Administrator can create new OUI or modify or delete OUI in table

Click **“add”** button can create new OUI.

Click **“Edit”** button can modify OUI data.

Click **“Delete”** button can delete OUI data.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

7.3 Protocol VLAN

7.3.1 Protocol Group

Administrator can configure this page to add or edit groups settings of protocol VLAN, Setting “add” and “Edit” and “Delete” function for this management.

VLAN → Protocol VLAN → Protocol Group

- Status
- Network
- Port
- POE Setting
- VLAN**
 - VLAN
 - Create VLAN
 - VLAN Configuration
 - Membership
 - Port Setting
 - Voice VLAN
 - Property
 - Voice OUI
 - Protocol VLAN
 - Protocol Group**
 - Group Binding
 - MAC VLAN
 - Surveillance VLAN
 - GVRP

Protocol Group Table

Showing All entries Showing 1 to 2 of 2 entries

	Group ID	Frame Type	Protocol Value
<input type="checkbox"/>	1	RFC_1042	0x0600
<input type="checkbox"/>	2	IEEE802.3_LL_C_Other	0x0601

Field	Description
Group ID	Display group ID of entry.
Frame Type	Display frame type of entry.
Protocol Value	Display protocol value of entry.

Add Protocol Group

Group ID

1

Frame Type

Ethernet_II

Protocol Value

IEEE802.3_LL_C_Other
RFC_1042

(0x600 ~ 0xFFFFE)

- **Group ID** : Select group ID of list. The range from 1 to 8.
- **Frame Type** : Select frame type of list that maps packets to protocol-defined VLANs by examining the type octet within the packet header to discover the type of protocol associated with it.
 - **Ethernet_II** : packet type is Ethernet version 2.

- **IEEE802.3_LL_C_Other** : packet type is 802.3 packet with LLC other header.
 - **RFC_1042** : packet type is rfc 1042 packet.
- **Protocol Value** : Input protocol value of the target protocol. Packets match this protocol value classified to specified VLAN ID.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

7.3.2 Group Binding

Administrator can configure this bind protocol VLAN group to each port with VLAN ID, Setting **“add”** and **“Edit”** and **“Delete”** function for this management.

VLAN → Protocol VLAN → Group Binding

- ✚ Status
- ✚ Network
- ✚ Port
- ✚ POE Setting
- VLAN
- ✚ VLAN
 - Create VLAN
 - VLAN Configuration
 - Membership
 - Port Setting
- ✚ Voice VLAN
 - Property
 - Voice OUI
- ✚ Protocol VLAN
 - Protocol Group
 - Group Binding

Group Binding Table

Showing All entries Showing 1 to 2 of 2 entries

	Port	Group ID	VLAN
<input type="checkbox"/>	GE5	2	4094
<input type="checkbox"/>	GE6	2	4094

Add
Edit
Delete

Field	Description
Port	Display port ID that binding with protocol group entry.
Group ID	Display group ID that port binding with.
VLAN	Display VLAN ID that assign to packets which match protocol group.

Add Group Binding

Port	Available Port	Selected Port
	<div>GE3</div> <div>GE4</div> <div>GE7</div> <div>GE8</div> <div>GE9</div> <div>GE10</div>	<div>GE5</div> <div>GE6</div>
<small>Note: Only VLAN Hybrid port can be set Protocol VLAN</small>		
Group ID	<div>2</div>	
VLAN	<div>4094</div> <div>(1 - 4094)</div>	

Apply

Close

- **Port** : Select ports in left box then move to right to binding with protocol group. Or select ports in right box then move to left to unbind with protocol group. Only interface has hybrid VLAN mode can be selected and bound with protocol group. Only available on Add dialog. .
- **Group ID** : Select a Group ID to associate with port. Only available on Add dialog.
- **VLAN** : Input VLAN ID that will assign to packets which match protocol group.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

7.4 MAC VLAN

7.4.1 MAC Group

The MAC VLAN feature allows incoming untagged packets to be assigned to a VLAN and thus classify traffic based on the source MAC address of the packet. You define a MAC to VLAN mapping by configuring an entry in the MAC to VLAN table. An entry is specified using a source MAC address and the appropriate VLAN ID. The MAC to VLAN configurations are shared across all ports of the device (i.e., there is a system-wide table that has MAC address to VLAN ID mappings).

When untagged or priority tagged packets arrive at the switch and entries exist in the MAC to VLAN table, the source MAC address of the packet is looked up. If an entry is found, the corresponding VLAN ID is assigned to the packet. If the packet is already priority tagged it will maintain this value; otherwise, the priority will be set to 0 (zero). The assigned VLAN ID is verified against the VLAN table. If the VLAN is valid, ingress processing on the packet continues; otherwise, the packet is dropped. This implies that you can configure a MAC address mapping to a VLAN that has not been created on the system, Setting **“add”** and **“Edit”** and **“Delete”** function for this management.

VLAN → MAC VLAN → MAC Group

- ▼ Status
- ▼ Network
- ▼ Port
- ▼ POE Setting
- ▼ **VLAN**
 - ▼ VLAN
 - Create VLAN
 - VLAN Configuration
 - Membership
 - Port Setting
 - ▼ Voice VLAN
 - Property
 - Voice OUI
 - ▼ Protocol VLAN
 - Protocol Group
 - Group Binding
 - ▼ MAC VLAN
 - MAC Group**

MAC Group Table

Showing entries Showing 1 to 1 of 1 entries

<input type="checkbox"/>	Group ID	MAC Address	Mask
<input type="checkbox"/>	215	8C:4D:EA:FE:CC:AE	24

Field	Description
Group ID	Display group ID of entry.
MAC Address	Display mac address of entry.
Mask	Display mask of mac address for classified packet.

Add MAC Group

Group ID

(1 - 2147483647)

MAC Address

(A:B:C:D:E:F)

Mask

(9 - 48)

- **Group ID:** Add a Group ID number.
- **MAC Address :** Enter the MAC Address.
- **Mask:** Enter the mask of mac address for classified packet..

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

7.4.2 Group Binding

The Group Binding allows user to bind MAC VLAN group to each port with VLAN ID, Setting “add” and “Edit” and “Delete” function for this management.

VLAN → MAC VLAN → Group Binding

- ▼ Status
- ▼ Network
- ▼ Port
- ▼ POE Setting
- ▼ **VLAN**
 - ⌄ VLAN
 - Create VLAN
 - VLAN Configuration
 - Membership
 - Port Setting
 - ⌄ Voice VLAN
 - Property
 - Voice OUI
 - ⌄ Protocol VLAN
 - Protocol Group
 - Group Binding
 - ⌄ MAC VLAN
 - MAC Group
 - Group Binding**

Group Binding Table

Showing All entries Showing 1 to 1 of 1 entries

<input type="checkbox"/>	Port	Group ID	VLAN
<input type="checkbox"/>	GE8	215	4094

First Previous

Add Edit Delete

Field	Description
Field	Description.
Port	Display port ID that binding with protocol group entry.
Group ID	Display group ID that port binding with.
VLAN	Display VLAN ID that assign to packets which match protocol group.

Add Group Binding

Port	Available Port	Selected Port
	GE3 GE4 GE5 GE6 GE7 GE9 GE10	GE8

Note: Only VLAN Hybrid port can be set MAC VLAN

Group ID

VLAN (1 - 4094)

- **Port:** Select the port in the left frame and move to the right to bind to the mac group; or select the port in the right frame and move to the left to bind to the mac group. Only interfaces with mixed VLAN mode can be selected and bound to the protocol group.
- **Group ID:** Choose a Group ID associated with the port.
- **VLAN:** Enter the VLAN ID that will be assigned to packets matching the MAC Group.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

7.5 Surveillance VLAN

7.5.1 Property

Administrator can configure this page to configure global and per interface settings of Surveillance VLAN.

VLAN → Surveillance VLAN → Property

- Status
- Network
- Port
- POE Setting
- VLAN**
 - VLAN
 - Create VLAN
 - VLAN Configuration
 - Membership
 - Port Setting
 - Voice VLAN
 - Property
 - Voice OUI
 - Protocol VLAN
 - Protocol Group
 - Group Binding
 - MAC VLAN
 - MAC Group
 - Group Binding
 - Surveillance VLAN
 - Property

State ☒ Enable

VLAN

CoS / 802.1p ☒ Enable

Remarking

Aging Time Min (30 - 65536, default 1440)

Port Setting Table

	Entry	Port	State	Mode	QoS Policy
<input type="checkbox"/>	1	GE1	Disabled	Auto	Video Packet
<input type="checkbox"/>	2	GE2	Disabled	Auto	Video Packet
<input type="checkbox"/>	3	GE3	Disabled	Auto	Video Packet
<input type="checkbox"/>	4	GE4	Disabled	Auto	Video Packet

- **State** : Set checkbox to enable or disable Surveillance VLAN function.
- **VLAN** : Select Surveillance VLAN ID. Surveillance VLAN ID cannot be default VLAN.
- **Cos/802.1p** : Select a value of VPT. Qualified packets will use this VPT value as inner priority.
- **Remarking**: Set checkbox to enable or disable 1p remarking. If enabled, qualified packets will be remark by this value.
- **Aging Time** : Input value of aging time. Default is 1440 minutes. A video VLAN entry will be age out after this time if without any packet pass through.

Click the **"Apply"** button to save your changes settings.

Port Setting Table

	Entry	Port	State	Mode	QoS Policy
<input type="checkbox"/>	1	GE1	Disabled	Auto	Video Packet
<input type="checkbox"/>	2	GE2	Disabled	Auto	Video Packet
<input type="checkbox"/>	3	GE3	Disabled	Auto	Video Packet
<input type="checkbox"/>	4	GE4	Disabled	Auto	Video Packet
<input type="checkbox"/>	5	GE5	Disabled	Auto	Video Packet
<input type="checkbox"/>	6	GE6	Disabled	Auto	Video Packet
<input type="checkbox"/>	7	GE7	Disabled	Auto	Video Packet
<input type="checkbox"/>	8	GE8	Disabled	Auto	Video Packet
<input type="checkbox"/>	9	GE9	Disabled	Auto	Video Packet
<input type="checkbox"/>	10	GE10	Disabled	Auto	Video Packet
<input type="checkbox"/>	11	GE11	Disabled	Auto	Video Packet
<input type="checkbox"/>	12	GE12	Disabled	Auto	Video Packet

Field	Description
Port	Display port entry.
State	Display enable/disabled status of interface.
Mode	Display voice VLAN mode.
QoS Policy	Display Surveillance VLAN remark will effect which kind of packet.

Edit Port Setting

Port	GE2-GE4
State	<input type="checkbox"/> Enable
Mode	<input checked="" type="radio"/> Auto <input type="radio"/> Manual
QoS Policy	<input checked="" type="radio"/> Video Packet <input type="radio"/> All

Apply
Close

- **Port** : Display selected port to be edited.
- **State** : Set checkbox to enable/disabled Surveillance VLAN function of interface.
- **Mode** : Select port Surveillance VLAN mode.
 - **Auto** : Video VLAN auto detect packets that match OUI table and add received port into surveillance VLAN ID tagged member.
 - **Manual** : User need add interface to VLAN ID tagged member manually.
- **QoS Policy** : Select port QoS Policy mode.
 - **Video Packet** : Video Packet: QoS attributes are applied to packets with OUIs in the source MAC address.
 - **All** : QoS attributes are applied to packets that are classified to the Surveillance VLAN.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

7.5.2 Surveillance OUI

Administrator can configure this page to add, edit or delete OUI MAC addresses, Setting **“add”** and **“Edit”** and **“Delete”** function for this management.

VLAN → Surveillance VLAN → Surveillance OUI

- Status
- Network
- Port
- POE Setting
- VLAN**
 - VLAN
 - Create VLAN
 - VLAN Configuration
 - Membership
 - Port Setting
 - Voice VLAN
 - Property
 - Voice OUI
 - Protocol VLAN
 - Protocol Group
 - Group Binding
 - MAC VLAN
 - MAC Group
 - Group Binding
 - Surveillance VLAN
 - Property
 - Surveillance OUI**

Surveillance OUI Table

Showing entries Showing 1 to 1 of 1 entries

<input type="checkbox"/>	OUI	Description
<input type="checkbox"/>	84:40:EA	CAM1

First Previous 1

Add Edit Delete

Field	Description
OUI	Display OUI MAC address.
Description	Display description of OUI entry.

Add Surveillance OUI

OUI
 : :

Description

Apply Close

- **OUI** : Input OUI MAC address. Can't be edited in edit dialog.
- **Description** : Input description of the specified MAC address to the Surveillance VLAN OUI table.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

7.6 GVRP

The GVRP (Generic VLAN Registration Protocol) is described in the IEEE 802.1p standard; It's an IEEE 802.1Q-compliant method for facilitating automatic (dynamic) VLAN membership configuration. GVRP-enabled switches can exchange VLAN configuration information with other GVRP-enabled switches.

Policy rules or other network management methods can determine who is admitted to a VLAN. When a node requests admission to a specific VLAN, GVRP handles the registration of the node with GVRP-enabled switches and maintains that information.

GVRP reduces the chance of errors in VLAN configuration by automatically providing VLAN ID (VID) consistency across the network. In addition, you can use GVRP to dynamically enable port membership in static VLANs configured on a switch. Once GVRP creates a dynamic VLAN will can also reduce unnecessary broadcast traffic and unicast traffic.

7.6.1 Property

Administrator can enable GVRP function and set every port registration on GVRP.

VLAN → GVRP → Property

- Status
- Network
- Port
- POE Setting
- VLAN**
 - VLAN
 - Create VLAN
 - VLAN Configuration
 - Membership
 - Port Setting
 - Voice VLAN
 - Property
 - Voice OUI
 - Protocol VLAN
 - Protocol Group
 - Group Binding
 - MAC VLAN
 - MAC Group
 - Group Binding
 - Surveillance VLAN
 - Property
 - Surveillance OUI
 - GVRP
 - Property**

State ☒ Enable

Operational Timeout

Join	<input type="text" value="20"/>	cs (2 - 16375, default 20)
Leave	<input type="text" value="60"/>	cs (45 - 32760, default 60)
LeaveAll	<input type="text" value="1000"/>	cs (65 - 32765, default 1000)

Port Setting Table

	Entry	Port	State	VLAN Creation	Registration
<input type="checkbox"/>	1	GE1	Disabled	Enabled	Normal
<input type="checkbox"/>	2	GE2	Disabled	Enabled	Fixed
<input type="checkbox"/>	3	GE3	Disabled	Enabled	Fixed
<input type="checkbox"/>	4	GE4	Disabled	Enabled	Fixed
<input type="checkbox"/>	5	GE5	Disabled	Enabled	Normal

- **State** : Set the enabling status of GVRP functionality
 - **Enable**: if Checked Enable GVRP, else is Disable GVRP.
- **Operational Timeout**: The port will not learn any dynamic VLAN. Only send static VLAN information to
 - **Join**.: GVRP Join time out.
 - **Leave**: GVRP leave time out.

Click the **"Apply"** button to save your changes settings.

Field	Description
Port	Port Name.
State	Display port GVRP state.

VLAN Creation	Display port GVRP creation VLAN state.
----------------------	--

Registration	Display port GVRP registration mode.
---------------------	--------------------------------------

Edit Port Setting

Port	GE2-GE4
State	<input type="checkbox"/> Enable
VLAN Creation	<input checked="" type="checkbox"/> Enable
Registration	<input type="radio"/> Normal <input checked="" type="radio"/> Fixed <input type="radio"/> Forbidden

Apply
Close

- **Port:** Display port number.
- **State:** Displays whether GVRP is enabled or disabled on the interface.
- **VLAN Creation:** Displays whether Dynamic VLAN creation is enabled or disabled on the interface. If it is disabled, GVRP can operate but new VLANs are not created.
- **Registration:** Displays the VLAN registration mode on the interface.
 - **Normal: Normal mode..**
 - **Fixed:** The port will not learn any dynamic VLAN. Only send static VLAN information to neighbor and allow static VLAN packet pass..
 - **Forbidden:** The port will not learn any dynamic VLAN and only allow default VLAN packet pass.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

7.6.2 Member ship

When enable GVRP function and state ports in GVRP then administrator can check GVRP member information.

VLAN → GVRP → Membership

- Status
- Network
- Port
- POE Setting
- VLAN**
 - VLAN
 - Voice VLAN
 - Protocol VLAN
 - MAC VLAN
 - Surveillance VLAN
 - GVRP
 - Property
 - Membership**
 - Statistics

Membership Table

Showing entries Showing 0 to 0 of 0 entries

VLAN	Member	Dynamic Member	Type
0 results found.			

First Previous

Field	Description
VLAN	VLAN ID.
Member	VLAN port members include static and dynamic member.
Dynamic Ports	GVRP learned dynamic ports.
Type	The type of VLAN is static or dynamic.

7.6.3 Statistics

When enable and set GVRP function then administrator can check every port in GVRP include Receive / Transmit and Error information.

VLAN → GVRP → Statistics

- Status
- Network
- Port
- POE Setting
- VLAN**
 - VLAN
 - Voice VLAN
 - Protocol VLAN
 - MAC VLAN
 - Surveillance VLAN
 - GVRP
 - Property
 - Membership
 - Statistics**
- MAC Address Table
- Spanning Tree
- ERPS

Port:

Statistics:

- ☒ All
- ☐ Receive
- ☐ Transmit
- ☐ Error

Refresh Rate:

- ☐ None
- ☐ 5 sec
- ☐ 10 sec
- ☒ 30 sec

Clear

Receive	
Join empty	0
Empty	0

Click the **“Clear”** button to clear this page.

Receive	
Join empty	0
Empty	0
Leave Empty	0
Join In	0
Leave In	0
Leave All	0

Transmit	
Join empty	0
Empty	0
Leave Empty	0
Join In	0
Leave In	0
Leave All	188

Error	
Invalid Protocol ID	0
Invalid Attribute Type	0
Invalid Attribute Value	0
Invalid Attribute Length	0
Invalid Event	0


Field	Description
Join empty	The number of Receive or Transmit Join empty attribute value.
Empty	The number of Receive or Transmit Empty attribute value.
Leave Empty	The number of Receive or Transmit Leave Empty attribute value.
Join In	The number of Receive or Transmit Join In attribute value.
Leave In	The number of Receive or Transmit Leave In empty attribute value.
Leave All	The number of Receive or Transmit Leave All attribute value.
Invalid Protocol ID	The number of Receive Invalid Protocol ID

Invalid Attribute Type	The number of Receive Invalid Attribute Type
Invalid Attribute Value	The number of Receive Invalid Attribute value.
Invalid Attribute Length	The number of Receive Invalid Attribute Length.
Invalid Event	The number of Receive Invalid Event.

8. MAC Address Table

8.1 Dynamic Address

This page can display MAC address for connected device. Administrator can set aging time for connected port.



MAC Address Table → Dynamic Address

Aging Time: Sec (10 - 630, default 300)

Apply

Dynamic Address Table

Showing All entries Showing 1 to 15 of 15 entries

	VLAN	MAC Address	Port
<input type="checkbox"/>	1	00:08:9B:D5:33:E4	GE25
<input type="checkbox"/>	1	00:11:32:11:76:30	GE25
<input type="checkbox"/>	1	00:1A:97:01:AD:B1	GE25
<input type="checkbox"/>	1	00:60:B9:BF:B6:74	GE25
<input type="checkbox"/>	1	00:E0:A0:10:04:6C	GE25
<input type="checkbox"/>	1	40:B0:34:54:97:82	GE27

- **Aging Time** : The time in seconds that an entry remains in the MAC address table. Its valid range is from 10 to 630 seconds, and the default value is 300 seconds.

Click the **"Apply"** button to save your changes settings.

Field	Description
MAC Address	The MAC address to which packets will be statically forwarded.
VLAN	Specify the VLAN to show or clear MAC entries.
Port	Interface or port number.

When administrator select checkbox MACs address and click **"Add Static Address"** button then selected MAC address will move to **"Static Address"** function.

8.2 Static Address

If administrator fixed an MAC address in the port then device MAC address will bind in the port, if device connection other port will can't working only connection bind port, Setting “add” and “Edit” and “Delete” function for this management.

Field	Description
MAC Address	The MAC address to which packets will be statically forwarded.
VLAN	Specify the VLAN to show or clear MAC entries.
Port	Interface or port number.

- **MAC Address** : Enter the MAC address to which packets will be statically forwarded.
- **VLAN** : Enter the Specify the VLAN ID
- **Port** : Select an interface or port number.

Click the “**Apply**” button to save your changes or “**Close**” the button to close settings.

8.3 Filtering Address

Administrator can set need filtering MAC address in the MAC table. If MAC is added on table this MAC will be blocked, Setting “add” and “Edit” and “Delete” function for this management.

Field	Description
MAC Address	Specify unicast MAC address in the packets to be dropped.
VLAN	Specify the VLAN ID for the specific MAC address.

- **MAC Address** : Enter to specify the unicast MAC address in the packets to be dropped.
- **VLAN** : Enter a VLAN ID that specifies a specific MAC address.

Click the “**Apply**” button to save your changes or “**Close**” the button to close settings.

8.4 Port Security Address

Administrator can set this Port Security Address function, Setting “add” and “Edit” and “Delete” function for this management.

The screenshot shows the 'MAC Address Table' and 'Port Security Address Table' interface. On the left, a sidebar lists navigation options: Status, Network, Port, POE Setting, VLAN, and MAC Address Table (selected). Under 'MAC Address Table', there are sub-options: Dynamic Address, Static Address, Filtering Address, and Port Security Address. The main area displays the 'Port Security Address Table' with a search bar and a table of entries. The table has columns: checkbox, VLAN, MAC Address, Type, and Port. One entry is shown for VLAN 4094, MAC Address 8C:4D:EA:00:08:0A, Type SecureConfigured, and Port GE5. Below the table are 'Add', 'Edit', and 'Delete' buttons.

Field	Description
VLAN	Specify the VLAN to show port security.
MAC Address	Specify the MAC address for port security.
Type	Specify the Type for port security.
Port	Interface or port number.

The screenshot shows the 'Add Port Security Address' dialog box. It contains three input fields: 'MAC Address' with the value 8C:4D:EA:00:08:0A, 'VLAN' with the value 4094 (range 1 - 4094), and 'Port' with a dropdown menu showing GE5. Below the fields are 'Apply' and 'Close' buttons.

- **MAC Address** : Enter the MAC address for port security.
- **VLAN** : Enter the Specify the VLAN ID
- **Port** : Select an interface or port number.

Click the “**Apply**” button to save your changes or “**Close**” the button to close settings.

9. Spanning Tree

Spanning Tree function allows only one active path at a time between any two network devices (this prevents the loops) but establishes the redundant links as a backup if the initial link should fail. If Spanning Tree costs change, or if one network segment in the Spanning Tree becomes unreachable, the spanning tree algorithm reconfigures the spanning tree topology and reestablishes the link by activating the standby path. Without spanning tree in place, it is possible that both connections may be simultaneously live, which could result in an endless loop of traffic on the LAN.

9.1 Property


Spanning Tree → Property

- ✚ Status
- ✚ Network
- ✚ Port
- ✚ POE Setting
- ✚ VLAN
- ✚ MAC Address Table
- **Spanning Tree**
 - Property
 - Port Setting
 - MST Instance
 - MST Port Setting
 - Statistics
- ✚ ERPS
- ✚ Discovery
- ✚ DHCP
- ✚ Multicast
- ✚ IP Configuration
- ✚ Security
- ✚ ACL
- ✚ QoS
- ✚ Diagnostics
- ✚ Management

State	<input type="checkbox"/> Enable	
Operation Mode	<input type="radio"/> STP <input checked="" type="radio"/> RSTP <input type="radio"/> MSTP	
Path Cost	<input checked="" type="radio"/> Long <input type="radio"/> Short	
BPDU Handling	<input type="radio"/> Filtering <input checked="" type="radio"/> Flooding	
Priority	<input type="text" value="32768"/>	(0 - 61440, default 32768)
Hello Time	<input type="text" value="2"/>	Sec (1 - 10, default 2)
Max Age	<input type="text" value="20"/>	Sec (6 - 40, default 20)
Forward Delay	<input type="text" value="15"/>	Sec (4 - 30, default 15)
Tx Hold Count	<input type="text" value="6"/>	(1 - 10, default 6)
Region Name	<input type="text" value="8C:4D:EA:30:DD:53"/>	
Revision	<input type="text" value="0"/>	(0 - 65535, default 0)
Max Hop	<input type="text" value="20"/>	(1 - 40, default 20)

- **State:** Administrator can choose Enable or Disable this function.
- **Operation Mode:** Administrator can choose use Spanning Tree (STP) or Rapid Spanning Tree (RSTP) or Multiple Spanning Tree (MSTP).
- **Path Cost:** Administrator can choose STP judgment use Path cost for Long or Short.
 - **Long :** Specifies that the default port path costs are within the range: 1-200,000,000.
 - **Short:** Specifies that the default port path costs are within the range:1-65,535.
- **BPDU Handling:** When the Switch receives the BPDU frame, Administrator can choose the BPDU Handling mode for Filtering or Flooding. Specify the BPDU forward method when the STP is disabled.

- **Filtering** : Filter the BPDU when STP is disabled.
- **Flooding** : Flood the BPDU when STP is disabled.
- **Priority**: Administrator can set bridge priority, default is 32768. The lower value (priority) is the root bridge. Specify the bridge priority. The valid range is from 0 to 61440, and the value should be the multiple of 4096. It ensures the probability that the switch is selected as the root bridge, and the lower value has the higher priority for the switch to be selected as the root bridge of the topology.



- **Hello Time**: The hello time is the time between each bridge protocol data unit (BPDU) that is sent on a port. This time is equal to 2 seconds (sec) by default, but you can tune the time to be between 1 and 10 sec.
- **Max. Age / Forward delay** : $2 * (Forward Delay - 1) \geq Max Age \geq 2 * (Hello Time + 1)$, the time interval in seconds for a switch to wait the configuration messages, without attempting to redefine its own configuration.
- **Forward Delay** : Specify the STP forward delay time, which is the amount of time that a port remains in the Listening and Learning states before it enters the Forwarding state. Its valid range is from 4 to 10 seconds.
- **TX hold Count**: Specify the tx-hold-count used to limit the maximum numbers of packets transmission per second. The valid range is from 1 to 10.
- **Region Name**: The MSTP instance name. Its maximum length is 32 characters. The default value is the MAC address of the switch.
- **Revision**: Administrator every time change MST value, customary "Revision" to add 1 value. The MSTP revision number. Its valid range is from 0 to 65535.
- **Max. Hop**: Set max. hop of switch. Specify the number of hops in an MSTP region before the BPDU is discarded. The valid range is 1 to 40.

9.2 Port Setting

Spanning Tree → Port Setting									
<div> <div> <div>Status</div> <div>Network</div> <div>Port</div> <div>POE Setting</div> <div>VLAN</div> <div>MAC Address Table</div> <div>Spanning Tree</div> </div> <div> <div>Property</div> <div>Port Setting</div> <div>MST Instance</div> <div>MST Port Setting</div> <div>Statistics</div> </div> </div>									
Port Setting Table									
	Entry	Port	State	Path Cost	Priority	BPDU Filter	BPDU Guard	Operational Edge	
<input type="checkbox"/>	1	GE1	Enabled	20000	48	Enabled	Enabled	Enabled	
<input checked="" type="checkbox"/>	2	GE2	Enabled	20000	48	Enabled	Enabled	Enabled	
<input checked="" type="checkbox"/>	3	GE3	Enabled	20000	48	Enabled	Enabled	Enabled	
<input checked="" type="checkbox"/>	4	GE4	Enabled	20000	48	Enabled	Enabled	Enabled	
<input checked="" type="checkbox"/>	5	GE5	Enabled	20000	48	Enabled	Enabled	Enabled	
<input type="checkbox"/>	6	GE6	Disabled	20000	128	Disabled	Disabled	Disabled	

Field	Description
Port	Specify the interface ID or the list of interface IDs.
State	The operational state on the specified port.
Path Cost	STP path cost on the specified port.
Priority	STP priority on the specified port.
BPDU Filter	The states of BPDU filter on the specified port.
BPDU Guard	The states of BPDU guard on the specified port.
Operational Edge	The operational edge port status on the specified port.
Operational Point-to-Point	The operational point-to-point status on the specified port.
Port Role	The current port role on the specified port. The possible values are: "Disabled", "Master", "Root", "Designated", "Alternative", and Backup".
Port State	The current port state on the specified port. The possible values are: "Disabled", "Discarding", "Learning", and "Forwarding".
Designated Bridge	The bridge ID of the designated bridge.
Designated Port ID	The designated port ID on the switch.
Designated Cost	The path cost of the designated port on the switch

Edit Port Setting

Port	GE2-GE5,LAG1	
State	<input checked="" type="checkbox"/> Enable	
Path Cost	<input type="text" value="0"/>	(0 - 200000000) (0 = Auto)
Priority	<input type="text" value="128"/> ▼	
Edge Port	<input checked="" type="radio"/> Auto <input type="radio"/> Enable <input type="radio"/> Disable	
BPDU Filter	<input checked="" type="checkbox"/> Enable	
BPDU Guard	<input type="checkbox"/> Enable	
Point-to-Point	<input type="radio"/> Auto <input checked="" type="radio"/> Enable <input type="radio"/> Disable	
Port State	Disabled	
Designated Bridge	0-00:00:00:00:00:00	
Designated Port ID	128-29	
Designated Cost	20000	
Operational Edge	False	
Operational Point-to-Point	False	

Apply
Close

- **State:** Administrator can set Enable or Disable.
- **Path Cost:** Path Cost (1-200000000) This parameter is used determine the best path between devices. Therefore, lower values should be assigned to ports attached to faster media, and higher values assigned to ports with slower media. (Path cost takes precedence over port priority.) Note that when the Path Cost Method is set to short, the maximum path cost is 65,535. Range: 1-200000000, (set 0 = Auto, default is 0).
- **Priority:** If the path cost for all ports on a switch is the same, the port with the highest priority (i.e., lowest value) will be configured as an active link in the Spanning Tree. Where more than one port is assigned the highest priority, the port with lowest numeric identifier will be enabled. Range: 0-240, default is 128.
- **Edge Port:** Specify the edge mode..
 - **Enable** : Force to true state (as link to a host).
 - **Disable** : Force to false state (as link to a bridge).

In the edge mode, the interface would be put into the Forwarding state immediately upon link up. If the edge mode is enabled for the interface and there are BPDUs received on the

interface, the loop might be occurred in the short time before the STP state change.

- **BPDU Filter** : The BPDU Filter configuration avoids receiving/transmitting BPDU from the specified ports.
 - **Enable** : Enable BPDU filter function.
 - **Disable** : Disable BPDU filter function.
- **BPDU Filter** : The BPDU Guard configuration to drop the received BPDU directly.
 - **Enable** : Enable BPDU guard function.
 - **Disable** : Disable BPDU guard function.
- **Point-to-Point** : Specify the Point-to-Point port configuration:
 - **Auto** : The state is depended on the duplex setting of the port.
 - **Enable** : Force to true state.
 - **Disable** : Force to false state.
- **Port State** : The current port state on the specified port. The possible values are : “Disabled”, “Discarding”, “Learning”, and “Forwarding”.
- **Designated Bridge** : The bridge ID of the designated bridge.
- **Designated Port ID** : The designated port ID on the switch.
- **Designated Cost** : The path cost of the designated port on the switch.
- **Operational Edge** : Show the “false” and “true” status.
- **Operational Point-to-Point** : Show the “false” and “true” status.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

9.3 MST Instance

MST can have multiple sets of STP instances. Each instance is independently formed as a logical spanning tree. And instance has its own VLAN and port state, can independently set the priority of each port.

Spanning Tree → MST Instance

Status

Network

Port

POE Setting

VLAN

MAC Address Table

Spanning Tree

Property

Port Setting

MST Instance

MST Port Setting

Statistics

ERPS

Discovery

DHCP

Multicast

IP Configuration

Security

ACL

QoS

Diagnostics

Management

MST Instance Table

	MSTI	Priority	Bridge Identifier	Designated Root Bridge	Root Port	Root Path Cost	Remaining Hop	VLAN
<input type="radio"/>	0	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	1-4094
<input type="radio"/>	1	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	2	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	3	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	4	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	5	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	6	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	7	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	8	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	9	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	10	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	11	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	12	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	13	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	14	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	15	32768	32768-8C:4D:EA:30:DD:53	0-00:00:00:00:00:00	N/A	0	0	

Edit

Field	Description
MSTI	MST instance ID.
Priority	The bridge priority on the specified MSTI.
Bridge Identifier	The bridge identifier on the specified MSTI.
Designated Root Bridge	The designated root bridge identifier on the specified MSTI.
Root Port	The designated root port on the specified MSTI.
Root Path Cost	The designated root path cost on the specified MSTI.
Remaining Hop	The configuration of remaining hop on the specified MSTI.
VLAN	The VLAN configuration on the specified MSTI.

Edit MST Instance Setting

MSTI	3	
VLAN	Available VLAN	Selected VLAN
	<div> 2 3 4 6 7 8 9 10 </div>	<div> 1 5 </div>
Priority	<input type="text" value="32768"/> (0 - 61440, default 32768)	
Bridge Identifier	32768-8C:4D:EA:30:DD:53	
Designated Root Bridge	0-00:00:00:00:00:00	
Root Port		
Root Path Cost	0	
Remaining Hop	0	

- **VLAN** : Select the VLAN list for the specified MSTI.
- **Priority**: Specify the bridge priority on the specified MSTI. The valid range is from 0 to 61440, and the value must be the multiple of 4096. It ensures the probability that the switch is selected as the root bridge, and the lower values has the higher priority for the switch to be selected as the root bridge of the STP topology.
- **Bridge Identifier**: Displays the priority and MAC address of the Root Bridge for the selected MST instance.
- **Root Port**: Displays the root port of the selected MST instance.
- **Root Path Cost**: Displays the root path cost of the selected MST instance.
- **Remaining Hops**: Displays the number of hops remaining to the next destination.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

9.4 MST Port Setting

MST (Multiple Spanning Tree) is an extension to RST (Rapid Spanning Tree). MST further develops the usefulness of VLANs. MST configures a separate spanning tree for each VLAN group and blocks all but one possible alternate path within each spanning tree. A Multiple Spanning Tree Instance (MSTI) calculates and builds a loop-free topology to bridge packets from the VLANs that map to the instance.

Spanning Tree → MST Port Setting											
<ul style="list-style-type: none"> Status Network Port POE Setting VLAN MAC Address Table Spanning Tree <ul style="list-style-type: none"> Property Port Setting MST Instance MST Port Setting Statistics ERPS Discovery DHCP Multicast IP Configuration Security ACL 	MST Port Setting Table										
	MSTI 0 ▼										
	<input type="checkbox"/>	1	GE1	20000	48	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	48-1
	<input type="checkbox"/>	2	GE2	20000	48	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	48-2
	<input type="checkbox"/>	3	GE3	20000	48	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	48-3
	<input type="checkbox"/>	4	GE4	20000	48	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	48-4
	<input type="checkbox"/>	5	GE5	20000	48	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	48-5
	<input type="checkbox"/>	6	GE6	20000	128	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	128-6
	<input type="checkbox"/>	7	GE7	20000	128	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	128-7
	<input type="checkbox"/>	8	GE8	20000	128	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	128-8
	<input type="checkbox"/>	9	GE9	20000	128	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	128-9
	<input type="checkbox"/>	10	GE10	20000	128	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	128-10
	<input type="checkbox"/>	11	GE11	20000	128	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	128-11
	<input type="checkbox"/>	12	GE12	20000	128	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	128-12

MST Port Settings is used to configure the port MSTP settings for every MST instance. It is also used to view statistics that have been learned from the protocol.

Field	Description
MSTI	Specify the port setting on the specified MSTI
Port	Specify the interface ID or the list of interface IDs.
Path Cost	The port path cost on the specified MSTI.
Priority	The port priority on the specified MSTI.
Port Role	The current port role on the specified port. The possible values are: "Disabled", "Master", "Root", "Designated", "Alternative", and "Backup".
Port State	The current port state on the specified port. The possible values are: "Disabled", "Discarding", "Learning", and "Forwarding".
Mode	The operational STP mode on the specified port.
Type	The possible value for the port type are: <ul style="list-style-type: none"> Boundary: The port attaching an MST Bridge to a LAN that is not in the same region. Internal: The port attaching an MST Bridge to a LAN that is not in the same region.
Designated Bridge	The bridge ID of the designated bridge.

Designated Port ID	The designated port ID on the switch.
Designated Cost	The path cost of the designated port on the switch.
Remaining Hop	The remaining hops count on the specified port.

Edit MST Port Setting

MSTI	0
Port	GE6-GE7
Path Cost	<input type="text" value="0"/> <small>(0 - 200000000) (0 = Auto)</small>
Priority	128 ▼
Port Role	Disabled
Port State	Disabled
Mode	RSTP
Type	Boundary
Designated Bridge	0-00:00:00:00:00:00
Designated Port ID	128-6
Designated Cost	20000
Remaining Hop	20

- **MTSI** : Specify the port setting on the specified MSTI.
- **Port** : Specify the interface ID or the list of interface IDs..
- **Path Cost**: Specify the STP port path cost on the specified MSTI,Path cost default value is 0 (auto) depends on source device rate.
If network is a loop occurs, the MST uses cost when selecting an interface to put in the forwarding state. Administrator can assign lower cost values to interfaces that you want selected first and higher cost values that you want selected last. If all interfaces have the same cost value, the MST puts the interface with the lowest interface number in the forwarding state and blocks the other interfaces.
- **Priority**: Specify the STP port priority on the specified MSTI,Administrator can configure the MTP priority and make it more likely that the switch will be chosen as the root switch.
- **Port Role**: Displays the port role per instance, assigned by the MSTP algorithm to provide STP paths. The current port role on the specified port. The possible values are :

“Disabled”, “Master”, “Root”, “Designated”, “Alternative”, and “Backup”.

- **Port State:** The current port state on the specified port. The possible values are: “Disabled”, “Discarding”, “Learning”, and “Forwarding”.
- **Mode:** The operational STP mode on the specified port.
 - **RSTP:** RSTP is enabled on the port.
 - **STP:** Classic STP is enabled on the port.
 - **MSTP:** MSTP is enabled on the port.
- **Type :** Displays the MSTP type of the port. The possible value for the port type are :
 - **Boundary :** The port attaching an MST Bridge to a LAN that is not in the same region.
 - **Internal:** The port attaching an MST Bridge to a LAN that is not in the same region.
- **Designated Bridge:** Displays the bridge ID number that connects the link or shared LAN to the root.
- **Designated Port ID:** Displays the priority and port ID on the designated bridge that connects the link or the shared LAN to the root.
- **Designated Cost:** Displays the cost of the port participating in the STP topology. Ports with a lower cost are less likely to be blocked if STP detects loops.
- **Remaining Hops :** Displays the hops remaining to the next destination.

Click the “**Apply**” button to save your changes or “**Close**” the button to close settings.

9.5 Statistics

This page can check Receive / Transmit BPDU information of the STP Port.

Spanning Tree → Statistics																																																																																																									
<div> <div> <div>✚ Status</div> <div>✚ Network</div> <div>✚ Port</div> <div>✚ POE Setting</div> <div>✚ VLAN</div> <div>✚ MAC Address Table</div> <div>– Spanning Tree</div> <div>Property</div> <div>Port Setting</div> <div>MST Instance</div> <div>MST Port Setting</div> <div>Statistics</div> <div>✚ ERPS</div> <div>✚ Discovery</div> <div>✚ DHCP</div> <div>✚ Multicast</div> </div> <div> <div>Statistics Table</div> <div>Refresh Rate <input type="text" value="0"/> sec</div> <table> <tr> <th rowspan="2"></th><th rowspan="2">Entry</th><th rowspan="2">Port</th><th colspan="3">Receive BPDU</th><th colspan="3">Transmit BPDU</th><th rowspan="2"></th></tr> <tr> <th>Config</th><th>TCN</th><th>MSTP</th><th>Config</th><th>TCN</th><th>MSTP</th></tr> <tr> <td><input checked="" type="checkbox"/></td><td>1</td><td>GE1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td></td></tr> <tr> <td><input checked="" type="checkbox"/></td><td>2</td><td>GE2</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td></td></tr> <tr> <td><input checked="" type="checkbox"/></td><td>3</td><td>GE3</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td></td></tr> <tr> <td><input type="checkbox"/></td><td>4</td><td>GE4</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td></td></tr> <tr> <td><input type="checkbox"/></td><td>5</td><td>GE5</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td></td></tr> <tr> <td><input type="checkbox"/></td><td>6</td><td>GE6</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td></td></tr> <tr> <td><input type="checkbox"/></td><td>7</td><td>GE7</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td></td></tr> <tr> <td><input type="checkbox"/></td><td>8</td><td>GE8</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td></td></tr> </table> </div> </div>											Entry	Port	Receive BPDU			Transmit BPDU				Config	TCN	MSTP	Config	TCN	MSTP	<input checked="" type="checkbox"/>	1	GE1	0	0	0	0	0	0		<input checked="" type="checkbox"/>	2	GE2	0	0	0	0	0	0		<input checked="" type="checkbox"/>	3	GE3	0	0	0	0	0	0		<input type="checkbox"/>	4	GE4	0	0	0	0	0	0		<input type="checkbox"/>	5	GE5	0	0	0	0	0	0		<input type="checkbox"/>	6	GE6	0	0	0	0	0	0		<input type="checkbox"/>	7	GE7	0	0	0	0	0	0		<input type="checkbox"/>	8	GE8	0	0	0	0	0	0	
	Entry	Port	Receive BPDU			Transmit BPDU																																																																																																			
			Config	TCN	MSTP	Config	TCN	MSTP																																																																																																	
<input checked="" type="checkbox"/>	1	GE1	0	0	0	0	0	0																																																																																																	
<input checked="" type="checkbox"/>	2	GE2	0	0	0	0	0	0																																																																																																	
<input checked="" type="checkbox"/>	3	GE3	0	0	0	0	0	0																																																																																																	
<input type="checkbox"/>	4	GE4	0	0	0	0	0	0																																																																																																	
<input type="checkbox"/>	5	GE5	0	0	0	0	0	0																																																																																																	
<input type="checkbox"/>	6	GE6	0	0	0	0	0	0																																																																																																	
<input type="checkbox"/>	7	GE7	0	0	0	0	0	0																																																																																																	
<input type="checkbox"/>	8	GE8	0	0	0	0	0	0																																																																																																	

Field	Description
Refresh Rate	The option to refresh the statistics automatically.
Receive BPDU (Config)	The counts of the received CONFIG BPDU.
Receive BPDU (TCN)	The counts of the received TCN BPDU.
Receive BPDU (MSTP)	The counts of the received MSTP BPDU.
Transmit BPDU (Config)	The counts of the transmitted CONFIG BPDU.
Transmit BPDU (TCN)	The counts of the transmitted TCN BPDU.
Transmit BPDU (MSTP)	The counts of the transmitted MSTP BPDU.
Clear	Clear the statistics for the selected interfaces
View	View the statistics for the interface.

Port	GE4
Refresh Rate	<input checked="" type="radio"/> None <input type="radio"/> 5 sec <input type="radio"/> 10 sec <input type="radio"/> 30 sec
Receive BPDU	
Config	0
TCN	0
MSTP	0
Transmit BPDU	
Config	0
TCN	0
MSTP	0

- **Refresh Rate** : The option to refresh the statistics automatically :
None , 5 sec , 10 sec , 30sec for refresh level.
- **Clear** : Clear the statistics for the selected interfaces.

10. ERPS

ERPS (Ethernet Ring Protection Switching) : In Ethernet switching networks such as ring networks, redundant links are generally used to provide link backup and enhance network reliability. However, using redundant links can create network loops, cause broadcast storms, and cause MAC address table instability. As a result, communication quality deteriorates, and even communication services are interrupted.

STP (Spanning Tree Protocol), RSTP (Rapid Spanning Tree Protocol), and MSTP (Multiple Spanning Tree Protocol) can also meet the reliability requirements of the network, but the convergence speed is slow and does not meet the industry standard requirements.

The first industrial standard Ethernet ring redundancy protocol (ITU-T G.8032), used for link backup, improving network reliability, Ethernet networks need faster ERPS function protection switch.

Complementary STP cannot meet the requirement of fast convergence. ERPS is an ITU-T standard protocol used to prevent ring network loops. It optimizes detection and performs fast convergence. ERPS allows all ERPS-capable devices on the ring network to communicate.

As shown in Figure sample-1 => Typical networking




Figure sample ERPS link is normal

ERPS is a standard ring network protocol dedicated to the Ethernet link layer, with the ERPS ring as the basic unit. Only two ports on each Layer 2 switching device can join the same ERPS ring. In the ERPS ring, in order to prevent loops, you can start the loop breaking mechanism, block the RPL owner port, and eliminate the loop. When a link failure occurs on the ring network, the device running the ERPS protocol can quickly unblock the blocked port and perform link protection switching..

As shown in Figure sample-2 => The link is failure




Figure sample ERPS link is normal

All devices on the ring consisting of Switch A to Switch E communicate normally. To prevent loops, ERPS will first block the RPL owner port. If an RPL neighbor port is configured, this port will also be blocked, and other ports can forward service traffic normally.

As shown in Figure sample-3 => The link is failure




Figure sample ERPS link is failure

When the link between Switch D and Switch E fails, the ERPS protocol starts the protection switching mechanism, blocks the ports at both ends of the faulty link, and releases the RPL owner port. The port resumes receiving and sending user traffic, thus ensuring uninterrupted traffic.


Note	After the link returns to normal, the ERPS ring is configured in switchback mode by default. The device where the RPL owner port is located will block the traffic on the RPL link again, and the original faulty link will be used to complete the transmission of user traffic.
------	---

10.1 Propely

In a network with ring topology that runs ERPS, only one switch is assigned as an “owner” that is responsible for blocking traffic in RPL so as to avoid loops. The switch adjacent to the RPL owner is called the RPL “neighbor” node that is responsible for blocking its end of the RPL under normal condition. Other participating switches adjacent to the RPL owner or neighbor in a ring are members or RPL next-neighbor nodes to this topology and normally forward receive traffic. ERPS, like STP, provides a loop-free network by using polling packets to detect faults. When a fault occurs, ERPS heals itself by sending traffic over a protected reverse path less than 50ms and recover quickly to forward traffic. Because of this fault detection mechanism, the network broadcast storm problem could be avoided as well.

Ethernet Ring Protection Switch (ERPS) is an Ethernet ring protection protocol which is used to prevent forming the loop in LAN, thus, the Broadcast Storm problem could be avoided. The loop avoidance mechanism ensures the traffic flows on all but the RPL ring link. In order to achieve the loop-avoidance mechanism, ITU-T G.8032 defines three roles in ERPS, which are “RPL Owner Node”, “RPL Neighbor Node”, and “None Node”.

Administrator can configure this “ERPS “for Enable / Disable ERPS function.



Click the “**Apply**” button to save your changes settings.

10.2 ERPS Instance Setting

Below, Click and edit to configuration interface “Ins” Setting.

Administrator can configure this “ERPS Instance”for Ring Instance config function.

ERPS → ERPS Instance

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS**
 - Property
 - ERPS Instance**
 - Discovery
 - DHCP
 - Multicast
 - IP Configuration

Erps Instance
 (0 - 15)

Apply

ERPS Instance Setting

	Instance	Ring Status	Mel	Control Vlan	WTR Time	Guard Time	Work Mode	Ring ID	Ring Type
<input checked="" type="checkbox"/>	Ins0	Disabled	0	0	5	500	revertive	1	0
<input type="checkbox"/>	Ins1	Disabled	0	0	5	500	non_revertive	1	0
<input type="checkbox"/>	Ins2	---					---		
<input type="checkbox"/>	Ins3	---					---		

Note

Before configuring ERPS, the rapid spanning tree protocol (RSTP), or multiple spanning tree protocol is required to disabled, due to only one protocol is exclusive running within a switch.

ERPS → ERPS Instance

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS**
 - Property
 - ERPS Instance**
 - Discovery
 - DHCP
 - Multicast
 - IP Configuration

Erps Instance
 (0 - 15)

Apply

ERPS Instance Setting

	Instance	Ring Status	Mel	Control Vlan	WTR Time	Guard Time	Work Mode	Ring ID	Ring Type
<input checked="" type="checkbox"/>	Ins0	Disabled	0	0	5	500	revertive	1	0
<input type="checkbox"/>	Ins1	Disabled	0	0	5	500	non_revertive	1	0
<input type="checkbox"/>	Ins2	---					---		
<input type="checkbox"/>	Ins3	---					---		

➤ **ERPS Instance:** The ID of the ERPS interface.

Click the “**Apply**” button to save your changes settings.

ERPS Instance Setting

<input type="checkbox"/>	Instance	Ring Status	Mel	Control Vlan	WTR Time	Guard Time	Work Mode	Ring ID	Ring Type
<input checked="" type="checkbox"/>	Ins0	Disabled	0	0	5	500	revertive	1	0
<input type="checkbox"/>	Ins1	Disabled	0	0	5	500	non_revertive	1	0
<input type="checkbox"/>	Ins2	---					---		
<input type="checkbox"/>	Ins3	---					---		

Protected Instance	Port0	Port Role	Port Status	Port1	Port Role	Port Status	Node Status
---	gi1	rpl	disabled	gi1	rpl	disabled	init
---	gi1	rpl	disabled	gi1	rpl	disabled	init

Field

Description

Instance

The ID of the ERPS , The ID of the Protection group.

Ring Status

Display Enable or Disable the Ring.

Mel

Display MEL for the Ring.

Control VLAN

Display the control VLAN ID.

WTR Time

The Wait To Restore timing value to be used in revertive switching.

The period of the WTR time can be configured by the operator in 1 minute steps between 5 and 12 minutes with a default value of 5 minutes.

Guard Time

Guard timeout value to be used to prevent ring nodes from receiving outdated R-APS messages.

The period of the guard timer can be configured in 100 ms steps between 100 ms and 2000ms(2 seconds), with a default value of 500 ms

Work Mode

Display Revertive or Non_revertive mode.

- **In Revertive mode** : after the conditions causing a protection switch has cleared,the traffic channel is restored to the working transport entity, i.e., blocked on the RPL
- **In Non-Revertive mode** : the traffic channel continues to use the RPL, if

it is not failed, after a protection switch condition has cleared.

Ring ID	Display ring ID
Ring Type	Display ring type "0" for Master-ring or "1" for Sub-ring.
Protected Instance	Protection instance of ERPS ring instance.
Port0	The port0(left port) for this node.
Port Role	Current port0 rule status.
Port Status	Display the port0 port(left port) status.
Port1	The port1(right port) for this node.
Port Role	Current port1 rule status.
Port Status	Display the port1 port(right port)status.
Node Status	<p>Shows the following ERPS states:</p> <p>Init : The ERPS ring has started but has not yet determined the status of the ring.</p> <p>Idle : If all nodes in a ring are in this state, it means that all the links in the ring are up. This state will switch to protection state if a link failure occurs.</p> <p>Protection : If a node in this state, it means that a link failure has occurred. This state will switch to idle state if all the failed links recover.</p>

Ring Instance Config	
Ins	1
Ring Status	<input checked="" type="radio"/> Disable <input type="radio"/> Enable
Mel	0 (Valid range is 0-7)
Protected Instance	0 (Valid range is 0-15)
Control Vlan	0 (Valid range is 1-4094)
WTR Time	5 (Valid range is 1-12 Min Default is 5 Min)
Guard Time	500 (Valid range is 100-2000 ms. Default is 500 ms)
Work Mode	<input checked="" type="radio"/> Revertive <input type="radio"/> Non_revertive
Ring ID	1 (Valid range is 1-239)
Ring Type	0 (0-master ring, 1-sub ring)
Port0	GE1
Port0 Role	<input checked="" type="radio"/> Normal <input type="radio"/> owner <input type="radio"/> neihsbour <input type="radio"/> next-neighbour
Port1	GE1
Port1 Role	<input checked="" type="radio"/> Normal <input type="radio"/> owner <input type="radio"/> neihsbour <input type="radio"/> next-neighbour

Apply Close

- **Ring Status :** Enables/disables the ring status.
 - **Disable :** Disable the Ins for ERPS protocol.
 - **Enable :** Enable the Ins for ERPS protocol.
- **Mel :** Configures the control MEL for the ring. Valid values are from 0 to 7, Default is 0.

Note

The ring maintenance entity group level (MEL) provides a communication channel for ring automatic protecting switching (R-APS) information. On a layer 2 network running ERPS, if another fault detection protocol is enabled, the MEL field in the RAPS PDU will determine whether these packets can be forwarded. If the MEL value of the ERPS ring is less than the MEL value of the fault detection protocol, the data packet has a lower priority and is discarded. In addition, the MEL value can also be used to facilitate communication with equipment from different vendors in the ERPS ring. The same MEL value can ensure smooth communication between multi-vendor devices. The recommended setting for MEL is 7. In networks that have a main ring and a sub ring, the MEL for both rings should be set to 7.

- **Protected Instance** : The valid 0-15 protected-instance setting to configures Ethernet ring protection (ERP) instances in an ERPS ring.
- **Control VLAN** : The control VLAN of the instance should be the same as it is under Control VLAN,ERPS Control VLAN ID, ranges from 1 to 4094. It's aVLAN ID to send PDUs of ERPS.

Note	In the ERPS ring, the control VLAN is only used to forward RAPS PDUs, thereby improving the security of the ERPS protocol. All devices in the ERPS ring must be configured with the same control VLAN. Other VLANs cannot use the same ID as the control VLAN. For example, if the standard VLAN 20 already exists in the VLAN configuration, you cannot set VLAN 20 as the control VLAN of the ERPS ring.
-------------	--

- **WTR Time** : Configures the WTR time for the ring. Valid values are between 1 and 12 (min) , Default is 5min.
- **Guard Time** : Configures the guard time for the ring. Valid values are between 100 and 2000 (ms), Default is500ms.
- **Work Mode** : Select the reversion mode or not.
 - **Revertive** : Enables and select the reversion mode.

Note	After learning of the ring network fault restored, the RPL owner node will restore the blockade status of RPL and make the network flow transmission path restore to the link before the fault
-------------	--

- **Non_revertive** : Disable and select the reversion mode.

Note	After learning of the ring network fault restored, the RPL owner node will not block the RPL, the network flow transmission path is same as before.
-------------	---

- **Ring ID** : ERPS ring ID, Configures the ring. Valid value are from 1 to 239 Ring ID distinguishes different Ring topology.
- **Ring Type** : Configures the Ring Type value to "0" for Master-ring or "1" for Sub-ring, Default is 0.

Note	Master-ring (if the value is set to "1") : It is the ring which connects the two ports on the interconnection node. Sub-ring (if the value is set to "0") : It is the ring which connects to other network through two interconnection nodes,it is not a ring network, it will make up a ring network only when connect it through the interconnection node.
-------------	--

- **Port0** : ERPS ring port 0, it could be map to real switch port1 (GE1) – port 24(GE24)

Note	Do not set the same as Ring port1.
-------------	------------------------------------

- **Port0 Role** : Set the ERPS port0 role as Normal or Owner, Neighbour or Next-Neighbour.
 - **Normal**: Besides Owner and Neighbor node, the rest of nodes are defined as This Normal node..
 - **Owner** : In charge of blocking one side of RPL link. It will prevent the packet flow from its blocked port.
 - **Neighbour**: In charge of blocking one side of RPL link. It will prevent the packet flow from its blocked port.
 - **Next-Neighbour**: In charge next of blocking one side of RPL link. It will prevent the packet flow from its blocked port.

- **Port1**: ERPS ring port 1, it could be map to real switch port1 (GE1) – port 24(GE24).

Note	Do not set the same as Ring port0.
-------------	------------------------------------

- **Port1 Role** : Set the ERPS port1 role as Normal or Owner, Neighbour or Next-Neighbour..
 - **Normal**: Besides Owner and Neighbor node, the rest of nodes are defined as This Normal node..
 - **Owner** : In charge of blocking one side of RPL link. It will prevent the packet flow from its blocked port.
 - **Neighbour**: In charge of blocking one side of RPL link. It will prevent the packet flow from its blocked port.
 - **Next-Neighbour**: In charge next of blocking one side of RPL link. It will prevent the packet flow from its blocked port

Note	Do not connect all switches to form a loop (ring) network until you have enabled any ERPS protocol on any ring node. There should be at least one ring port unplugged until all nodes in the topology are ready.
-------------	--

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

11. Discovery(LLDP)

The Link Layer Discovery Protocol (LLDP) is a vendor-neutral link layer protocol in the Internet Protocol Suite used by network devices for advertising their identity, capabilities, and neighbors on an IEEE 802 local area network, principally wired Ethernet.

LLDP information is sent by devices from each of their interfaces at a fixed interval, in the form of an Ethernet frame. Each frame contains one LLDP Data Unit (LLDPDU). Each LLDPDU is a sequence of type-length-value (TLV) structures.

11.1 Property

Discovery → LLDP → Property

<ul style="list-style-type: none"> ▼ Status ▼ Network ▼ Port ▼ POE Setting ▼ VLAN ▼ MAC Address Table ▼ Spanning Tree ▼ ERPS ▼ Discovery <ul style="list-style-type: none"> LLDP <ul style="list-style-type: none"> Property Port Setting MED Network Policy MED Port Setting Packet View Local Information Neighbor Statistics 	<table border="1"> <tr> <th colspan="2">LLDP</th> </tr> <tr> <td>State</td> <td> <input checked="" type="checkbox"/> Enable <input type="radio"/> Filtering <input type="radio"/> Bridging <input checked="" type="radio"/> Flooding </td> </tr> <tr> <td>TLV Advertise Interval</td> <td> <input type="text" value="30"/> Sec (5 - 32767, default 30) </td> </tr> <tr> <td>Hold Multiplier</td> <td> <input type="text" value="4"/> (2 - 10, default 4) </td> </tr> <tr> <td>Reinitializing Delay</td> <td> <input type="text" value="2"/> Sec (1 - 10, default 2) </td> </tr> <tr> <td>Transmit Delay</td> <td> <input type="text" value="2"/> Sec (1 - 8191, default 2) </td> </tr> <tr> <th colspan="2">LLDP-MED</th> </tr> <tr> <td>Fast Start Repeat Count</td> <td> <input type="text" value="3"/> (1 - 10, default 3) </td> </tr> </table> <p>Apply</p>	LLDP		State	<input checked="" type="checkbox"/> Enable <input type="radio"/> Filtering <input type="radio"/> Bridging <input checked="" type="radio"/> Flooding	TLV Advertise Interval	<input type="text" value="30"/> Sec (5 - 32767, default 30)	Hold Multiplier	<input type="text" value="4"/> (2 - 10, default 4)	Reinitializing Delay	<input type="text" value="2"/> Sec (1 - 10, default 2)	Transmit Delay	<input type="text" value="2"/> Sec (1 - 8191, default 2)	LLDP-MED		Fast Start Repeat Count	<input type="text" value="3"/> (1 - 10, default 3)
LLDP																	
State	<input checked="" type="checkbox"/> Enable <input type="radio"/> Filtering <input type="radio"/> Bridging <input checked="" type="radio"/> Flooding																
TLV Advertise Interval	<input type="text" value="30"/> Sec (5 - 32767, default 30)																
Hold Multiplier	<input type="text" value="4"/> (2 - 10, default 4)																
Reinitializing Delay	<input type="text" value="2"/> Sec (1 - 10, default 2)																
Transmit Delay	<input type="text" value="2"/> Sec (1 - 8191, default 2)																
LLDP-MED																	
Fast Start Repeat Count	<input type="text" value="3"/> (1 - 10, default 3)																

- **State:** Administrator can choose Enable or disable this LLDP function.
- **LLDP Handling:** If cancel checkbox then administrator can choose Filtering / Bridging / Flooding for LLDP handling. Select LLDP PDU handling action to be filtered, bridging or flooded when LLDP is globally disabled
 - **Filtering:** Deletes the packet.
 - **Bridging:** (VLAN-aware flooding) Forwards the packet to all VLAN members.
 - **Flooding:** Forwards the packet to all ports
- **TLV Advertise Interval:** Select the interval at which frames are transmitted. (range 5-32760, default is 30)
- **Hold Multiplier:** Set Hold value (Range 2-10, default is 4). Administrator can control the aging time of local information on the neighbor device by configuring the value of the Hold multiplier.
*TTL=Hold multiplier * TLV Advertise Interval.*
- **Reinitializing Delay:** S Select the delay before a re-initialization (range 1–10 seconds, default = 2)..

- **Transmit Delay:** Select the delay after an LLDP frame is sent (range 1–8191 seconds, default = 3).
- **Fast Start Repeat Count:** The fast start repeat count when port link up(range 1–10,default = 3).

Click the **“Apply”** button to save your changes settings.

11.2 Port Setting

Administrator can configure each port of the LLDPDU Transmit / Receive / Normal or Disable the mode and choose from "Optional TLV" list send the TLV type of port.

Discovery → LLDP → Port Setting

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery**
 - LLDP
 - Property
 - Port Setting**
 - MED Network Policy
 - MED Port Setting
 - Packet View
 - Local Information
 - Neighbor
 - Statistics

Port Setting Table

	Entry	Port	Mode	Selected TLV
<input type="checkbox"/>	1	GE1	Receive	Port Description , 802.3 MAC-PHY , 802.3 Maximum Frame Size , 802.1 PVID , 802.1 VLAN N
<input type="checkbox"/>	2	GE2	Receive	Port Description , 802.3 MAC-PHY , 802.3 Maximum Frame Size , 802.1 PVID , 802.1 VLAN N
<input type="checkbox"/>	3	GE3	Normal	802.3 Link Aggregation , 802.3 Maximum Frame Size , Management IP Address , 802.1 PVID ,
<input type="checkbox"/>	4	GE4	Normal	802.3 Link Aggregation , 802.3 Maximum Frame Size , Management IP Address , 802.1 PVID ,
<input type="checkbox"/>	5	GE5	Normal	802.3 Link Aggregation , 802.3 Maximum Frame Size , Management IP Address , 802.1 PVID ,
<input type="checkbox"/>	6	GE6	Normal	802.3 Link Aggregation , 802.3 Maximum Frame Size , Management IP Address , 802.1 PVID ,
<input type="checkbox"/>	7	GE7	Transmit	Port Description , System Description , 802.3 MAC-PHY , 802.1 PVID , 802.1 VLAN Name
<input type="checkbox"/>	8	GE8	Transmit	Port Description , System Description , 802.3 MAC-PHY , 802.1 PVID , 802.1 VLAN Name
<input type="checkbox"/>	9	GE9	Transmit	Port Description , System Description , 802.3 MAC-PHY , 802.1 PVID , 802.1 VLAN Name
<input type="checkbox"/>	10	GE10	Normal	802.1 PVID
<input checked="" type="checkbox"/>	11	GE11	Normal	802.1 PVID

Field	Description
Port	Display the port of LLDP state.
Mode	Display the Transmit (TX Only),Receive (RX Only),Normal (TX And RX),Disable
Selected TLV	Display the TLVs for your selected.

Edit Port Setting

Port	GE7-GE9		
Mode	<input checked="" type="radio"/> Transmit <input type="radio"/> Receive <input type="radio"/> Normal <input type="radio"/> Disable		
Optional TLV	Available TLV		Selected TLV
	System Name System Capabilities 802.3 Link Aggregation 802.3 Maximum Frame Size Management IP Address	> <	802.1 PVID System Description 802.3 MAC-PHY Port Description
802.1 VLAN Name	Available VLAN		Selected VLAN
		> <	VLAN 1

Apply

Close

- **Mode** : Administrator can choose Transmit(TX) / Receive(RX) or Normal(TX+RX) and Disable, if choose disable will don't send and receive LLDPDU.
 - Transmit (TX Only): Transmit LLDP PDUs only.
 - Receive (RX Only): Receive LLDP PDUs only.
 - Normal (TX And RX): Transmit and receive LLDP PDUs both
 - Disable : Disable the transmission of LLDP PDUs
- **Optional TLV** : Administrator can be configuration information into different TLV, encapsulates LLDPDU and issued to the neighbor device.
 - System Name
 - Port Description
 - System Description
 - System Capability
 - 802.3 MAC-PHY
 - 802.3 Link Aggregation
 - 802.3 Maximum Frame Size
 - Management Address
 - 802.1 PVID
- **802.1 VLAN Name** : Select the VLAN Name ID to be carried (multiple selection is allowed).

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

11.3 MED Network Policy

Administrator can see the display for LLDP MED Network Policy Setting, Setting “add” and “Edit” and “Delete” function for this management.

Discovery → LLDP → MED Network Policy

- ✚ Status
- ✚ Network
- ✚ Port
- ✚ POE Setting
- ✚ VLAN
- ✚ MAC Address Table
- ✚ Spanning Tree
- ✚ ERPS
- **Discovery**
 - LLDP
 - Property
 - Port Setting
 - MED Network Policy**
 - MED Port Setting

MED Network Policy Table

Showing All entries Showing 1 to 2 of 2 entries

<input type="checkbox"/>	Policy ID	Application	VLAN	VLAN Tag	Priority	DSCP
<input type="checkbox"/>	1	Voice	4094	Tagged	5	63
<input type="checkbox"/>	5	Guest Voice	4094	Tagged	2	11

First Previous

Add Edit Delete

Field	Description
Policy ID	Display the policy ID.
Application	Display the network policy type.
VLAN	Display the VLAN ID.
VLAN Tag	Display the VLAN tag status.
Priority	Display the L2 priority.
DSCP	Display the DSCP value.

Add MED Network Policy

Policy ID	1	
Application	Voice	
VLAN	4094	Range (0 - 4095)
VLAN Tag	<input checked="" type="radio"/> Tagged <input type="radio"/> Untagged	
Priority	5	
DSCP	63	

Apply
Close

- **Policy ID** : Select specified network policy ID to configure..
- **Application** : Select the network policy application type.
 - Voice
 - Voice Signaling
 - Guest Voice
 - Guest Voice Signaling
 - Softphone Voice
 - Video Conferencing
 - App Streaming Video
 - VideoSignaling
- **VLAN** : Set the VLAN ID, range from 1 to 4094..
- **VLAN Tag** : Set the VLAN tag status.
 - **Tagged** : Traffic is tagged.
 - **Untagged** : Traffic is untagged.
- **Priority** : Set the L2 priority, range from 0 to 7.
- **DSCP** : Set the DSCP value, range from 0 to 63.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

11.4 MED Port Setting

Administrator can see the display for LLDP MED Port Setting.

Discovery → LLDP → MED Port Setting								
<ul style="list-style-type: none"> ▼ Status ▼ Network ▼ Port ▼ POE Setting ▼ VLAN ▼ MAC Address Table ▼ Spanning Tree ▼ ERPS – Discovery <ul style="list-style-type: none"> LLDP <ul style="list-style-type: none"> Property Port Setting MED Network Policy MED Port Setting Packet View Local Information Neighbor Statistics 	MED Port Setting Table							
	<input type="checkbox"/>	Entry	Port	State	Network Policy		Location	Inventory
					Active	Application		
	<input type="checkbox"/>	1	GE1	Enabled	Yes	Voice	No	Yes
	<input type="checkbox"/>	2	GE2	Enabled	Yes	Voice	No	Yes
	<input type="checkbox"/>	3	GE3	Enabled	Yes	Voice	No	Yes
	<input type="checkbox"/>	4	GE4	Enabled	Yes		No	No
	<input type="checkbox"/>	5	GE5	Enabled	Yes		No	No
	<input type="checkbox"/>	6	GE6	Enabled	Yes		No	No
	<input type="checkbox"/>	7	GE7	Enabled	Yes		No	No
	<input type="checkbox"/>	8	GE8	Enabled	Yes		No	No
	<input type="checkbox"/>	9	GE9	Enabled	Yes		No	No
	<input type="checkbox"/>	10	GE10	Enabled	Yes		No	No

Field	Description
Port	Display the LLDP MED specified port.
State	Display the LLDP MED status
Optional TLV	Display the LLDP MED optional TLVs.
Network Policy	Display the LLDP MED network policy Active and Application IDs.
Location	Display the location status.
Inventory	Display the inventory by yes or no.

Edit MED Port Setting

Port	GE1-GE3	
State	<input checked="" type="checkbox"/> Enable	
Optional TLV	Available TLV	Selected TLV
	<div>Location</div>	<div>Network Policy</div> <div>Inventory</div>
Network policy	Available Policy	Selected Policy
	<div>5 (Guest Voice)</div>	<div>1 (Voice)</div>

Location

Coordinate	<input type="text"/>	(16 pairs of hexadecimal characters)
Civic	<input type="text"/>	(6 - 160 pairs of hexadecimal characters)
ECS ELIN	<input type="text"/>	(10 - 25 pairs of hexadecimal characters)

Apply

Close

- **Port** : Select specified port or all ports to configure LLDP MED.
- **State** : Select LLDP MED enable status
- **Optional TLV** : Select LLDP MED optional TLVs (multiple selection is allowed).
 - Network Policy
 - Location
 - Inventory
- **Network Policy** : Select the network policy IDs to be bound to ports. The network policy should be created in MED Network Policy page at first.
- **Location**:
 - **Coordinate** : Set Coordinate
 - **Civic** : Set Civic
 - **ECS ELIN** : Set ECS ELIN

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

11.5 Packet View

Administrator can select which port to view and click on the "Detail" button to view the information of the LLDP packet on the selected port.

Discovery → LLDP → Packet View

- ✚ Status
- ✚ Network
- ✚ Port
- ✚ POE Setting
- ✚ VLAN
- ✚ MAC Address Table
- ✚ Spanning Tree
- ✚ ERPS
- **Discovery**
 - ✚ LLDP
 - Property
 - Port Setting
 - MED Network Policy
 - MED Port Setting
 - Packet View**
 - Local Information

Packet View Table

Q

	Entry	Port	In-Use (Bytes)	Available (Bytes)	Operational Status
<input type="radio"/>	1	GE1	162	1326	Not Overloading
<input type="radio"/>	2	GE2	162	1326	Not Overloading
<input type="radio"/>	3	GE3	200	1288	Not Overloading
<input type="radio"/>	4	GE4	113	1375	Not Overloading
<input checked="" type="radio"/>	5	GE5	113	1375	Not Overloading
<input type="radio"/>	6	GE6	113	1375	Not Overloading
<input type="radio"/>	7	GE7	81	1407	Not Overloading
<input type="radio"/>	8	GE8	81	1407	Not Overloading
<input type="radio"/>	9	GE9	81	1407	Not Overloading

Field	Description
Port	Port Name
In-Use (Bytes)	Total number of bytes of LLDP information in each packet.
Available (Bytes)	Total number of available bytes left for additional LLDP information in each packet.
Operational Status	Overloading or not

Packet View Detail

Port	GE5
------	-----

Mandatory TLVs

Size (Bytes)	21
Operational Status	Transmitted

MED Capabilities

Size (Bytes)	9
Operational Status	Transmitted

MED Location	
Size (Bytes)	0
Operational Status	Transmitted
MED Network Policy	
Size (Bytes)	0
Operational Status	Transmitted
MED Inventory	
Size (Bytes)	0
Operational Status	Transmitted
MED Extended Power via MDI	
Size (Bytes)	0
Operational Status	Transmitted
802.3 TLVs	
Size (Bytes)	19
Operational Status	Transmitted
Optional TLVs	
Size (Bytes)	40
Operational Status	Transmitted
802.1 TLVs	
Size (Bytes)	24
Operational Status	Transmitted
Total	
In-Use (Bytes)	113
Available (Bytes)	1375
<input type="button" value="Close"/>	

Click the **"Close"** button to close the view detail page.

Field	Description
Port	Port Name
Mandatory TLVs	Total mandatory TLV byte size. Status is sent or overloading.
MED Capabilities	Total MED Capabilities TLV byte size. Status is sent or overloading.

MED Location	Total MED Location byte size. Status is sent or overloading.
MED Network Policy	Total MED Network Policy byte size. Status is sent or overloading.
MED Inventory	Total MED Inventory byte size. Status is sent or overloading.
MED Extended Power via MDI	Total MED Extended Power via MDI byte size. Status is sent or overloading.
802.3 TLVs	Total 802.3 TLVs byte size. Status is sent or overloading.
Optional TLVs	Total Optional TLV byte size. Status is sent or overloading.
802.1 TLVs	Total 802.1 TLVs byte size. Status is sent or overloading.
Total	Total number of bytes of LLDP information in each packet.

11.6 Local Information

Displays switch summary and every port status of LLDP. Administrator can select which port to view and click on the "detail" button to view the information of the local device as well as the information of selected port LLDP property.

Discovery → LLDP → Local Information

- ✚ Status
- ✚ Network
- ✚ Port
- ✚ POE Setting
- ✚ VLAN
- ✚ MAC Address Table
- ✚ Spanning Tree
- ✚ ERPS
- **Discovery**
 - ✚ LLDP
 - Property
 - Port Setting
 - MED Network Policy
 - MED Port Setting
 - Packet View
 - Local Information**
 - Neighbor
 - Statistics
 - ✚ DHCP
 - ✚ Multicast
 - ✚ IP Configuration

Device Summary

Chassis ID Subtype	MAC address
Chassis ID	8C:4D:EA:30:DD:53
System Name	Switch
System Description	CS-3424G-24P
Supported Capabilities	Bridge, Router
Enabled Capabilities	Bridge, Router
Port ID Subtype	Local

Port Status Table

	Entry	Port	LLDP State	LLDP-MED State
<input checked="" type="radio"/>	1	GE1	Receive	Enabled
<input type="radio"/>	2	GE2	Receive	Enabled
<input type="radio"/>	3	GE3	Normal	Enabled

Device Summary

Field	Description
Chassis ID Subtype	Type of chassis ID, such as the MAC address.
Chassis ID	Identifier of chassis. Where the chassis ID subtype is a MAC address, the MAC address of the switch is displayed.
System Name	Name of switch.
System Description	Description of the switch.
Supported Capabilities	Primary functions of the device, such as Bridge, WLAN AP, or Router.
Enabled Capabilities	Primary enabled functions of the device.
Port ID Subtype	Type of the port identifier that is shown.

Port Status Table

Field	Description
Port	Type of the port number
LLDP Status	LLDP Tx and Rx abilities.
LLDP Med Status	LLDP MED enable state.

Click “**detail**” button on the page to view detail information of the selected port.

Local Information Detail

Chassis ID Subtype	MAC address
Chassis ID	8C:4D:EA:30:DD:53
System Name	Switch
System Description	CS-3424G-24P
Supported Capabilities	Bridge, Router
Enabled Capabilities	Bridge, Router
Port ID	GE1
Port ID Subtype	Local
Port Description	

Management Address Table

Address Subtype	Address	Interface Subtype	Interface Number
-----------------	---------	-------------------	------------------

0 results found.

Management Address Table

Field	Description
Address Subtype	Type of the port number
Address	Display management IP address type.
Interface Subtype	Returned address most appropriate for management use, typically a Layer 3 address.
Interface number	Specific interface associated with this management address.

MAC/PHY Details

MAC/PHY Detail	
Auto-Negotiation Supported	True
Auto-Negotiation Enabled	True
Auto-Negotiation Advertised Capabilities	1000baseTFD , 100baseTXFD , 100baseTX , 10baseTFD , 10baseT
Operational MAU Type	Other

Field	Description
Auto-Negotiation Supported	Port speed auto-negotiation support status.
Auto-Negotiation Enabled	Port speed auto-negotiation active status.
Auto-Negotiation Advertised Capabilities	Port speed auto-negotiation capabilities, for example, 1000BASE-T half-duplex mode, 100BASE-TX full-duplex mode.
Operational MAU Type	Medium Attachment Unit (MAU) type. The MAU performs physical layer functions, including digital data conversion from the Ethernet interfaces' collision detection and bit injection into the network, for example, 100BASE-TX full duplex mode.

802.3 Detail

802.3 Detail	
802.3 Maximum Frame Size	1522

Field	Description
802.3 Maximum Frame Size	The maximum supported IEEE 802.3 frame size.

802.3 Link Aggregation

802.3 Link Aggregation	
Aggregation Capability	N/A
Aggregation Status	N/A
Aggregation Port ID	N/A

Field	Description
Aggregation Capability	Indicates whether the interface can be aggregated.
Aggregation Status	Indicates whether the interface is aggregated.
Aggregation Port ID	Advertised aggregated interface ID.

MED Detail

MED Detail	
Capabilities Supported	Capabilities , Network policy
Current Capabilities	Capabilities , Network policy
Device Class	Network Connectivity
PoE Device Type	N/A
PoE Power Source	N/A
PoE Power Priority	N/A
PoE Power Value	N/A
Hardware Revision	N/A
Firmware Revision	N/A
Software Revision	N/A
Serial Number	N/A
Manufacturer Name	N/A
Model Name	N/A
Asset ID	N/A

Field	Description
Capabilities Supported	MED capabilities supported on the port.
Current Capabilities	MED capabilities enabled on the port.
Device Class	LLDP MED endpoint device class.
PoE Device Type	Port PoE type, for example, powered.
PoE Power Source	Port power source.
PoE Power Priority	Port power priority.
PoE Power Value	Port power value.
Hardware Revision	Hardware version.
Firmware Revision	Firmware version.
Software	Software version.

Revision

Serial Number	Device serial number.
Manufacturer Name	Device chipset IC manufacturer name.
Model Name	Device chipset IC model name.
Asset ID	Asset ID.

Location Information

Location Information		
	Civic	N/A
	Coordinate	N/A
	ECS ELIN	N/A

Field	Description
Coordinate	Set Coordinate.
Civic	Set Civic.
ECS ELIN	Set ECS ELIN.

Network Policy Table

Network Policy Table				
Application Type	VLAN	VLAN Type	Priority	DSCP
Voice	4094	Tagged	5	63

Close

Field	Description
Application	<p>Display the network policy application type.</p> <ul style="list-style-type: none"> ● Voice ● Voice Signaling ● Guest Voice ● Guest Voice Signaling ● Softphone Voice ● Video Conferencing

- App Streaming Video
- VideoSignaling

VLAN	Display the VLAN ID.
VLAN Type	VLAN tag status. Display the network policy application Traffic is tagged or Traffic is untagged type.
Priority	Display the L2 priority.
DSCP	Display the DSCP value.

Click the **“Close”** button to close the information page.

11.7 Neighbor

The page displays information that was received using the LLDP protocol from neighboring devices. After timeout the information is deleted. (Based on the value received from the neighbor time to Live TLV during which no LLDP PDU was received from a neighbor), Setting **“add”** and **“Edit”** and **“Delete”** function for this management.

Local Port	Chassis ID Subtype	Chassis ID	Port ID Subtype	Port ID	System Name	Time to Live
GE25	MAC address	10:60:4B:8B:78:99	MAC address	10:60:4B:8B:78:99		2452
GE25	MAC address	00:E0:A0:10:04:6C	MAC address	00:E0:A0:10:04:6C		3397
GE27	MAC address	40:B0:34:54:97:82	MAC address	40:B0:34:54:97:82		3395

Field	Description
Local Port	Number of the local port to which the neighbor is connected.
Chassis ID Subtype	Type of chassis ID (for example, MAC address).
Chassis ID	Identifier of the 802 LAN neighboring device's chassis.

Port ID Subtype	Type of the port identifier that is shown.
Port ID	Identifier of port.
System Name	Published name of the switch.
Time to Live	Time interval in seconds after which the information for this neighbor is deleted.

Click “detail” to view selected neighbor detail information.

Neighbor Information Detail

Local Port	GE25
------------	------

Basic Detail

Chassis ID Subtype	MAC address
Chassis ID	10:60:4B:8B:78:99
Port ID Subtype	MAC address
Port ID	10:60:4B:8B:78:99
Port Description	
System Name	
System Description	
Supported Capabilities	N/A
Enabled Capabilities	N/A

Management Address Table

Address Subtype	Address	Interface Subtype	Interface Number
0 results found.			

MAC/PHY Detail	
Auto-Negotiation Supported	True
Auto-Negotiation Enabled	True
Auto-Negotiation Advertised Capabilities	1000baseTFD
Operational MAU Type	Other

802.3 Power via MDI

MDI Power Support Port Class	N/A
PSE MDI Power Support	N/A
PSE MDI Power State	N/A
PSE Power Pair Control Ability	N/A
PSE Power Pair	N/A
PSE Power Class	N/A
Power Type	N/A
Power Source	N/A
Power Priority	N/A
PD Request Power Value	N/A
PSE Allocated Power Value	N/A

802.3 Detail

802.3 Maximum Frame Size	N/A
--------------------------	-----

802.3 Link Aggregation

Aggregation Capability	N/A
Aggregation Status	N/A
Aggregation Port ID	N/A

802.1 VLAN and Protocol

PVID	
VLAN Name	N/A

MED Detail

Capabilities Supported	Capabilities
Current Capabilities	Capabilities
Device Class	Endpoint Class 1
PoE Device Type	N/A
PoE Power Source	N/A
PoE Power Priority	N/A
PoE Power Value	N/A
Hardware Revision	N/A
Firmware Revision	N/A
Software Revision	N/A
Serial Number	N/A
Manufacturer Name	N/A
Model Name	N/A
Asset ID	N/A

Location Information	
Civic	N/A
Coordinate	N/A
ECS ELIN	N/A

Network Policy Table					
Application Type	VLAN	VLAN Type	Priority	DSCP	
0 results found.					

Close

Click the **“Close”** button to close the information page.

11.8 Statistics

This page displays LLDP statistical information per port. The Link Layer Discovery Protocol (LLDP) Statistics page displays summary and per-port information for LLDP frames transmitted and received on the switch.

Discovery → LLDP → Statistics

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery**
 - LLDP
 - Property
 - Port Setting
 - MED Network Policy
 - MED Port Setting
 - Packet View
 - Local Information
 - Neighbor
 - Statistics
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS

Global Statistics

Insertions	3
Deletions	0
Drops	0
AgeOuts	0

Clear Refresh

Statistics Table

	Entry	Port	Transmit Frame	Receive Frame			Receive TLV		Neighbor Timeout
			Total	Total	Discard	Error	Discard	Unrecognized	
<input type="checkbox"/>	1	GE1	0	0	0	0	0	0	0
<input type="checkbox"/>	2	GE2	0	0	0	0	0	0	0
<input type="checkbox"/>	3	GE3	0	0	0	0	0	0	0
<input type="checkbox"/>	4	GE4	0	0	0	0	0	0	0
<input type="checkbox"/>	5	GE5	0	0	0	0	0	0	0
<input type="checkbox"/>	6	GE6	0	0	0	0	0	0	0

Global Statistics

Field	Description
Insertions	The number of times the complete set of information advertised by a particular MAC Service Access Point (MSAP) has been inserted into tables associated with the remote systems.
Deletions	The number of times the complete set of information advertised by MSAP has been deleted from tables associated with the remote systems.
Drops	The number of times the complete set of information advertised by MSAP could not be entered into tables associated with the remote systems because of insufficient resources.
Age Outs	The number of times the complete set of information advertised by MSAP has been deleted from tables associated with the remote systems because the information timeliness interval has expired.

Click the **“Clear”** button to clear this page or click the **“Refresh”** button to refresh the page .

Statistics Table

Field	Description
Port	Interface or port number.
Transmit Frame Total	Number of LLDP frames transmitted on the corresponding port.
Receive Frame	<ul style="list-style-type: none"> ● Total: Number of LLDP frames received by this LLDP agent on the corresponding port, while the LLDP agent is enabled ● Discarded: Number of LLDP frames discarded for any reason by the LLDP agent on the corresponding port. ● Errors: Number of invalid LLDP frames received by the LLDP agent on the corresponding port, while the LLDP agent is enabled.
Receive TLV	<ul style="list-style-type: none"> ● Discarded: Number of TLVs of LLDP frames discarded for any reason by the LLDP agent on the corresponding port. ● Unrecognized: Number of TLVs of LLDP frames that are unrecognized while the LLDP agent is enabled ● Neighbor Timeout: Number of TLVs of LLDP frames that are unrecognized while the LLDP agent is enabled
Neighbor Timeout	Number of age out LLDP frames.

12. DHCP

The protocol operates on a client-server model. When DHCP clients connect to the network, they send broadcast queries to request the necessary information from the DHCP server. A DHCP server manages a pool of IP addresses and network configuration information. If they receive a query from a DHCP client, they will automatically be assigned an IP address and network parameters.

Dynamic Host Configuration Protocol (DHCP) is a standardized network protocol. It is used in Internet Protocol (IP) networks to dynamically distribute network configuration parameters. For example, a device can request an IP address for an interface from a DHCP server. Using DHCP also reduces the need for network administrators or users to manually configure these settings.

12.1 Property

Administrator can configure this "DHCP port Setting Table" for Enable / Disable DHCP Server function.

Entry	Port	State
1	GE1	Enabled
2	GE2	Enabled
3	GE3	Enabled
4	GE4	Disabled
5	GE5	Disabled
6	GE6	Disabled

Use this section to enable the DHCP Server function on the switch. Also can select DHCP "Static Binding First" function to ticking "enable" for your configuration.

Click the "Apply" button to save your changes settings.

Field	Description
Port	Display the DHCP of port entry.
State	Show the DHCP Enable or DHCP Display Status.

Edit Port Setting :

You can select the port form GE1 - GE28 (Ports) and LAG1~LAG8 (Groups) to be set, and click "Edit" to edit DHCP port to ticking "enable" for your configuration.

Edit Port Setting

Port	GE12
State	<input checked="" type="checkbox"/> Enable

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

12.2 IP Pool Setting

Administrator can configure this IP Pool Table Setting **"add"** and **"Edit"** and **"Delete"** function management.

DHCP → IP Pool Setting

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP**
 - Property
 - IP Pool Setting
 - VLAN IF Address Group Setting
 - Client List
 - Client Static Binding Table

IP Pool Table

Showing entries Showing 1 to

	Pool	Section			Gateway
		Section	Start Address	End Address	
<input type="checkbox"/>	adm	1	192.168.2.1	192.168.2.100	192.168.2.254

IP Pool Table

Showing entries Showing 1 to 1 of 1 entries

	Pool	Section			Gateway	Mask	DNS Primary Server	DNS Second Server	option 43		Lease time
		Section	Start Address	End Address					Address	Format	
<input type="checkbox"/>	adm	1	192.168.2.1	192.168.2.100	192.168.2.254	255.255.255.0	8.8.8.8	168.95.1.1	ascii		1: 0: 0

Field	Description
Pool	Display the Pool Name.
Section	<ul style="list-style-type: none"> • Section : Section entry. • Start Address : Displays the starting IP address of the IP address pool configured for this DHCP server instance. • End Address : Displays the last IP address of the IP address pool configured for this DHCP server instance.
Gateway	Displays the default gateway value sent to clients from this DHCP server instance.
Mask	Displays the subnet mask value sent to clients from this DHCP server instance.
DNS Primary Server	Displays the primary DNS server value sent to clients from this DHCP server instance.
DNS Second Server	Displays the secondary DNS server value sent to clients from this DHCP server instance.
Option43	<ul style="list-style-type: none"> • Address : Displays of option 43 address. • Format : Displays of option 43 format type.
Lease time	This field displays the amount of time that the IP address is valid.

IP Pool Table

Pool	adm		
Gateway	<input type="text" value="192.168.2.254"/>		
Mask	<input type="text" value="255.255.255.0"/>		
IP Address Section	Section	<input type="text" value="1"/>	
	Start Address	<input type="text" value="192.168.2.1"/>	
	End Address	<input type="text" value="192.168.2.100"/>	
DNS Primary Server	<input checked="" type="checkbox"/> Enable	<input type="text" value="8.8.8.8"/>	
DNS Second Server	<input checked="" type="checkbox"/> Enable	<input type="text" value="168.95.1.1"/>	
option 43	<input checked="" type="radio"/> ascii <input type="radio"/> hex	<input type="text"/>	
Lease time	<input type="text" value="1"/>	Day <input type="text" value="00"/>	Hour <input type="text" value="00"/> Minute

- **Pool** : Select Add New Pool and enter a name for the DHCP Pool.
- **Gateway** : Enter the IP address of the gateway, which is the host on the LAN that relays all traffic coming into and going out of the LAN.
- **Mask** : Assign the subnet mask of IP address.
- **IP Address Section** :
 - **Section** : Select the Section number.
 - **Start Address** : Enter the starting point for the DHCP server to assign IP address for the device connected.
 - **End Address** : Enter the ending point for the DHCP server to assign IP address for the device connected.
- **DNS Primary Server** : Select “enable” and fill in the for your primary DNS IP address.
- **DNS Second Server** : Select “enable” and fill in the for your second DNS IP address.
- **Option 43** : Configure option 43 character string with “ASCII” format and configure option 43 character string with “HEX” format in IP DHCP pool mode.
- **Lease time** : A controllable time period that DHCP server will reclaim IP addresses, Set the time value if set time is selected as Day / Hour / Minute.

Click the “**Apply**” button to save your changes or “**Close**” the button to close settings.

12.3 VLAN IF Address Group Setting

Administrator can configure select the drop down list of "VLAN Interface" and ""DHCP server group " in the VLAN interface address pool table".

- **Interface** : Select a VLAN interface.
- **DHCP Sever Group** : Select a DHCP Sever Group.

Click the **“Apply”** button to save your changes settings.

Administrator can configure this “DHCP Server Group Table “page setting for **“add”** and “Edit” and **“Delete”** function management.

Field	Description
Group ID	Displays the DHCP Server Group ID
Group IP Address	Displays the DHCP Server Group IP Address
Bind VLAN Interface	Displays the DHCP Server Bind VLAN Interface

- **DHCP Server Group** : Administrator can be select “DHCP Server Group in the drop-down box, and then confirm the grouping function to be set.
- **Group IP Address** : Administrator can fill in Group IP address.

Click the “**Apply**” button to save your changes or “**Close**” the button to close settings.

12.4 Client List

This page can displayed DHCP Client List show” MAC Address Table” and show “IPv4 Address” and show “VLAN” and show “Hostname” information .

Field	Description
MAC Address Table	Display the MAC address of the client device.
IPv4 Address	Display the IP address sent to the client device.
VLAN	Display the VLAN ID of the DHCP client.
Hostname	Displays the hostname of the DHCP client.

Click “**Refresh**” to refresh the “Client List” statistics .

12.5 Client Static Binding Table

Administrator can configure this “Static Binding Table” setting for “add” and “Delete” function management. And this page can displayed “Static Binding Table” show “MAC Address Table” and show “IPv4 Address” and show “VLAN” and show “User Name” information .

DHCP → Client Static Binding Table

Static Binding Table

Showing **All** entries Showing 1 to 2 of 2 entries

<input type="checkbox"/>	MAC Address Table	IPv4 Address	VLAN	User Name
<input type="checkbox"/>	8C:4D:EA:00:00:01	192.168.2.88	4094	guest
<input type="checkbox"/>	8C:4D:EA:00:00:0E	192.168.2.85	4094	staff1

Add **Delete** **First** **Previous** **1**

Property
IP Pool Setting
VLAN IF Address Group Setting
Client List
Client Static Binding Table

Field	Description
MAC Address Table	Display the MAC address of the client device.
IPv4 Address	Display the IP address sent to the client device.
VLAN	Display the VLAN ID of the DHCP client.
Users Name	Displays the Users Name of the DHCP client.

Static Binding Table Add

MAC Address	8C:4D:EA:00:08:0A
VLAN	4094 (1 - 4094)
IPv4 Address	192.168.2.81
User Name	service-PC (1 - 32)

Apply **Close**

- **MAC Address** : The MAC address of the device that wishes binding.
- **VLAN** : Administrator can be configuration the DHCP VLAN ID.
- **IPv4 Address** : The IP address that will assign to the device with Binding MAC address.
- **User Name** : Generates a username for this binding rule.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

13. Multicast

Multicast is the only type of IPv4 multicast that is supported by the Ethernet gateway.

13.1 General

13.1.1 Property

This page can be configured with unknown multicast action, administrator can set the forwarding method is based on the DMAC or the DIP, the function implements high performance data transfer from point to multipoint in network will be reduce the loading on the network.

Multicast -> General -> Property

- ✖ Status
- ✖ Network
- ✖ Port
- ✖ POE Setting
- ✖ VLAN
- ✖ MAC Address Table
- ✖ Spanning Tree
- ✖ ERPS
- ✖ Discovery
- ✖ DHCP
- **Multicast**
 - General
 - Property
 - Group Address
 - Router Port
 - Forward All
 - Throttling
 - Filtering Profile
 - Filtering Binding
 - IGMP Snooping
 - MLD Snooping
 - MVR

Unknown Multicast Action

☒ Flood
☐ Drop
☐ Forward to Router Port

Multicast Forward Method

IPv4 ☒ DMAC-VID ☐ DIP-VID

IPv6 ☒ DMAC-VID ☐ DIP-VID

Apply

- **Unknown Multicast Action** : Set the unknown multicast action
 - **Drop**: drop the unknown multicast data.
 - **Flood**: flood the unknown multicast data.
 - **Router port**: forward the unknown multicast data to router port.
- **Multicast Forward Method** : Assign the subnet mask of IP address.
- **IPv4** : Set the ipv4 multicast forward method.

- **MAC-VID** : forward method dmac+vid.
- **DIP-VID** : forward method dip+vid.
- **IPv6** : Set the ipv6 multicast forward method.
 - **MAC-VID** : forward method dmac+vid.
 - **DIP-VID** : forward method dip+vid(dip is ipv6 low 32 bit).

Click the **“Apply”** button to save your changes settings.

13.1.2 Group Address

The multicast address range is 224.0.0.0 to 239.255.255.255 and forms the Class D range which is made up of the high order bits 1110 followed by the 28 bit multicast group ID. There is no subletting with these Class D addresses. A multicast group can have a permanently-assigned address or the group may be Transient, , Setting **“add”** and **“Edit”** and **“Delete”** and **“Refresh”** function for this management.

- **IPv4 Version** : Select the IP Version.
 - **IPv4** : ipv4 multicast group.
 - **IPv6** : ipv6 multicast group.

Field	Description
VLAN	The VLAN ID of group.
Group Address	The group IP address.

Member	The member ports of group.
Type	The type of group. Static or Dynamic.
Life(Sec)	The life time of this dynamic group.

Add Group Address


VLAN	1 ▾	
IP Version	IPv4 ▾	
Group Address	<input type="text"/>	
Member	<div>Available Port</div> <div> GE1 GE2 GE3 GE4 GE5 GE6 GE7 GE8 </div>	<div>Selected Port</div> <div> <input type="text"/> </div>

- **VLAN** : The VLAN ID of group.
- **IP Version** :
 - **IPv4** : ipv4 multicast group.
 - **IPv6** : ipv6 multicast group.
- **Group Address** : The group IP address.
- **Member** : The member ports of group.
 - **Available Port**: Optional port member.
 - **Selected Port**: Selected port member.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

13.1.3 Router Port

A Multicast Router (MRouter) port is a port that connects to a Multicast router. The switch includes the MRouter port(s) when it forwards Multicast streams and IGMP/ MLD registration messages. It is required in order for all Router(s) can, in turn; forward the Multicast streams and propagate the registration messages to other subnets, Setting **“add”** and **“Edit”** and **“Delete”** function for this management.



➤ **IPv4 Version** : Select the IP Version.

- **IPv4** : ipv4 multicast router.
- **IPv6** : ipv6 multicast router.

Field	Description
VLAN	The VLAN ID router entry.
Member	Router Port member (include static and learned port member).
Static Port	Static router port member.
Forbidden Port	Forbidden router port member.
Life(Sec)	The expiry time of the router entry.

Add Router Port

VLAN	Available VLAN	Selected VLAN
	<div>1</div>	<div></div>
IP Version	IPv4	
Type	<input checked="" type="radio"/> Static <input type="radio"/> Forbidden	
Port	Available Port	Selected Port
	<div>GE1 GE2 GE3 GE4 GE5 GE6 GE7 GE8</div>	<div></div>

Apply

Close

- **VLAN** : The VLAN ID of group.
 - **Available VLAN**: Optional VLAN member.
 - **Selected VLAN**: Selected VLAN member.
- **IP Version** :
 - **IPv4** : IPv4 multicast router.
 - **IPv6** : IPv6 multicast router.
- Type** : The router port type:
 - **Static** : Static router port.
 - **Forbidden** : forbidden router port, can't learn dynamic router port member.
- **Port** : The member ports of Router entry.
 - **Available Port**: Optional router port member.
 - **Selected Port**: Selected router port member.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

13.1.4 Forward All

Configure ports or LAGs to receive Multicast streams from a specific VLAN. Administrator can statically configure a port to Forward All if the devices connecting to the port do not support IGMP or MLD, Setting “add” and “Edit” and “Delete” function for this management.

Note

The configuration affects only the ports that are members of the selected VLAN.

- **IPv4 Version** : Select the IP Version.
 - **IPv4** : IPv4 multicast forward all.
 - **IPv6** : IPv6 multicast forward all.

Field	Description
VLAN	VLAN ID of forward all entry
Static Port	Known multicast group always forward port member
Forbidden Port	Known multicast group always not forward port member

Add Forward All

VLAN	Available VLAN	Selected VLAN
	<div></div>	<div>1</div>
IP Version	IPv4	
Type	<input checked="" type="radio"/> Static <input type="radio"/> Forbidden	
Port	Available Port	Selected Port
	<div> GE2 GE3 GE4 GE5 GE6 GE7 GE8 GE9 </div>	<div>GE1</div>

- **VLAN** : The VLAN ID of forward all entry.
 - **Available VLAN**: Optional VLAN member.
 - **Selected VLAN**: Selected VLAN member.
- **IP Version** :
 - **IPv4** : IPv4 multicast forward all.
 - **IPv6** : IPv6 multicast forward all.
- **Type** : The forward all port type
 - **Static** : Static forward all port. The port is statically configured as a Multicast router port.
 - **Forbidden** : Forbidden forward all port. This port is not to be configured as a Multicast Router port, even if IGMP or MLD queries are received on this port.
- **Port** : The member ports of forward all.
 - **Available Port**: Optional router port member.
 - **Selected Port**: Selected router port member.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

13.1.5 Throttling

This page allow user to configure port can learned max group number and if port group number arrived max group number action.

Multicast → General → Throttling

Throttling Table

IP Version: IPv4 ▼

	Entry	Port	Max Group	Exceed Action
<input type="checkbox"/>	1	GE1	256	Deny
<input type="checkbox"/>	2	GE2	256	Deny
<input type="checkbox"/>	3	GE3	256	Deny
<input type="checkbox"/>	4	GE4	256	Deny
<input type="checkbox"/>	5	GE5	256	Deny
<input type="checkbox"/>	6	GE6	256	Deny
<input type="checkbox"/>	7	GE7	256	Deny
<input type="checkbox"/>	8	GE8	256	Deny
<input type="checkbox"/>	9	GE9	256	Deny

- **IPv4 Version** : Select the IP Version.
- **IPv4** : IPv4 for IGMP snooping throttling.
 - **IPv6** : IPv6 for MLD snooping throttling.

Field	Description
Port	Display the Port Name
Max Group	Display the Max number of group for port
Exceed Action	Display the port exceed max number group learning group action

Edit Throttling

Port	GE14
IP Version	IPv4
Max Group	256 (0 - 256)
Exceed Action	<input checked="" type="radio"/> Deny <input type="radio"/> Replace

Apply Close

- **Port** : Display the selected port list.
- **IP Version** : Display the selected IP version
- **Max Group** : Max number of group for port
- **Exceed Action** : Excess Max number of port learning group action.
 - **Deny**: do not learning group.
 - **Replace**: random replace one exist group.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

13.1.6 Filtering Profile

Filter profile permits or denies a range of Multicast groups to be learned when the join group matches the filter profile IP group range, Setting **“add”** and **“Edit”** and **“Delete”** function for this management.

- **IPV4 Version** : Select the IP Version.
 - **IPv4** : IPv4 for IGMP snooping profile.
 - **IPv6** : IPv6 for MLD snooping profile.

Field	Description
Profile ID	Display profile ID

Start Address	The start group address of profile
End Address	The end group address of profile
Action	Display profile action

The screenshot shows a 'Add Profile' window with the following fields:

- Profile ID:** A text input field with a range indicator '(1 - 128)'.
- IP Version:** A dropdown menu currently showing 'IPv4'.
- Start Address:** A text input field.
- End Address:** A text input field.
- Action:** Two radio buttons, 'Allow' (selected) and 'Deny'.

At the bottom of the window are two buttons: 'Apply' and 'Close'.

- **Profile ID: Profile ID.**
- **IP Version :** Display the selected IP version
 - **IPv4:** IGMP snooping profile.
 - **IPv6:** MLD snooping profile.
- **Start Address:** The start group address of profile.
- **End Address :** The end group address of profile.
- **Action:** The action of profile:
 - **Allow:** permit all packets that match the profile.
 - **Deny:** deny all packets that match the profile.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

13.1.7 Filtering Binding

When the setting is completed of Filtering Profile, administrator can select ports to set filtering binding.

Multicast → General → Filtering Binding

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast**
 - General
 - Property
 - Group Address
 - Router Port
 - Forward All
 - Throttling
 - Filtering Profile
 - Filtering Binding

Filtering Binding Table

IP Version IPv4 ▾

<input type="checkbox"/>	Entry	Port	Profile ID
<input type="checkbox"/>	1	GE1	
<input type="checkbox"/>	2	GE2	
<input type="checkbox"/>	3	GE3	
<input type="checkbox"/>	4	GE4	
<input type="checkbox"/>	5	GE5	
<input type="checkbox"/>	6	GE6	
<input type="checkbox"/>	7	GE7	
<input type="checkbox"/>	8	GE8	
<input type="checkbox"/>	9	GE9	
<input type="checkbox"/>	10	GE10	
<input type="checkbox"/>	11	GE11	

- **IPv4 Version** : Select the IP Version.
 - **IPv4** : IPv4 for IGMP snooping throttling.
 - **IPv6** : IPv6 for MLD snooping throttling.

Field	Description
Entry	Entry of number
Port	Port Name
Profile ID	Port binding Profile ID

Edit Filtering Binding

Port

GE1-GE3

IP Version

IPv4

Profile ID

☒ Enable

- **Port**: Selected Port List.
- **IP Version** : Display Selected Port filtering IP version.
- **Profile ID**: If check Enable, can select or change profile ID, Else it will delete port filter profile binding.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

13.2 IGMP Snooping

IGMP snooping is the process of listening to Internet Group Management Protocol (IGMP) network traffic. The feature allows a network switch to listen in on the IGMP conversation between hosts and routers. By listening to these conversations the switch maintains a map of which links need which IP multicast streams. Multicasts may be filtered from the links which do not need them and thus controls which ports receive specific multicast traffic. The IGMP snooping support v2 & v3, administrator can forward or drop Unknown Multicast.

13.2.1 Property

When IGMP Snooping is enabled globally or on a VLAN, all IGMP packets are forwarded to the CPU. The CPU analyzes select of ports are asking to join Multicast groups on VLAN or routers that are generating IGMP queries, or receiving PIM / OSPF / DVMRP / IGMP query protocols incoming packets.

Multicast → IGMP Snooping → Property

☒ State **Enable**
☐ Version **IGMPv2**
☒ **IGMPv3**
☒ Report Suppression **Enable**

Apply

VLAN Setting Table

VLAN	Operational Status	Router Port Auto Learn	Query Robustness	Query Interval	Query Max Response Interval	Last Member Query Count
1	Disabled	Enabled	2	125	10	

Edit

- **State:** Administrator can select Enable or Un-enable, Set the enabling status of IGMP Snooping functionality.
 - **Enable:** If Checked Enable IGMP Snooping, else is Disabled IGMP Snooping.
- **Version:** Select either IGMPv2 or IGMPv3, Set the igmp snooping version.
 - **IGMPv2:** Only support process igmp v2 packet.
 - **IGMPv3:** Support v3 basic and v2.
- **Report Suppression:** Enable or disable IGMP report suppression. If administrator select disabling this feature will forward all IGMP reports to Multicast routers, Set the enabling status

of IGMP v2 report suppression.

- **Enable:** If Checked Enable IGMP Snooping v2 report suppression, else Disable the report suppression function.

Click the **“Apply”** button to save your changes.

VLAN Setting Table									
<div> <input type="text"/> </div>									
<input type="checkbox"/>	VLAN	Operational Status	Router Port Auto Learn	Query Robustness	Query Interval	Query Max Response Interval	Last Member Query Counter	Last Member Query Interval	Immediate Leave
<input type="checkbox"/>	1	Disabled	Enabled	2	125	10	2	1	Disabled
<div>Edit</div>									

Field	Description
VLAN	The IGMP entry VLAN ID
Operation Status	The enable status of IGMP snooping VLAN functionality
Router Port Auto Learn	The enabling status of IGMP snooping router port auto learning
Query Robustness	The Query Robustness allows tuning for the expected packet loss on a subnet.
Query Interval	The interval of querier to send general query
Query Max Response Interval	In Membership Query Messages, it specifies the maximum allowed time before sending a responding report in units of 1/10 second.
Last Member Query count	The count that Querier-switch sends Group-Specific Queries when it receives a Leave Group message for a group.
Last Member Query Interval	The interval that Querier-switch sends Group-Specific Queries when it receives a Leave Group message for a group.
Immediate leave	The immediate leave status of the group will immediate leave when receive IGMP Leave message.

Edit VLAN Setting

VLAN	1
State	<input checked="" type="checkbox"/> Enable
Router Port Auto Learn	<input checked="" type="checkbox"/> Enable
Immediate leave	<input type="checkbox"/> Enable

Query Robustness	2 (1 - 7, default 2)
Query Interval	125 Sec (30 - 18000, default 125)
Query Max Response Interval	10 Sec (5 - 20, default 10)

Last Member Query Counter	2 (1 - 7, default 2)
Last Member Query Interval	1 Sec (1 - 25, default 1)

Operational Status

Status	Disabled
Query Robustness	2
Query Interval	125 (Sec)
Query Max Response Interval	10 (Sec)
Last Member Query Counter	2
Last Member Query Interval	1 (Sec)

Apply
Close

- **VLAN:** The VLAN ID of IGMP Snooping.
- **State:** Set the enabling status of IGMP Snooping VLAN functionality.
 - **Enable:** If Checked Enable IGMP Snooping VLAN, else is Disabled IGMP Snooping VLAN.
- **Router Port Auto Learn:** Set the enabling status of IGMP Snooping router port learning.
 - **Enable:** If checked Enable learning router port by query and PIM, DVRMP, else Disable the learning router port.
- **Immediate leave:** Immediate Leave the group when receive IGMP Leave message.
 - **Enable:** If checked Enable immediate leave, else disable immediate leave.
- **Query Robustness:** The Admin Query Robustness allows tuning for the expected packet loss on a subnet.
- **Query Interval:** The Admin interval of querier to send general query.
- **Query Max Response Interval:** The Admin query max response interval, In Membership Query Messages, it specifies the maximum allowed time before sending a responding report in units of 1/10 second.
- **Last Member Query Counter:** The Admin last member query count that Querier-switch sends Group-Specific Queries when it receives a Leave Group message for a group.
- **Last Member Query Interval:** The Admin last member query interval that Querier-switch sends Group-Specific Queries when it receives a Leave Group message for a group.

- **Operational Status:** Set the enabling status of IGMP Snooping router port learning.
 - **Status:** Operational IGMP snooping status, must both IGMP snooping global and IGMP snooping enable the status will be enable.
 - **Query Robustness:** Operational Query Robustness.
 - **Query Interval:** Operational Query Interval.
 - **Query Max Response Interval:** Operational Query Max Response Interval.
 - **Last Member Query Counter:** Operational Last Member Query Count.
 - **Last Member Query Interval:** Operational Last Member Query Interval.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

13.2.2 Querier

Administrator can choose created VLAN to enable or disable the IGMP Snooping query function. When select checkbox and click **"Edit"** button will be go to set IGMP Snooping version, this function can get IGMP Snooping query device regularly to VLAN local segments in all hosts and routers send IGMP Snooping general query packets, to the query segment which multicast group members.

	VLAN	State	Operational Status	Version	Querier Address
<input type="checkbox"/>	1	Disabled	Disabled		

Field	Description
VLAN	IGMP Snooping querier entry VLAN ID

State	The IGMP Snooping querier Admin State.
Operational Status	The IGMP Snooping querier operational status
Querier Version	The IGMP Snooping querier operational version.
Querier IP	The operational Querier IP address on the VLAN

- **VLAN:** The Selected Edit IGMP Snooping querier VLAN List.
- **State :** Set the enabling status of IGMP Querier Election on the chose VLANs.
 - **Enabled:** if checked Enable IGMP Querier else Disable IGMP Querier.
- **Version :** Set the query version of IGMP Querier Election on the chose VLANs.
 - **IGMPv2:** Querier version 2.
 - **IGMPv3:** Querier version 3. (IGMP Snooping version should be IGMPv3).

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

13.2.3 Statistics

Display Receive / Transmit Packet information of IGMP snooping.

- **Special Group Query:** IGMP special group query packet include querier transmit special group query packet.
- **Source-specific Group Query:** IGMP Special Source and Group General Query packet.

Click the **“Clear”** button to clear this page or click the **“Refresh”** button to refresh the page .

13.3 MLD Snooping

The function support selective Multicast forwarding (IPv6), MLD Snooping must be enabled globally and for each relevant VLAN. The switch supports MLD Snooping on both static and dynamic VLANs. Hosts use the MLD protocol to report their participation in Multicast sessions, and the switch uses MLD Snooping to build Multicast membership lists. It uses these lists to forward Multicast packets only to switch ports where there are host nodes that are members of the Multicast groups. The switch does not support MLD Querier.

13.3.1 Property

Administrator to enable MLD Snooping in addition to the manually configured Multicast groups, the result is a union of the Multicast groups and port memberships derived from the manual setup and the dynamic discovery by MLD Snooping. However, only the static definitions are preserved when the switch is rebooted.

Multicast → MLD Snooping → Property

☒ State **Enable**
☐ Version **MLDv1**
☒ **MLDv2**
☒ Report Suppression **Enable**

Apply

VLAN Setting Table

	VLAN	Operational Status	Router Port Auto Learn	Query Robustness	Query Interval	Query Max Response Interval	Last Member Query Count
<input type="checkbox"/>	1	Disabled	Enabled	2	125	10	

Edit

- **State:** Administrator can select Enable or Un-enable, Set the enabling status of IGMP Snooping functionality.

- **Enable:** If Checked Enable IGMP Snooping, else is Disabled IGMP Snooping.
- **Version:** Select either MLDv1 or MLDv2, Set the MLD snooping version.
 - **MLDv1:** Only support process MLD v1 packet.
 - **MLDv2:** Support v2 basic and v1.
- **Report Suppression:** Set the enabling status of MLD v1 report suppression.
 - **Enable:** If Checked Enable MLD Snooping v1 report suppression, else Disable the report suppression function.

Click the **"Apply"** button to save your changes.

VLAN Setting Table									
	VLAN	Operational Status	Router Port Auto Learn	Query Robustness	Query Interval	Query Max Response Interval	Last Member Query Counter	Last Member Query Interval	Immediate Leave
<input type="checkbox"/>	1	Disabled	Enabled	2	125	10	2	1	Disabled
<input type="button" value="Edit"/>									

Field	Description
VLAN	The MLD entry VLAN ID
Operation Status	The enable status of MLD snooping VLAN functionality
Router Port Auto Learn	The enabling status of MLD snooping router port auto learning
Query Robustness	The Query Robustness allows tuning for the expected packet loss on a subnet.
Query Interval	The interval of querier to send general query
Query Max Response Interval	In Membership Query Messages, it specifies the maximum allowed time before sending a responding report in units of 1/10 second.
Query Max Response Interval	The count that Querier-switch sends Group-Specific Queries when it receives a Leave Group message for a group.
Last Member Query Interval	The interval that Querier-switch sends Group-Specific Queries when it receives a Leave Group message for a group.
Immediate leave	The immediate leave status of the group will immediate leave when receive MLD Leave message.

Administrator can select VLAN in checkbox and click Edit button to set MLD Snooping.

VLAN	1
State	<input type="checkbox"/> Enable
Router Port Auto Learn	<input checked="" type="checkbox"/> Enable
Immediate leave	<input type="checkbox"/> Enable
Query Robustness	2 (1 - 7, default 2)
Query Interval	125 Sec (30 - 18000, default 125)
Query Max Response Interval	10 Sec (5 - 20, default 10)
Last Member Query Counter	2 (1 - 7, default 2)
Last Member Query Interval	1 Sec (1 - 25, default 1)
Operational Status	
Status	Disabled
Query Robustness	2
Query Interval	125 (Sec)
Query Max Response Interval	10 (Sec)
Last Member Query Counter	2
Last Member Query Interval	1 (Sec)

- **VLAN:** The VLAN ID of MLD Snooping.
- **State:** Set the enabling status of MLD Snooping VLAN functionality.
 - **Enable:** If Checked Enable MLD Snooping VLAN, else is Disabled MLD Snooping VLAN.
- **Router Port Auto Learn:** Set the enabling status of MLD Snooping router port learning.
 - **Enable:** If checked Enable learning router port by query and PIM, DVRMP, else Disable the learning router port.
- **Immediate leave:** Immediate Leave the group when receive MLD Leave message.
 - **Enable:** If checked Enable immediate leave, else disable immediate leave.
- **Query Robustness:** The Admin Query Robustness allows tuning for the expected packet loss on a subnet.
- **Query Interval:** The Admin interval of querier to send general query.
- **Query Max Response Interval:** The Admin query max response interval, In Membership Query Messages, it specifies the maximum allowed time before sending a responding report in units of 1/10 second.
- **Last Member Query Counter:** The Admin last member query count that Querier-switch sends Group-Specific Queries when it receives a Leave Group message for a group.
- **Last Member Query Interval:** The Admin last member query interval that Querier-switch sends Group-Specific Queries when it receives a Leave Group message for a group.

- **Operational Status:** Set the enabling status of MLD Snooping router port learning.
 - **Status:** Operational MLD snooping status, must both MLD snooping global and MLD snooping enable the status will be enable.
 - **Query Robustness:** Operational Query Robustness.
 - **Query Interval:** Operational Query Interval.
 - **Query Max Response Interval:** Operational Query Max Response Interval.
 - **Last Member Query Counter:** Operational Last Member Query Count.
 - **Last Member Query Interval:** Operational Last Member Query Interval.

13.3.2 Statistics

If administrator to enable MLD snooping, the page will display Receive / Transmit Packet information of MLD Snooping.

Multicast → MLD Snooping → Statistics

Receive Packet	
Total	0
Valid	0
InValid	0
Other	0
Leave	0
Report	0
General Query	0
Special Group Query	0
Source-specific Group Query	0

Transmit Packet	
Leave	0
Report	0
General Query	0
Special Group Query	0
Source-specific Group Query	0

Clear Refresh

Field	Description
Receive Packet	● Total: Total RX MLD packet, include ipv4 multicast data to CPU.
	● Valid: The valid MLD snooping process packet.
	● InValid: The invalid MLD snooping process packet.
	● Other: The ICMPV6 type is not MLD, and is not ipv6

	<p>multicast data packet and is not IPV6 router protocol.</p> <ul style="list-style-type: none"> ● Leave: MLD leave packet. ● Report: MLD join and report packet. ● General Query: MLD General Query packet. ● Special Group Query: MLD Special Group General Query packet. ● Source-specific Group Query: MLD Special Source and Group General Query packet.
Transmit Packet	<ul style="list-style-type: none"> ● Leave: MLD leave packet. ● Report: MLD join and report packet. ● General Query: MLD general query packet. ● Special Group Query: MLD special group query packet. ● Source-specific Group Query: MLD Special Source and Group General Query packet.

Click the **“Clear”** button to clear this page or click the **“Refresh”** button to refresh the page .

13.4 MVR

MVR (Multicast VLAN Registration) is designed for applications that use wide-scale deployment of multicast traffic across an Ethernet ring-based service-provider network (for example, the broadcast of multiple television channels over a service-provider network). MVR allows a subscriber on a port to subscribe and unsubscribe to a multicast stream on the network-wide multicast VLAN.

It allows the single multicast VLAN to be shared in the network while subscribers remain in separate VLANs. MVR provides the ability to continuously send multicast streams in the multicast VLAN, but to isolate the streams from the subscriber VLANs for bandwidth and security reasons.

13.4.1 Property

Multicast → MVR → Property

- ▼ Status
- ▼ Network
- ▼ Port
- ▼ POE Setting
- ▼ VLAN
- ▼ MAC Address Table
- ▼ Spanning Tree
- ▼ ERPS
- ▼ Discovery
- ▼ DHCP
- ▼ Multicast
 - General
 - IGMP Snooping
 - MLD Snooping
 - MVR
 - Property
 - Port Setting
 - Group Address

State	<input checked="" type="checkbox"/> Enable
VLAN	1
Mode	<input checked="" type="radio"/> Compatible <input type="radio"/> Dynamic
Group Start	0.0.0.0
Group Count	1 (1 - 128)
Query Time	1 Sec (1 - 10)

Operational Group	
Maximum	128
Current	0

Apply

- **State:** Administrator can select Enable or Un-enable, Set the enabling status of MVR functionality.
 - **Enable:** if checked enable the MVR state, else disable the MVR state.
- **VLAN:** Select the MVR VLAN ID.
- **Mode:** Set the MVR mode.
 - **Compatible:** compatible mode.
 - **Dynamic:** dynamic mode, will learn group member on source port.
- **Group Start:** Administrator can set range is 224.0.0.0 to 239.255.255.255, MVR group range start.
- **Group Count:** MVR group continue count, Uses the count parameter to configure a contiguous series of MVR group addresses (the range for count is 1 to 128; the default is 1).
- **Query Time:** MVR query time when receive MVR leave MVR group packet, Administrator can defines the maximum time to wait for IGMP report memberships on a receiver port before removing the port from multicast group membership. The value is in units of second. The range is 1 to 10, and the default is 1 second.
- **Operational Group:**
 - **Maximum:** The max number of MVR group database.
 - **Current:** The learned MVR group current time.

Click the **“Apply”** button to save your changes settings.

13.4.2 Port Setting

Administrator can select ports to set role and immediate of MVR.

Multicast → MVR → Port Setting

Status

Network

Port

POE Setting

VLAN

MAC Address Table

Spanning Tree

ERPS

Discovery

DHCP

Multicast

General

IGMP Snooping

MLD Snooping

MVR

Property

Port Setting

Group Address

Port Setting Table

	Entry	Port	Role	Immediate Leave
<input type="checkbox"/>	1	GE1	None	Disabled
<input type="checkbox"/>	2	GE2	None	Disabled
<input type="checkbox"/>	3	GE3	None	Disabled
<input type="checkbox"/>	4	GE4	None	Disabled
<input type="checkbox"/>	5	GE5	None	Disabled
<input type="checkbox"/>	6	GE6	None	Disabled
<input type="checkbox"/>	7	GE7	None	Disabled
<input type="checkbox"/>	8	GE8	None	Disabled
<input type="checkbox"/>	9	GE9	None	Disabled
<input type="checkbox"/>	10	GE10	None	Disabled
<input type="checkbox"/>	11	GE11	None	Disabled

Field	Description
Port	Port Name
Role	Port Role for MVR, the type is None/Receiver/Source
Immediate Leave	Status of immediate leave

Edit Port Setting

Port

GE1

Role

☒ None

☐ Receiver

☐ Source

Immediate Leave

☐ Enable

Apply

Close

- **Port:** Display the selected port list.
- **Role:** MVR port role.
 - **None:** port role is none.
 - **Receiver:** port role is receiver, Configures a port as a receiver port if it is a subscriber port

and should only receive multicast data. It does not receive data unless it becomes a member of the multicast group, either statically or by using IGMP leave and join messages. Receiver ports cannot belong to the multicast VLAN.

- **Source:** port role is source, Configures uplink ports that receive and send multicast data as source ports. Subscribers cannot be directly connected to source ports. All source ports on a switch belong to the single multicast VLAN.

Note

If administrator to set a non-MVR port with MVR characteristics is operation fails. The default configuration is as a non-MVR port.

➤ **Immediate Leave:** MVR Port immediate leave

- **Enable:** if checked is enable immediate leave, else disable immediate leave, This function only be enabled on receiver ports to which a single receiver device is connected. When Enables the Immediate Leave feature of MVR on the port. The Immediate Leave feature is disabled by default

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

13.4.3 Group Address

Setting **“add”** and **“Edit”** and **“Delete”** and **“Refresh”** function for this management.

Multicast → MVR → Group Address

- ✚ Status
- ✚ Network
- ✚ Port
- ✚ POE Setting
- ✚ VLAN
- ✚ MAC Address Table
- ✚ Spanning Tree
- ✚ ERPS
- ✚ Discovery
- ✚ DHCP
- **Multicast**
 - ✚ General
 - ✚ IGMP Snooping
 - ✚ MLD Snooping
 - ✚ MVR
 - Property
 - Port Setting
 - Group Address

Group Address Table

Showing entries Showing 0 to 0 of 0 entries

<input type="checkbox"/>	VLAN	Group Address	Member	Type	Life (Sec)
0 results found.					

First Previous 1

Add Edit Delete Refresh

Field	Description
VLAN	The VLAN ID of MVR group.
Group Address	The MVR group IP address.
Member	The member ports of MVR group.
Type	The type of MVR group. Static or Dynamic.
Life(Sec)	The life time of this dynamic MVR group.

Add Group Address

VLAN	1									
Group Address	<input type="text"/> (0.0.0.0 - 0.0.0.0)									
Member	<table border="1"> <thead> <tr> <th>Available Port</th> <th></th> <th>Selected Port</th> </tr> </thead> <tbody> <tr> <td><div></div></td> <td><div>></div></td> <td><div></div></td> </tr> <tr> <td><div></div></td> <td><div><</div></td> <td><div></div></td> </tr> </tbody> </table>	Available Port		Selected Port	<div></div>	<div>></div>	<div></div>	<div></div>	<div><</div>	<div></div>
Available Port		Selected Port								
<div></div>	<div>></div>	<div></div>								
<div></div>	<div><</div>	<div></div>								

- **VLAN:** The VLAN ID of MVR group.
- **Group Address:** MVR group IP address ,Administrator can set MVR multicast group addresses on the switch.(The address range is 224.0.0.0 to 239.255.255.255)
- **Member:** Select Ports in the MVR Group.
 - **Available Port:** Optional port member, it is only receiver port when MVR mode is compatible, it include source port when mode is dynamic.
 - **Selected Port:** Selected port member.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

14. IP Configuration

By default all ports belong to the same VLAN and the switch only provides Layer 2 Function. To segment connected networks, first create a VLAN for each unique network user group or application traffic, assign all ports belonging to the same group to these VLANs, and assign an IP interface to each VLAN. By dividing the network into Different VLANs, which can be divided into subnets that are disconnected at the layer2. Network traffic within the same subnet is still switched using Layer 2 switching. and VLANs can now (as required) be interconnected with Layer 3 switching. Each VLAN represents a layer 3 virtual interface. You only need to provide Network address for each virtual interface, and traffic between different interfaces Subnets will be routed through Layer 3 switching.

14.1 IPv4 Management and Interfaces

This chapter describes how to configure the IP interface for management access Switch over the network. The switch supports IP version 4 and version 6, And can be managed simultaneously by any of these address types. You can manually configure specific IPv4 or IPv6 addresses, or instruct the switch to obtain an IPv4 address from a BOOTP or DHCP server. An IPv6 address can only be configured manually.

IPv4 Configuration – Set the IPv4 address for management access.

An IPv4 address default IP is '**192.168.2.200**' To configure a static address, To configure a static address, you need to change the switch's default settings to values that are compatible with your network. **You may also need to establish a default gateway between the switch and management stations that exist on another network segment (if no routing protocols are enabled).**

You can direct the device to obtain an address from a BOOTP or DHCP server, or manually configure a static IP address. Valid IP addresses consist of four decimal numbers, 0 to 255, separated by periods. Anything other than this format will not be accepted.

14.1.1 IPv4 Interface & Default IP Configure

Administrator can configure this drop down list to specify the VLAN ID number of the IPv4 interface through which the IPv4 packets are forwarded and The Switch supports the VLAN interface type and Loopback interface type, Setting "**add**" and "**Edit**" and "**Delete**" function for this management.

IP Configuration → IPv4 Management and Routing → IPv4 Interface

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration**
 - IPv4 Management and Routing
 - IPv4 Interface
 - IPv4 Routes
 - ARP
 - IPv6 Management and Routing

IPv4 Interface Table

<input type="checkbox"/>	Interface	IP Address Type	IP Address	Mask	Status	Roles
<input type="checkbox"/>	VLAN 1	Static	192.168.2.200	255.255.255.0	Valid	primary

IPv4 Interface Table

<input type="checkbox"/>	Interface	IP Address Type	IP Address	Mask	Status	Roles
<input checked="" type="checkbox"/>	VLAN 1	Static	192.168.2.200	255.255.255.0	Valid	primary

Configure VLAN1 (Default VLAN) IP address for your POE Switch

And 'Save running configuration to startup configuration'

Edit IPv4 Interface

Interface	VLAN 1		
Address Type	<input type="radio"/> Dynamic <input checked="" type="radio"/> Static		
IP Address	<input type="text" value="192.168.2.200"/>		
Mask	<input checked="" type="radio"/> Network Mask	<input type="text" value="255.255.255.0"/>	
	<input type="radio"/> Prefix Length	<input type="text"/>	(8 - 30)
Roles	<input checked="" type="radio"/> primary <input type="radio"/> sub		

➤ **Address Type :**

- **Dynamic :** Select to set as "Dynamic" type.
- **Static :** Select to set as "Static" type.

Note	If set the "Dynamic" type , The IP settings will be obtained from other DHCP server assignments.
-------------	--

➤ **IP Address :** IP Address of the VLAN. Valid IP addresses consist of four numbers, 0 to 255, separated by periods. **(Default IP is : 192.168.2.200).**

➤ **Mask :**

- **Network Mask :** This mask identifies the host address bits used for routing to specific subnets. **(Default Network Mask is : 255.255.255.0)**
- **Prefix Length :** In the Prefix Length field, define the Prefix Length of the Routing IPv4 Interface.

➤ **Roles :**

- **Primary :** In the Primary field, Select the setting defined as the primary roles.
- **Sub :** In the Sub field, Select the setting defined as the secondary roles.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.


'Save running configuration to startup configuration'

The screenshot shows the Cerio web interface for IPv4 Interface configuration. At the top right, there are buttons for 'Save', 'Logout', and 'Reboot'. The 'Save' button is highlighted with a red box. Below the buttons, the breadcrumb navigation is 'IP Configuration → IPv4 Management and Routing → IPv4 Interface'. On the left, there is a sidebar menu with options: Status, Network, Port, POE Setting, VLAN, MAC Address Table, Spanning Tree, ERPS, and Discovery. The main content area is titled 'IPv4 Interface Table' and contains a table with the following data:

	Interface	IP Address Type	IP Address	Mask	Status	Roles
<input type="checkbox"/>	VLAN 1	Static	192.168.101.89	255.255.255.0	Valid	primary

Below the table, there are buttons for 'Add', 'Edit', and 'Delete'.

After successfully changing the new IP, execute "Save running configuration to startup configuration" to make the new IP setting of POE Switch take effect every time it is started.



Click the “ok” button to save ‘Save running configuration to startup configuration’.

Add New VLAN IP address setting on ‘Loopback’

Add IPv4 Interface

Interface	<input type="radio"/> VLAN 1
	<input checked="" type="radio"/> Loopback
Address Type	<input type="radio"/> Dynamic
	<input checked="" type="radio"/> Static
IP Address	192.168.182.8
Mask	<input checked="" type="radio"/> Network Mask 255.255.255.0
	<input type="radio"/> Prefix Length (8 - 30)
Roles	<input checked="" type="radio"/> primary
	<input type="radio"/> sub


Apply Close

- **Address Type** : The Interface for Loopback only provides settings as "static" type.
- **IP Address** : In the IP Address field, define the IP address of the Routing IPv4 Interface.
- **Mask** :
 - **Network Mask** : In the Network Mask field, define the Subnet Mask of the Routing IPv4 Interface.
- **Prefix Length** : In the Prefix Length field, define the Prefix Length of the Routing IPv4
- **Roles** :
 - **Primary** : In the Primary field, Select the setting defined as the primary roles.
 - **Sub** : In the Sub field, Select the setting defined as the secondary roles.

Click the “Apply” button to save your changes or “Close” the button to close settings.

14.1.2 IPv4 Routes & Default Route Configure

You can enter static routes in the routing table using the IP > Static Routes (Add) page. Static routes may be required to force the use of a specific route to a subnet. Static routes do not automatically change in response to changes in network topology , so you should only configure a small number of stable routes to ensure network




The Switch usually uses the default gateway to route outbound traffic from computers on the LAN to the Internet. In the network, the router selects an appropriate path according to the destination address of the received data, and forwards the data to the next router. The last router in the path is responsible for forwarding the packet to the destination host.

For example, the traffic from “Network node” to the Internet through the Switch’s **default Route (default Gateway) (Site-3)**. You create one static route to connect to services offered by your ISP behind router (Site-2).

You create another static route to communicate with a separate network behind a router (Site-1) connected to the Switch.

Administrator can configure this “IPv4 Routing Table” page setting for “**add**” and “**Edit**” and “**Delete**” function management.



Configure next hop route of the Gateway IP forwarded packet in

"Default Route", for LAN device to access the Internet.

And 'Save running configuration to startup configuration'

Default routes in hosts are often called default gateways. The **default gateway** is usually a filtering device such as a NAT gateway router, firewall, or proxy server.

"**Default route**" is the route selected by the router when no other existing route can be found for the destination address in the IP packet. All packets whose destination is not in the router's routing table will use the default route. The route usually leads to another router that also handles the packet: if it knows how to route the packet, it forwards the packet to the known route; otherwise, the packet is forwarded to the default route. Route to another router. With each forwarding, the route increases the distance by one hop.

Note	CS-3424G-24P is a switch with route function. "Default Route" this feature is often referred to as "Default Gateway Configure" when operating in a Layer 2 switch environments. These settings for L2 and L3 have the same purpose, which is to set the default transmission destination for unknown IP data.
-------------	---

The default route in a TCP/IP network is a setting that tells the device how to forward the packet when the destination IP of the packet is not on the same subnet as the device, in order to achieve smooth access to the Internet. Use static routing settings to determine the gateway IP address to designate as the next hop.

Configure the "default route" (Gateway IP) of the POE switch . Please refer to the following .

Default Route (Gateway IP)Configure Sample:

The default route setting Sample destination IP address and Mask IP Address are “0.0.0.0 “(Means any IP), Gateway Router IP Address is “192.168.2.254”, Metric is “1” .


Note	The destination IP and netmask 0.0.0.0 (Means any IP) represents any destination IP address that does not match other route entries. According to this preset route, all traffic to the Internet will be forwarded to the gateway router (192.168.2.254).This will allow you to successfully access the Internet. (Distance is an optional parameter, in this case we can leave it as default or set it to 1) .
-------------	--

- **IP Address / Destination IP :** In the Destination IP field, specify the IP address for the destination.
- **Mask :**
 - **Network Mask :** Specify the subnet mask for the attached network.
 - **Prefix Length :** In the IPv4 Prefix Length field, specify the IPv4 prefix length for the destination.

- **Next Hop Router IP Address** : In the Next Hop IP Address field, specify the outgoing router IP address to use when forwarding traffic to the next router (if any) in the path toward the destination.
- **Metric** : Please fill in the cost (hop count) of transmission you want to apply for routing purposes.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

'Save running configuration to startup configuration'




The screenshot shows the 'IPv4 Routes' configuration page. On the left is a navigation menu with options like Status, Network, Port, POE Setting, VLAN, MAC Address Table, Spanning Tree, ERPS, Discovery, DHCP, Multicast, and IP Configuration. Under IP Configuration, 'IPv4 Management and Routing' is selected, and 'IPv4 Routes' is the current view. The main area displays the 'IPv4 Routing Table' with the following data:

	Destination IP Prefix	Prefix Length	Route Type	Next Hop Router IP Address
<input type="checkbox"/>	0.0.0.0 (Any IP)	24	Static	192.168.2.254 (Gateway IP)
<input type="checkbox"/>	192.168.2.0	24	Directly Connected	

Below the table are 'Add', 'Edit', and 'Delete' buttons. At the top right of the configuration area, there are 'Save', 'Logout', and 'Reboot' buttons. The 'Save' button is highlighted with a red rectangle.

After successfully changing the new IP, execute "Save running configuration to startup configuration" to make the Gateway IP setting of POE Switch take effect every time it is started.



The screenshot shows a confirmation dialog box in the center of the screen. The dialog box contains the text: "Save running configuration to startup configuration. Do you want to continue?". Below the text are two buttons: 'OK' and 'Cancel'. The background shows the 'IPv4 Interface' configuration page, which is dimmed.

Click the "ok" button to save 'Save running configuration to startup configuration'.

Static Route Configure Sample:

Add IPv4 Static Route

IP Address	<input type="text" value="162.159.200.1"/>	
Mask	<input checked="" type="radio"/> Network Mask	<input type="text" value="255.255.255.0"/>
	<input type="radio"/> Prefix Length	<input type="text" value=""/> (0 - 32)
Next Hop Router IP Address	<input type="text" value="192.168.101.254"/>	
Metric	<input type="text" value="2"/>	(1 - 255, default 1)

The Static Route Sample IP Address is 162.159.200.1

Gateway Router IP Address is 192.168.101.254

- **IP Address / Destination IP :** In the Destination IP field, specify the IP address for the destination.

Note	<p>This parameter specifies the IP network address of the final destination. Routing is always based on network numbers.</p> <p>If you need to specify a route to a single host, use the subnet mask 255.255.255.255 in the Subnet Mask field to force the network number to be the same as the host ID.</p>
------	--

- **Mask :**
 - **Network Mask :** Specify the subnet mask for the attached network.
 - **Prefix Length :** In the IPv4 Prefix Length field, specify the IPv4 prefix length for the destination.
- **Next Hop Router IP Address :** In the Next Hop IP Address field, specify the outgoing router IP address to use when forwarding traffic to the next router (if any) in the path toward the destination.

Note	<p>The next router is always one of the adjacent neighbors or the IP address of the local interface for a directly attached network.</p>
------	--

- **Metric :** Please fill in the cost (hop count) of transmission you want to apply for routing purposes.

Note	This metric represents the "cost" of transmission for routing purposes. IP routing uses "hop count" as a measure of cost, with a minimum value of 1 for directly connected networks. Enter a number that approximates the cost of this link. The number does not need to be exact, but must be between 1 and 255. In fact, 1 or 2 or 3 is usually suggested here to fill in the frequently used numbers.
-------------	--

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

Diagnostics → Ping

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS
- Diagnostics**
 - Logging
 - Mirroring
 - Ping
 - Traceroute

Address Type	<input type="radio"/> Hostname <input checked="" type="radio"/> IPv4 <input type="radio"/> IPv6
Server Address	162.159.200.1
Count	10 (1 - 32)

Ping
Stop

Ping Result

Packet Status	
Status	Success.
Transmit Packet	10
Receive Packet	10
Packet Lost	0 %

For the Static Route Sample IP Address Enter to “ 162.159.200.1”, If the setting is successful, you can test and verify it through the "Diagnostics> Ping tool.

IPv4 Routing Table							
<div><div></div><div></div></div>							
<input type="checkbox"/>	Destination IP Prefix	Prefix Length	Route Type	Next Hop Router IP Address	Metric	Administrative Distance	Outgoing Interface
<input type="checkbox"/>	162.159.200.0	24	Static	192.168.101.254	2	1	VLAN 1*
<input type="checkbox"/>	192.168.101.0	24	Directly Connected				VLAN 1*
<div><div>Add</div><div>Edit</div><div>Delete</div></div>							

Field	Description
Destination IP Prefix	The IP Prefix for the destination
Prefix Length	The prefix length for the active route.
Router Type	The type of route: Static or Dynamic, depending on how the route was added.
Next Hop Router IP Address	The outgoing router IP address to use when forwarding traffic to the next router (if any) in the path toward the destination. The next router (ex. Your Gateway site IP address) is always one of the adjacent neighbors or the IP address of the local interface for a directly attached network.
Metric	The Metric value for the configured next hop. Specify the Metric (sometimes called administrative distance), which is an integer value from 1 to 255.
Administrative Distance	The route administrative distance of the configured route.
Outgoing Interface	The outgoing interface of the route active or inactive.

14.1.3 ARP

ARP (Address Resolution Protocol, Address Resolution Protocol) is a protocol that resolves an IP address into an Ethernet MAC address (or physical address). In a local area network, when a host or other network device has data to send to another host or device, it must know the other party's network layer and IP address. But just having an IP address is not enough, because IP data must be encapsulated into a frame to be sent through the physical network, so the sending station must also have the physical address of the receiving station, so the address needs to be mapped from the IP to the physical address. ARP is the protocol to achieve this function.

ARP table (ARP Cache page)

After the device resolves the destination MAC address through ARP, it will add an IP address-to-MAC address mapping entry in its own ARP table for subsequent data forwarding to the same destination. ARP table are divided into “dynamic ARP table” and “static ARP table”.

Use the **ARP Table** (ARP Cache page) to view entries in the table, a table of the remote connections most recently seen by this switch.

IP Configuration → IPv4 Management and Routing → ARP

ARP Entry Age Out Sec (15 - 21600, default 1200)

Clear ARP Table Entries

☐ All
☐ Dynamic
☐ Static
☒ Normal Age Out

ARP Table

	Interface	IP Address	MAC Address	Status
<input type="checkbox"/>	VLAN 1	192.168.101.63	00:e0:a0:10:04:6c	Dynamic
<input type="checkbox"/>	VLAN 1	192.168.101.100	8c:4d:ea:fe:05:be	Static
<input type="checkbox"/>	VLAN 1	192.168.101.167	00:60:b9:bf:b6:74	Dynamic
<input type="checkbox"/>	VLAN 1	192.168.101.254	8c:4d:ea:04:f8:50	Dynamic

- **ARP Entry Age Out :** The setting of ARP aging time can be set from 15 seconds to 21600 seconds, and the default is 1200 seconds.
- **Clear ARP Table Entries :** Administrator can configure this “ARP Table for Clean ARP Table Entries by “All” and “Dynamic” and “Static” and by “Normal Age Out” (ARP aging set time) management.

Note	<p>1. Dynamic ARP Table :</p> <p>Dynamic ARP Table are automatically generated and maintained by the ARP protocol through ARP aging-out time , and can be outdated and invalid, updated by new ARP table , or overwritten by static ARP Table. When the invalid time expires and the interface is disabled, the corresponding dynamic ARP Table will be deleted automatically.</p> <p>2. Static ARP Table :</p> <p>Static ARP Table are manually configured and maintained, and will not be invalidated or overwritten by dynamic ARP Table.</p>
-------------	--

Click the **“Apply”** button to save your changes or **“Cancel”** the button to cancel settings.

ARP Table

Administrator can configure this “ARP “page setting for **“add”** and “Edit” and **“Delete”** function management.

Field	Description
Interface	The routing interface associated with the ARP entry.
IP Address	Displays the IP address of the device (on a subnet) that is attached an existing routing interface of the switch.
MAC Address	Displays the unicast MAC address of the attached device. The address is six two-digit hexadecimal numbers separated by colons, for example, 40:bo:34:54:97:82
Status	<p>The type of ARP entry. Possible values are as follows:</p> <ul style="list-style-type: none"> • Local : An ARP entry associated with one of the switch’s routing interface’s MAC addresses. • Gateway : A dynamic ARP entry whose IP address is that of a router. • Static : An ARP entry that was manually configured. • Dynamic : An ARP entry that was learned by the router.

Add ARP

Interface	VLAN 1
Note: Only interfaces with an valid IPv4 address are available for selection	
IP Address	192.168.101.100
MAC Address	8C:4D:EA:FE:05:BE

Apply
Close

- **Interface** : Administrator can select VLAN interface.
- **IP Address** : Enter the IPv4 address of add ARP table.
- **MAC Address** : Enter the MAC address of add ARP table.

Note	Configuring a static ARP table can improve communication security. Static ARP Table restricts the use of specified MAC addresses when communicating with devices with specified IP addresses. At this time, the harmful network transmission cannot modify the mapping relationship between the IP address and the MAC address of the entry, so as to protect the communication between the device and the specified device. Normal communication.
-------------	--

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

14.2 IPv6 Management and Interfaces

This chapter describes how to configure the IP interface for management access

Switch over the network. The switch supports IP version 4 and version 6,

And can be managed simultaneously by any of these address types. You can manually configure specific IPv4 or IPv6 addresses, or instruct the switch to obtain an IPv4 address from a BOOTP or DHCP server. An IPv6 address can only be configured manually.

IPv6 Configuration – Set the IPv6 address for management access.

14.2.1 IPv6 Interface

Administrator can configure this “IPv6 Interface Table” page setting for **“add”** and **“Edit”** and **“Delete”** function management.

IP Configuration → IPv6 Management and Routing → IPv6 Interface

- ✖ Status
- ✖ Network
- ✖ Port
- ✖ POE Setting
- ✖ VLAN
- ✖ MAC Address Table
- ✖ Spanning Tree
- ✖ ERPS
- ✖ Discovery
- ✖ DHCP
- ✖ Multicast
- IP Configuration**
 - ✖ IPv4 Management and Routing
 - ✖ IPv6 Management and Routing
 - IPv6 Interface**
 - IPv6 Addresses

IPv6 Unicast Routing ☒ Enable

Apply Cancel

IPv6 Interface Table

	Interface	Stateless	DHCPv6 Client Information Refresh Time	Minimum Information Refresh Time	Auto Configuration	DAD Attempts
<input type="checkbox"/>	VLAN 1	Disabled	86400	600	Enabled	1

Add Edit Delete

IPv6 Unicast Routing : Administrator can configure “Enable” this IPv6 Unicast Routing function.

Note	Next to IPv6 Unicast Routing, specify whether IPv6 unicast routing is globally enabled by selecting the Enable radio button or the Disable radio button.
-------------	--

Click the **“Apply”** button to save your changes or **“Cancel”** the button to cancel settings.

Select the type of the IPv6 interface through which the IPv6 packets are forwarded.
The Switch supports the VLAN interface type and Loopback interface type .

Configuration” Interface” setting on “VLAN” :

Add IPv6 Interface

Interface	<input checked="" type="radio"/> VLAN 1 <input type="radio"/> Loopback
Auto Configuration	<input checked="" type="checkbox"/> Enable
DAD Attempts	<input type="text" value="1"/> (0 - 600, default 1)
DHCPv6 Client	
Stateless	<input type="checkbox"/> Enable
Information Refresh Time	<input type="text" value="86400"/> (86400 - 4294967294, default 86400)
Minimum Information Refresh Time	<input type="text" value="600"/> (600 - 4294967294, default 600)

Apply Close

- **Auto Configuration** : The IPv6 address autoconfiguration automatically creates new IPv6 interfaces for a given line description, and assigns IPv6 addresses for the interfaces.
- **DAD Attempts** : Configures the number of neighbor solicitations to be sent when performing duplicate address detection (DAD) for a unicast address configured on an interface. The no form of this command sets the number of attempts to the default value.

DHCPv6 Client :

- **Stateless** : IPv6 stateLess AddressAutoConfiguration(SLAAC) function
- **Information Refresh Time** : 86400 by default
- **Minimum Information Refresh Time** : 600 by default

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

Configuration” Interface” setting on “Loopback” :

Add IPv6 Interface


Interface	<input checked="" type="radio"/> VLAN 1
	<input type="radio"/> Loopback
Auto Configuration	<input checked="" type="checkbox"/> Enable
DAD Attempts	<input style="width: 150px;" type="text" value="1"/> (0 - 600, default 1)
DHCPv6 Client	
Stateless	<input type="checkbox"/> Enable
Information Refresh Time	<input style="width: 150px;" type="text" value="86400"/> (86400 - 4294967294, default 86400)
Minimum Information Refresh Time	<input style="width: 150px;" type="text" value="600"/> (600 - 4294967294, default 600)

Loopback : The loopback address may be used by a node to send an IPv6 packet to itself.
It must not be assigned to a physical or virtual interface.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

14.2.2 IPv6 Addresses

Administrator can configure this “IPv6 Address Table” page setting for “add” and “Delete” function management.



IPv6 Address Table

- **Interface :** From the Interface menu, Administrator can select the VLAN for the IPv6 Interface Selection page displays. The page also shows the IPv6 Interface Configuration table.

Field	Description
IPv6 Address Type	The IP Prefix for the destination
IPv6 Address	The prefix length for the active route.
IPv6 Prefix Length	The type of route: Static or Dynamic, depending on how the route was added.
DAD status	Shows the state of the IPv6 address. The state can be one of the following <ul style="list-style-type: none">• Tent : Routing is disabled or the address does not work because of a “duplicate address detection” (DAD) condition.• Active : The IPv6 address is valid and active.• Preferred : The IPv6 address was verified to be unique, valid, and active.

Select the type of the IPv6 Address through which the IPv6 format are use.

The Switch supports the Global type and Link Local type .

Configuration" IPv6 Address Type" setting on "Global " :

Add IPv6 Interface

Interface	VLAN 1
IPv6 Address Type	<input checked="" type="radio"/> Global <input type="radio"/> Link Local
IPv6 Address	fe80::8e4d:eaff:fe30:dd55
Prefix Length	32 (3 - 128)
EUI-64	<input checked="" type="checkbox"/> Enable

Apply
Close

➤ **IPv6 Address Type :**

- **Global :** Configures an IPv6 global unicast address with a full IPv6 address including the network prefix and host address bits, followed by a forward slash, and a decimal value indicating how many contiguous bits of the address comprise the prefix.
- **Link Local :** Configures an IPv6 link-local address. The address prefix must be in the range of FE80 to FEBF. and you can configure only one link-local address per interface.(The specified address replaces a link-local address that was automatically generated for the interface).

➤ **IPv6 Address :** Full in your IPv6 address . Example of IPv6 input network range: 2001: 8E4D: EAFF: FE01: 0000: 0000: 0000: 0002 ~ FFFF: FFFF: FFFF: FFFE. (For IPv6 IP acquisition, May please contact your ISP provider).

➤ **Prefix Length :** The Prefix Length of the IPv6 address of the Switch .

➤ **EUI-64 :** Use this section to tick the Enable for EUI-64 format IPv6 configuration, Configures an IPv6 address for an interface using an EUI-64 interface ID in the low order 64 bits.

Note	The switch must be configured with a link-local address. Therefore, any configuration process that enables IPv6 functionality, including address auto configuration, explicitly enabling IPv6 or manually assigning a global unicast address will also automatically generate a link-local unicast address. The prefix length for a link local address is fixed at 64 bits, and the host portion of the default address is based on the modified EUI-64 (Extended Universal Identifier) form of the interface identifier.
-------------	---

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

Configuration” IPv6 Address Type” setting on “Link Local” :

Add IPv6 Interface

Interface	VLAN 1
IPv6 Address Type	<input type="radio"/> Global <input checked="" type="radio"/> Link Local
IPv6 Address	FE80::8E4D:EAF:FE05:3406
	(3 - 128)
	<input type="checkbox"/> Enable

Apply
Close

- **IPv6 Address :** This section uses the Link Local address of the local identifier interface required by the IPv6 mode address operation specification, for example, it is as “FE80::8E4D:EAF:FE05:3406”.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

14.2.3 IPv6 Routers

You can enter static routes in the routing table using the IP > Static Routes (Add) page. Static routes may be required to force the use of a specific route to a subnet. Static routes do not automatically change in response to changes in network topology , so you should only configure a small number of stable routes to ensure network

This page system can displayed IPv6 Routing Table for “Destination IP Prefix” / Prefix Length / Route Type / Next Hop Router IP Address / Metric / Administrative Distance / Outgoing Interface information.

Administrator can configure this “IPv6 Routing Table” page setting for **“add”** and **“Edit”** and **“Delete”** function management.

IP Configuration → IPv6 Management and Routing → IPv6 Routes

Status

Network

Port

POE Setting

VLAN

MAC Address Table

Spanning Tree

ERPS

Discovery

DHCP

Multicast

IP Configuration

IPv4 Management and Routing

IPv6 Management and Routing

IPv6 Interface

IPv6 Addresses

IPv6 Routes

IPv6 Neighbors

IPv6 Routing Table

Destination IP Prefix

Prefix Length

Route Type

Next Hop Router IP Address

Metric

0 results found.

Add

Edit

Delete

IPv6 Routing Table

Destination IP Prefix

Prefix Length

Route Type

Next Hop Router IP Address

Metric

Administrative Distance

Outgoing Interface

0 results found.

Add

Edit

Delete

Field	Description
Destination IP Prefix	The IP Prefix for the destination
Prefix Length	The prefix length for the active route.
Router Type	<div>The type of protocol for the active route:</div> <div><div>• Static. The route was manually defined.</div><div>• ND (Neighbor Discovery). The route was discovered through the ND protocol.</div><div>• Connected. The route was derived from a manually configured IPv6 address.</div></div>
Next Hop Router IP Address	The next hop IPv6 address for the active route.
Metric	The Metric value for the configured next hop.

Specify the Metric (sometimes called administrative distance), which is an integer value from 1 to 255.

Administrative Distance The route administrative distance of the configured route.

Outgoing Interface The outgoing interface of the route active or inactive.

Add IPv6 Static Route

IPv6 Prefix	<input type="text"/>
IPv6 Prefix Length	<input type="text"/> (0 - 128)
Next Hop Router IP Address	<input type="text"/>
Metric	<input type="text"/> 1 (1 - 255, default 1)

- **IPv6 Prefix** : In the IPv6 Prefix field, specify the IPv6 network prefix for the destination..
- **IPv6 Prefix Length** : In the IPv6 Prefix Length field, specify the IPv6 prefix length for the destination..
- **Next Hop Router IP Address** : In the Next Hop IPv6 Address field, specify the outgoing router IPv6 address to use when forwarding traffic to the next router (if any) in the path toward the destination.

Note	The next router is always one of the adjacent neighbors or the IPv6 address of the local interface for a directly attached network.
-------------	---

- **Metric** : Please fill in the cost (hop count) of transmission you want to apply for routing purposes.

Note	This metric represents the "cost" of transmission for routing purposes. IP routing uses "hop count" as a measure of cost, with a minimum value of 1 for directly connected networks. Enter a number that approximates the cost of this link. The number does not need to be exact, but must be between 1 and 255. In fact, 1 or 2 or 3 is usually suggested here to fill in the frequently used numbers.
-------------	--

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

14.2.4 IPv6 Neighbors

Administrator can configure this “IPv6 Neighbor Table” page setting for “add” and “Edit” and “Delete” function management.

IP Configuration → IPv6 Management and Routing → IPv6 Neighbors

- ▼ Status
- ▼ Network
- ▼ Port
- ▼ POE Setting
- ▼ VLAN
- ▼ MAC Address Table
- ▼ Spanning Tree
- ▼ ERPS
- ▼ Discovery
- ▼ DHCP
- ▼ Multicast
- IP Configuration**
 - IPv4 Management and Routing
 - IPv6 Management and Routing
 - IPv6 Interface
 - IPv6 Addresses
 - IPv6 Routes
 - IPv6 Neighbors

Clear Neighbor Table

☐ All
☐ Dynamic
☐ Static
☒ N/A

Apply

Cancel

IPv6 Neighbor Table

	Interface	IPv6 Address	MAC Address	Status	Router
0 results found.					

Add

Edit

Delete

Clear Neighbor Table

☐ All
☐ Dynamic
☐ Static
☒ N/A

Apply

Cancel

IPv6 Neighbor Table

8c

	Interface	IPv6 Address	MAC Address	Status	Router
<input type="checkbox"/>	VLAN 1	fe80::8e4d:aaaa:fe05:3408	8c:4d:ea:fe:05:be	Static	N/A
<input type="checkbox"/>	VLAN 1	fe80::8e4d:eaff:ee09:3589	8c:4d:ea:fe:cc:ee	Static	N/A
<input type="checkbox"/>	VLAN 1	fe80::8e4d:eaff:fe05:3406	8c:4d:ea:fe:05:06	Static	N/A

Add

Edit

Delete

Clear Neighbor Table

The administrator can select the filter Status type including by “All” or “Dynamic” or “Static” or “N/A” “to quickly select batches to clear the “IPv6 Neighbor Table”.

Use the "Search" menu to consult the list.

Search by "Keyword" using the Search menu and field. For example, '8c'. Then click the Search icon button. If the address exists, show the entry.

Field	Description
	The interface whose settings are displayed in the current table row.
Interface	This field displays the ID number of the IPv6 interface on which the IPv6 address is created or through which the neighboring device can be reached.
IPv6 Address	The IPv6 address of the neighbor or interface.
MAC Address	This field displays the MAC address of the IPv6 interface on which the IPv6 address is configure or the MAC address of the neighboring device.
Status	The state of the neighbor cache entry. The states for "dynamic entries" or "Static entries" in the IPv6 neighbor discovery cach.
Router	Neighbor for the active route.

Add Neighbor

Interface

VLAN 1

IP Address

MAC Address

Apply

Close

- **Interface** : Select the type of IPv6 interface for VLAN ID configure.
- **IP Address** : Specify the IPv6 address of the neighboring device which can be reached through the interface.
- **MAC Addresss** : Specify the MAC address of the neighboring device which can be reached through the interface.

Click the "**Apply**" button to save your changes or "**Close**" the button to close settings.

15. Security

15.1 RADIUS

Network architecture can establish a Remote Authorization login Service (RADIUS) server to provide a centralized 802.1X or MAC-based network access control for all of its devices. This switch can act as a RADIUS client that uses the RADIUS server to provide centralized security and authorization and user authentication.

Administrator can set account for the switch on the RADIUS server, and configure that RADIUS server along with the other parameters on the RADIUS page.

Security → RADIUS

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security**
 - RADIUS
 - TACACS+
 - AAA
 - Management Access
 - Authentication Manager

Use Default Parameter

Retry	<input type="text" value="3"/>	(1 - 10, default 3)
Timeout	<input type="text" value="3"/>	Sec (1 - 30, default 3)
Key String	<input type="text"/>	

RADIUS Table

Showing entries Showing 1 to 1 of 1 entries

	Server Address	Server Port	Priority	Retry	Timeout	Usage
<input type="checkbox"/>	192.168.2.99	1812	1	3	3	All

➤ Use Default Parameters :

- **Retry:** Set default retry number ,Enter the number of transmitted requests that are sent to the RADIUS server before a failure is considered to have occurred. Default is 3.
- **Timeout:** Set default timeout value ,Enter the number of seconds that the switch waits for an answer from the RADIUS server before retrying the query, or switching to the next server. Default is 3.
- **Key String:** Set default RADIUS key string ,The key string used security communications between the switch and the RADIUS server by MD5.This key must match the key configured on the RADIUS server. If don't have an encrypted key string (from other device), please enter the key string in plaintext form.

Click the **"Apply"** button to save your changes settings.

Field	Description
Server Address	RADIUS server address.
Server Port	RADIUS server port.
Priority	RADIUS server priority (smaller value has higher priority). RADIUS session will try to establish with the server setting which has highest priority. If failed, it will try to connect to the server with next higher priority.
Retry	RADIUS server retry value. If it is fail to connect to server, it will keep trying until timeout with retry times.
Timeout	RADIUS server timeout value. If it is fail to connect to server, it will keep trying until timeout.
Usage	RADIUS server usage type <ul style="list-style-type: none"> • Login: For login authentication. • 802.1x: For 802.1x authentication. • All: For alltypes.

Add RADIUS Server

Address Type	<input checked="" type="radio"/> Hostname <input type="radio"/> IPv4 <input type="radio"/> IPv6
Server Address	192.168.2.99
Server Port	1812 (0 - 65535, default 1812)
Priority	1 (0 - 65535)
Key String	<input checked="" type="checkbox"/> Use Default <input type="text"/>
Retry	<input checked="" type="checkbox"/> Use Default <input type="text"/> 3 (1 - 10, default 3)
Timeout	<input checked="" type="checkbox"/> Use Default <input type="text"/> 3 Sec (1 - 30, default 3)
Usage	<input type="radio"/> Login <input type="radio"/> 802.1X <input checked="" type="radio"/> All

- **Address Type:** Select IP Version 4 / 6 or use Hostname type, In add dialog, user need to specify server Address Type
 - **Hostname:** Use domain name as server address.
 - **IPv4:** Use IPv4 as server address.
 - **IPv6:** Use IPv6 as server address.
- **Server Address:** Please enter the IP address or hostname of the RADIUS server. In add dialog, user need to input server address based on address type. In edit dialog, it shows current edit server address.
- **Server Port:** Set port of RADIUS server.
- **Priority:** Administrator can enter the priority of the server. The priority determines the order that the switch attempts to contact the servers to authenticate users. The switch first starts with the highest priority server. 0 is the high priority, Set RADIUS server priority (smaller value has higher priority). RADIUS session will try to establish with the server setting which has highest priority. If failed, it will try to connect to the server with next higher priority.
- **Key String:** Administrator can select user defined Encrypted or Plaintext to enter the key string form used for authenticating and encrypting the communication between the switch and the RADIUS server. This key must match the key configured on the RADIUS server. If administrator select use default (checked in checkbox) will use the default key string.
- **Retry:** Select User Defined to enter the number of requests that are sent to the RADIUS server before a failure is considered to have occurred, or select Use Default to use the default value.
- **Timeout:** Select User Defined to enter the number of seconds that the switch waits for an answer from the RADIUS server before retrying the query or switching to the next server, or select Use Default to use the default value. Set RADIUS server timeout value. If it is fail to connect to server, it will keep trying until timeout.
- **Usage:** Select the RADIUS server authentication type.
 - **Login:** RADIUS server is used for authenticating users that want to administer the switch.
 - **802.1X:** RADIUS server is used for authentication in 802.1X access control.
 - **All:** RADIUS server is used for authenticating user that wants to administer the switch and for authentication in 802.1X access control.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

15.2 TACACS+

Administrator can be configuration TACACS+ to connection TACACS+ Server to provide authentication and authorization for all devices in the organization.

This page allow user to add, edit or delete TACACS+ server settings and modify default parameter of TACACS+ server.

Security → TACACS+

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security**
 - RADIUS
 - TACACS+**
 - AAA
 - Management Access

Use Default Parameter

Timeout: Sec (1 - 30, default 5)

Key String:

TACACS+ Table

Showing entries Showing 1 to 1 of 1 entries

	Server Address	Server Port	Priority	Timeout
<input type="checkbox"/>	192.168.2.101	49	2	5

➤ Use Default Parameters :

- **Timeout:** Enter the amount of time in seconds that passes before the connection between the switch and the TACACS+ server times out. If a value is not entered for an individual server, the value is taken from this field, default is 5.
- **Key String:** Enter the default key string in encrypted or plaintext form used for communicating with all TACACS+ servers.

Note	If administrator don't enter the default key string here, the key entered on the Add page must match the encryption key used by the TACACS+ server or enter the default key string here and a key string for an individual TACACS+ server, the key string configured for the individual TACACS+ server takes precedence.
-------------	--

Click the **"Apply"** button to save your changes settings.

Field	Description
Server Address	TACACS+ server address.
Server Port	TACACS+ server port.
Priority	TACACS+ server priority (smaller value has higher priority). TACACS+ session will try to establish with the server setting which has highest priority. If failed, it will try to connect to the server with next higher priority.
Retry	RADIUS server retry value. If it is fail to connect to server, it will keep trying until timeout with retry times.
Timeout	TACACS+ server timeout value. If it is fail to connect to server, it will keep trying until timeout.

Add TACACS+ Server

Address Type	<input type="radio"/> Hostname <input checked="" type="radio"/> IPv4 <input type="radio"/> IPv6
Server Address	192.168.2.101
Server Port	49 (0 - 65535, default 49)
Priority	2 (0 - 65535)
Key String	<input checked="" type="checkbox"/> Use Default <input type="text"/>
Timeout	<input checked="" type="checkbox"/> Use Default <input type="text"/> 5 Sec (1 - 30, default 5)

- **Address Type:** Select IP Version 4 / 6 or use Hostname typem, In add dialog, user need to specify server Address Type
 - **Hostname:** Use domain name as server address.
 - **IPv4:** Use IPv4 as server address.
 - **IPv6:** Use IPv6 as server address.
- **Server Address:** In add dialog, user need to input server address based on address type. In edit

dialog, it shows current edit server address.

- **Server Port:** Set TACACS+ server port.
- **Priority:** Administrator can enter the priority of the server. The priority determines the order that the switch attempts to contact the servers to authenticate users. The switch first starts with the highest priority server. 0 is the high priority, Set TACACS+ server priority (smaller value has higher priority). TACACS+ session will try to establish with the server setting which has highest priority. If failed, it will try to connect to the server with next higher priority.
- **Key String:** Administrator can select user defined Encrypted or Plaintext to enter the key string form used for authenticating and encrypting the communication between the switch and the TACACS+ server. This key must match the key configured on the TACACS+ server. If administrator select use default (checked in checkbox) will use the default key string.
- **Timeout:** Set TACACS+ server timeout value. If it is fail to connect to server, it will keep trying until timeout.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

15.3 AAA

15.3.1 Method List

Administrator can set groups of AAA security, each group have 4 method table, each method can select 1 of 6 type which contains Empty / None / Local / Enable / RADIUS and TACACS+.

This page allow user to add, edit or delete login authentication list settings (The “default” list cannot be deleted.). The line combined to this list will authenticate login user by methods in this list. If the first method is failed, it will try to use the next priority method to authenticate if it exists. With RADIUS and TACACS+ methods, the failed means connecting to server fail. With Local method, the failed means cannot find the user in local database.

Security → AAA → Method List

- ✖ Status
- ✖ Network
- ✖ Port
- ✖ POE Setting
- ✖ VLAN
- ✖ MAC Address Table
- ✖ Spanning Tree
- ✖ ERPS
- ✖ Discovery
- ✖ DHCP
- ✖ Multicast
- ✖ IP Configuration
- Security**
 - RADIUS
 - TACACS+
 - ✖ AAA
 - Method List**
 - Login Authentication
 - ✖ Management Access
 - ✖ Authentication Manager
 - Port Security
 - Protected Port
 - Storm Control
 - ✖ DoS
 - ✖ Dynamic ARP Inspection
 - ✖ DHCP Snooping
 - ✖ IP Source Guard

Method List Table

Showing All entries Showing 1 to 1 of 1 entries

<input type="checkbox"/>	Name	Sequence
<input type="checkbox"/>	default	(1) Local

First Previous 1 Next

Add Edit Delete

Field	Description
Name	Login authentication list name. This name should be different from other existing lists.

Priority of login authentication method.

Sequence

- **None:** Authenticated with any condition.
- **Local:** Use local accounts database to authenticate
- **TACACS+:** Use remote TACACS+ server to authenticate.
- **RADIUS:** Use remote Radius server to authenticate.
- **Enable:** Use local enable password to authenticate

Name	Methods
default	<p><input type="radio"/> Empty</p> <p><input type="radio"/> None</p> <p><input checked="" type="radio"/> Local</p> <p><input type="radio"/> Enable</p> <p><input type="radio"/> RADIUS</p> <p><input type="radio"/> TACACS+</p>
	<p><input checked="" type="radio"/> Empty</p> <p><input type="radio"/> None</p> <p><input type="radio"/> Local</p> <p><input type="radio"/> Enable</p> <p><input type="radio"/> RADIUS</p> <p><input type="radio"/> TACACS+</p>
	<p><input checked="" type="radio"/> Empty</p> <p><input type="radio"/> None</p> <p><input type="radio"/> Local</p> <p><input type="radio"/> Enable</p> <p><input type="radio"/> RADIUS</p> <p><input type="radio"/> TACACS+</p>
	<p><input checked="" type="radio"/> Empty</p> <p><input type="radio"/> None</p> <p><input type="radio"/> Local</p> <p><input type="radio"/> Enable</p> <p><input type="radio"/> RADIUS</p> <p><input type="radio"/> TACACS+</p>

Apply Close

- **Name:** Login authentication list name. This name should be different from other existing lists.
- **Method 1:** Select first priority of login authentication method.
 - **None:** Authenticated with any condition.
 - **Local:** Use local accounts database to authenticate TACACS+: Use remote TACACS+ server to authenticate.
 - **RADIUS:** Use remote Radius server to authenticate.
 - **Enable:** Use local enable password to authenticate.
- **Method 2:** Select first priority of login authentication method.
 - **None:** Authenticated with any condition.
 - **Local:** Use local accounts database to authenticate TACACS+: Use remote TACACS+ server to authenticate.
 - **RADIUS:** Use remote Radius server to authenticate.

- **Enable:** Use local enable password to authenticate.
- **Method 3:** Select first priority of login authentication method.
 - **None:** Authenticated with any condition.
 - **Local:** Use local accounts database to authenticate TACACS+: Use remote TACACS+ server to authenticate.
 - **RADIUS:** Use remote Radius server to authenticate.
 - **Enable:** Use local enable password to authenticate.
- **Method 4:** Select first priority of login authentication method.
 - **None:** Authenticated with any condition.
 - **Local:** Use local accounts database to authenticate TACACS+: Use remote TACACS+ server to authenticate.
 - **RADIUS:** Use remote Radius server to authenticate.
 - **Enable:** Use local enable password to authenticate.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

15.3.2 Login Authentication

When administrator has created security groups in "AAA→method" then administrator can select different security group in service port.

Service	Method	Available Methods
Console	default	(1) Local
Telnet	test	(1) TACACS+, (2) TACACS+, (3) RADIUS, (4) TACACS+
SSH	default	(1) Local
HTTP	test	(1) TACACS+, (2) TACACS+, (3) RADIUS, (4) TACACS+
HTTPS	default	(1) Local

Field	Description
Console	Specify login authentication list combined on console

Telnet	Specify login authentication list combined on Telnet
SSH	Specify login authentication list combined on SSH
HTTPS	Specify login authentication list combined on HTTPS

Click the **"Apply"** button to save your changes settings.

15.4 Management Access

15.4.1 Management Service

Administrator can select enable Telnet / SSH / HTTP / HTTPS / SNMP by different protocol to login service and configuration login timeout limit and password error retry count limit.

Security → Management Access → Management Service

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security**
 - RADIUS
 - TACACS+
 - AAA
 - Management Access
 - Management Service**
 - Management ACL
 - Management ACE
 - Authentication Manager
 - Port Security
 - Protected Port
 - Storm Control
 - DoS
 - Dynamic ARP Inspection
 - DHCP Snooping
 - IP Source Guard
- ACL
- QoS
- Diagnostics
- Management

Management Service

Telnet	<input type="checkbox"/> Enable
SSH	<input type="checkbox"/> Enable
HTTP	<input checked="" type="checkbox"/> Enable
HTTPS	<input type="checkbox"/> Enable
SNMP	<input type="checkbox"/> Enable

Session Timeout

Console	<input type="text" value="10"/> Min (0 - 65535, default 10)
Telnet	<input type="text" value="10"/> Min (0 - 65535, default 10)
SSH	<input type="text" value="10"/> Min (0 - 65535, default 10)
HTTP	<input type="text" value="10"/> Min (0 - 65535, default 10)
HTTPS	<input type="text" value="10"/> Min (0 - 65535, default 10)

Password Retry Count

Console	<input type="text" value="3"/> (0 - 120, default 3)
Telnet	<input type="text" value="3"/> (0 - 120, default 3)
SSH	<input type="text" value="3"/> (0 - 120, default 3)

Silent Time

Console	<input type="text" value="0"/> Sec (0 - 65535, default 0)
Telnet	<input type="text" value="0"/> Sec (0 - 65535, default 0)
SSH	<input type="text" value="0"/> Sec (0 - 65535, default 0)

➤ **Management Service:** Management service admin state.

- **Telnet:** Connect CLI through telnet.
- **SSH:** Connect CLI through SSH.

- **HTTP:** Connect WEBUI through HTTP.
- **HTTPS:** Connect WEBUI through HTTPS.
- **SNMP:** Manage switch through SNMP.
- **Session Timeout:** Set session timeout minutes for user access to user interface. 0 minutes means never timeout, After login management page, in the set time if not session then system will auto timeout, administrator need re-login.
 - **Console:** Set console for session timeout 0~65535 minutes.
 - **Telnet:** Set Telnet for session timeout 0~65535 minutes.
 - **SSH:** Set SSH for session timeout 0~65535 minutes.
 - **HTTP:** Set HTTP for session timeout 0~65535 minutes.
 - **HTTPS:** Set HTTPS for session timeout 0~65535 minutes.
- **Password Retry Count:** Retry count is the number which CLI password input error tolerance count. After input error password exceeds this count, the CLI will freeze after silent time, If login error reaches the set value then login page will be kicked out, administrator need reopen the login page.
 - **Console:** Set console for password Retry count of 0~120 .
 - **Telnet:** Set Telnet for password Retry count of 0~120 .
 - **SSH:** Set SSH for password Retry count of 0~120 .
- **Silent Time:** This function to be matched "Password Retry Count" function, if login error reaches the set value within then set value of silent time will can't be reopen login page until the set time end ,After input error password exceeds password retry count, the CLI will freeze after silent time.
 - **Console:** Set console for Silent Time of 0~65535 minutes .
 - **Telnet:** Set Telnet for Silent Time of 0~65535 minutes .
 - **SSH:** Set SSH for for Silent Time of 0~65535 minutes .

15.4.2 Management ACL

Administrator can create ACL and set Active or Deactive the rules.

If administrator set "Active" will be apply "Management ACE" rules. ACL can set which ports is Permit or Deny connection to which services of the switch management interface.

Note

If only create one ACL Profile and click Active then these all ports and services will are all denied.

Security → Management Access → Management ACL

- ▼ Status
- ▼ Network
- ▼ Port
- ▼ POE Setting
- ▼ VLAN
- ▼ MAC Address Table
- ▼ Spanning Tree
- ▼ ERPS
- ▼ Discovery
- ▼ DHCP
- ▼ Multicast
- ▼ IP Configuration
- Security**
 - RADIUS
 - TACACS+
 - AAA
 - Management Access
 - Management Service
 - Management ACL**
 - Management ACE
 - Authentication Manager
 - Port Security
 - Protected Port
 - Storm Control
 - DoS
 - Dynamic ARP Inspection
 - DHCP Snooping
 - IP Source Guard

ACL Name

Management ACL Table

Showing entries Showing 1 to 1 of 1 entries

<input type="checkbox"/>	ACL Name	State	Rule
<input type="checkbox"/>	ACLtest	Deactive	0

➤ **ACL Name:** Input MAC ACL name.

Click the "**Apply**" button to save your changes settings.

Field	Description
ACL Name	Display Management ACL name
State	Display Management ACL whether active.
Rule	Display the number Management ACE rule of ACL

Set the "**Active**" and "**Deactive**" and "**Delete**" for this table management.

15.4.3 Management ACE

This management ACE page is to create an ACL profile rule. Administrator can select an created

ACL profile to set security rule. If set the ACE only use Telnet a single rule. After confirmation the rule will apply to ACL profile.

Administrator can go to "management ACL" page click "Active" button to enable the rule. After active the rule, this management page will can't operating only use Telnet protocol to management, Setting **"add"** and **"Edit"** and **"Delete"** function for this management.

Security → Management Access → Management ACE

Management ACE Table

ACL Name

Showing entries Showing 1 to 1 of 1 entries

<input type="checkbox"/>	Priority	Action	Service	Port	Address / Mask
<input type="checkbox"/>	1	Deny	Snmp	GE2-GE3	192.168.2.77 / 255.255.255.0

First Previous 1 Next

Add Edit Delete

➤ **ACL Name:** Select the ACL name to which an ACE is being added.

Field	Description
Priority	Display the priority of ACE.
Action	Display the action of ACE
Service	Display the service ACE.
Port	Display the port list of ACE.
Address / Mask	Display the source IP address and mask of ACE.

Add Managemet ACE

ACL Name	test1		
Priority	1 (1 - 65535)		
Service	<input type="radio"/> All <input type="radio"/> Http <input type="radio"/> Https <input checked="" type="radio"/> Snmp <input type="radio"/> SSH <input type="radio"/> Telnet		
Action	<input type="radio"/> Permit <input checked="" type="radio"/> Deny		
Port	Available Port GE1 GE4 GE5 GE6 GE7 GE8 GE9 GE10	Selected Port GE3 GE2	
IP Version	<input type="radio"/> All <input checked="" type="radio"/> IPv4 <input type="radio"/> IPv6		
IPv4	192.168.2.77 / 255.255.255.0		
IPv6	/ 128 (1 - 128)		

Apply
Close

- **ACL Name:** Display the ACL name to which an ACE is being added.
- **Priority:** Set this rule priority, Specify the priority of the ACE. ACEs with higher sequence are processed first (1 is the highest priority). Only available on Add Dialog.
- **Service:** Select the type service of rule.
 - **All:** All services .
 - **HTTP:** Only HTTP service .
 - **HTTPS:** Only HTTPS service.
 - **SNMP:** Only SNMP service.
 - **SSH:** Only SSH service.
 - **Telnet:** Only Telnet service
- **Action:** Select the action after ACE match packet.
 - **Permit:** Forward packets that meet the ACE criteria.
 - **Deny:** Drop packets that meet the ACE criteria.

- **Port:** Select ports which will be matched.
- **IP Version:** Select the type of source IP address.
 - **All:** All IP addresses can access.
 - **IPv4:** Specify IPv4 address ca access.
 - **IPv6:** Specify IPv6 address ca access
- **IPv4:** Enter the source IPv4 address value and mask to which will be matched.
- **IPv6:** Enter the source IPv6 address value and mask to which will be matched.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

15.5 Authentication Manager

15.5.1 Property

This page allow user to edit authentication global settings and some port mods' configurations, Administrator can edit authentication global settings and some port mods' configurations.

Security → Authentication Manager → Property

- ✖ Status
- ✖ Network
- ✖ Port
- ✖ POE Setting
- ✖ VLAN
- ✖ MAC Address Table
- ✖ Spanning Tree
- ✖ ERPS
- ✖ Discovery
- ✖ DHCP
- ✖ Multicast
- ✖ IP Configuration
- Security
 - RADIUS
 - TACACS+
 - AAA
 - Management Access
 - Authentication Manager
 - Property
 - Port Setting
 - MAC-Based Local Account
 - WEB-Based Local Account
 - Sessions
 - Port Security
 - Protected Port
 - Storm Control
 - DoS
 - Dynamic ARP Inspection
 - DHCP Snooping
 - IP Source Guard
 - ACL
 - QoS
 - Diagnostics
 - Management

Authentication Type

☒ 802.1x

☒ MAC-Based

☒ WEB-Based

Guest VLAN

☐ Enable

MAC-Based User ID Format

XXXXXXXXXXXX

Apply

Port Mode Table

Entry	Port	Authentication Type			Host Mode	Order	Method	Guest VLAN	VLAN Assign Mode
		802.1x	MAC-Based	WEB-Based					
<input checked="" type="checkbox"/>	1 GE1	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	2 GE2	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	3 GE3	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	4 GE4	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	5 GE5	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	6 GE6	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	7 GE7	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	8 GE8	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	9 GE9	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	10 GE10	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	11 GE11	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	12 GE12	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input checked="" type="checkbox"/>	13 GE13	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	14 GE14	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static

- **Authentication Type :** Set checkbox to enable/disable following authentication types
 - 802.1x: Use IEEE 802.1x to do authentication
 - MAC-Based: Use MAC address to do authentication
 - WEB-Based: Prompt authentication web page for user to do authentication

- **Guest VLAN** : Set checkbox to enable/disable guest VLAN, if guest VLAN is enabled, you need to select one available VLAN ID to be guest VID.
- **MAC-Based User ID Format** : Select mac-based authentication RADIUS username/password ID format.
 - XXXXXXXXXXXXX
 - XXXXXXXXXXXXX
 - XX:XX:XX:XX:XX:XX
 - XX:XX:XX:XX:XX:XX
 - XX-XX-XX-XX-XX-XX
 - XX-XX-XX-XX-XX-XX
 - XX.XX.XX.XX.XX.XX
 - XX.XX.XX.XX.XX.XX
 - XXXX:XXXX:XXXX
 - XXXX:XXXX:XXXX
 - XXXX-XXXX-XXXX
 - XXXX-XXXX-XXXX
 - XXXX.XXXX.XXXX
 - XXXX.XXXX.XXXX
 - XXXXXX:XXXXXX
 - XXXXXX:XXXXXX
 - XXXXXX-XXXXXX
 - XXXXXX-XXXXXX

Click the **“Apply”** button to save your changes settings.

Port Mode Table										
	Entry	Port	Authentication Type			Host Mode	Order	Method	Guest VLAN	VLAN Assign Mode
			802.1x	MAC-Based	WEB-Based					
<input type="checkbox"/>	1	GE1	Enabled	Enabled	Enabled	Multiple Authentication	802.1x , WEB-Based	RADIUS , Local	Enabled	Disable
<input type="checkbox"/>	2	GE2	Enabled	Enabled	Enabled	Multiple Authentication	802.1x , WEB-Based	RADIUS , Local	Enabled	Disable
<input type="checkbox"/>	3	GE3	Enabled	Enabled	Enabled	Multiple Authentication	802.1x , WEB-Based	RADIUS , Local	Enabled	Disable
<input type="checkbox"/>	4	GE4	Enabled	Enabled	Enabled	Multiple Authentication	802.1x , WEB-Based	RADIUS , Local	Enabled	Disable
<input type="checkbox"/>	5	GE5	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	6	GE6	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	7	GE7	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	8	GE8	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	9	GE9	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static

Field	Description
Port	Port name
Authentication Type (802.1X)	<p>802.1 X authentication type state</p> <ul style="list-style-type: none"> • Enabled: 802.1X is enabled • Disabled: 802.1X is disabled
Authentication Type (MAC-Based)	<p>MAC-Based authentication type state</p> <ul style="list-style-type: none"> • Enabled: MAC-Based authentication is enabled • Disabled: MAC-Based authentication is disabled
Authentication Type (WEB-Based)	<p>WEB-Based authentication type state</p> <ul style="list-style-type: none"> • Enabled: WEB-Based authentication is enabled • Disabled: WEB-Based authentication is disabled
Host Mode	<p>Authenticating host mode</p> <ul style="list-style-type: none"> • Multiple Authentication: In this mode, every client need to pass authenticate procedure individually. • Multiple Hosts: In this mode, only one client need to be authenticated and other clients will get the same access accessibility. Web-auth cannot be enabled in this mode. • Single Host: In this mode, only one host is allowed to be authenticated. It is the same as Multi-auth mode with max hosts number configure to be 1.
Order	<p>Support following authentication type order combinations. Web Authentication should always be the last type. The authentication manager will go to next type if current type is not enabled or authenticated fail.</p> <ul style="list-style-type: none"> • 802.1x • MAC-Based • WEB-Based • 802.1x MAC-Based • 802.1x WEB-Based • MAC-Based 802.1x • WEB-Based 802.1x • 802.1x MAC-Based WEB-Based • 802.1x WEB-Based MAC-Based

Method	<p>Support following authentication method order combinations. These orders only available on MAC-Based authentication and WEB-Based authentication. 802.1x only support Radius method.</p> <ul style="list-style-type: none"> • Local: Use DUT's local database to do authentication • Radius: Use remote RADIUS server to do authentication • Local Radius • RadiusLocal
Guest VLAN	<p>Port guest VLAN enable state</p> <ul style="list-style-type: none"> • Enabled: Guest VLAN is enabled on port • Disabled: Guest VLAN is disabled on port
VLAN Assign Mode	<p>Support following VLAN assign mode and only apply when source is RADIUS</p> <ul style="list-style-type: none"> • Disable: Ignore the VLAN authorization result and keep original VLAN of host. • Reject: If get VLAN authorized information, just use it. However, if there is no VLAN authorized information, reject the host and make it unauthorized. • Static: If get VLAN authorized information, just use it. If there is no VLAN authorized information, keep original VLAN of host.

Edit Port Mode

Port	GE1,GE13	
Authentication Type	<input checked="" type="checkbox"/> 802.1x	
	<input checked="" type="checkbox"/> MAC-Based	
	<input checked="" type="checkbox"/> WEB-Based	
Host Mode	<input checked="" type="radio"/> Multiple Authentication <input type="radio"/> Multiple Hosts <input type="radio"/> Single Host	
Order	Available Type	Select Type
	<div>MAC-Based</div> <div></div>	<div>802.1x</div> <div>WEB-Based</div>
Method	Available Method	Select Method
	<div>Local</div> <div></div>	<div>RADIUS</div> <div></div>
Guest VLAN	<input type="checkbox"/> Enable	
VLAN Assign Mode	<input type="radio"/> Disable <input type="radio"/> Reject <input checked="" type="radio"/> Static	

Apply
Close

- **Port :** Display selected Port number.
- **Authentication Type :** Set checkbox to enable/disable authentication types.
 - **802.1x :** Use IEEE 802.1x to do authentication
 - **MAC-Based :** Use MAC address to do authentication
 - **WEB-Based :** Prompt authentication web page for user to do authentication
- **Host Mode :** Select authenticating host mode.
 - **Multiple Authentication :** In this mode, every client need to pass authenticate procedure individually
 - **Multiple Hosts :** In this mode, only one client need to be authenticated and other clients will get the same access accessibility. Web-auth cannot be enabled in this mode.
 - **Single Host :** In this mode, only one host is allowed to be authenticated. It is the same as Multi-auth mode with max hosts number configure to be 1.
- **Order :** Support following authentication type order combinations. Web Authentication should always be the last type. The authentication manager will go to next type if current

type is not enabled or authenticated fail.

- 802.1x
 - MAC-Based
 - WEB-Based
 - 802.1x MAC-Based
 - 802.1x WEB-Based
 - MAC-Based 802.1x
 - WEB-Based 802.1x
 - 802.1x MAC-Based WEB-Based
 - 802.1x WEB-Based MAC-Based
- **Method** : Support following authentication method order combinations. These orders only available on MAC-Based authentication and WEB-Based authentication. 802.1x only support Radius method.
- **Local** : Use DUT's local database to do authentication
 - **Radius** : Use remote RADIUS server to do authentication
- **Guest VLAN** : Set checkbox to enable/disable guest VLAN.
- **VLAN Assign Mode** : Support following VLAN assign mode and only apply when source is RADIUS.
- **Disable**: Ignore the VLAN authorization result and keep original VLAN of host.
 - **Reject**: If get VLAN authorized information, just use it. However, if there is no VLAN authorized information, reject the host and make it unauthorized. Local Radius.
 - **Static**: If get VLAN authorized information, just use it. If there is no VLAN authorized information, keep original VLAN of host.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

15.5.2 Port Setting

Administrator can configure authentication manger port settings, This page allow user to configure authentication manger port settings

Security → Authentication Manager → Port Setting

Port Setting Table									
	Entry	Port	Port Control	Reauthentication	Max Hosts	Common Timer			
						Reauthentication	Inactive	Quiet	
<input type="checkbox"/>	1	GE1	Auto	Enabled	256	3600	60	60	
<input type="checkbox"/>	2	GE2	Auto	Enabled	256	3600	60	60	
<input type="checkbox"/>	3	GE3	Auto	Enabled	256	3600	60	60	
<input type="checkbox"/>	4	GE4	Disabled	Disabled	256	3600	60	60	
<input type="checkbox"/>	5	GE5	Disabled	Disabled	256	3600	60	60	
<input type="checkbox"/>	6	GE6	Disabled	Disabled	256	3600	60	60	
<input type="checkbox"/>	7	GE7	Disabled	Disabled	256	3600	60	60	
<input type="checkbox"/>	8	GE8	Disabled	Disabled	256	3600	60	60	
<input type="checkbox"/>	9	GE9	Disabled	Disabled	256	3600	60	60	
<input checked="" type="checkbox"/>	10	GE10	Disabled	Disabled	256	3600	60	60	
<input type="checkbox"/>	11	GE11	Disabled	Disabled	256	3600	60	60	
<input type="checkbox"/>	12	GE12	Disabled	Disabled	256	3600	60	60	

Port Setting Table

	Entry	Port	Port Control	Reauthentication	Max Hosts	Common Timer				802.1x Parameters				Web-Based Parameters	
						Reauthentication	Inactive	Quiet		TX Period	Supplicant Timeout	Server Timeout	Max Request		Max Login
<input type="checkbox"/>	1	GE1	Auto	Enabled	256	3600	60	60		30	30	30	2		3
<input type="checkbox"/>	2	GE2	Auto	Enabled	256	3600	60	60		30	30	30	2		3
<input type="checkbox"/>	3	GE3	Auto	Enabled	256	3600	60	60		30	30	30	2		3
<input type="checkbox"/>	4	GE4	Disabled	Disabled	256	3600	60	60		30	30	30	2		3
<input type="checkbox"/>	5	GE5	Disabled	Disabled	256	3600	60	60		30	30	30	2		3
<input type="checkbox"/>	6	GE6	Disabled	Disabled	256	3600	60	60		30	30	30	2		3
<input type="checkbox"/>	7	GE7	Disabled	Disabled	256	3600	60	60		30	30	30	2		3
<input type="checkbox"/>	8	GE8	Disabled	Disabled	256	3600	60	60		30	30	30	2		3
<input type="checkbox"/>	9	GE9	Disabled	Disabled	256	3600	60	60		30	30	30	2		3
<input checked="" type="checkbox"/>	10	GE10	Disabled	Disabled	256	3600	60	60		30	30	30	2		3
<input type="checkbox"/>	11	GE11	Disabled	Disabled	256	3600	60	60		30	30	30	2		3
<input type="checkbox"/>	12	GE12	Disabled	Disabled	256	3600	60	60		30	30	30	2		3

Field Description

Port

Port name

Support following authentication port control types.

- **Disable:** Disable authentication function and all clients have network accessibility.
- **Force Authorized:** Port is force authorized and all clients have network accessibility.
- **Force Unauthorized:** Port is force unauthorized and all clients have no network accessibility.
- **Auto:** Need passing authentication procedure to get network accessibility.

Port Control

Reauthentication	<p>Reauthenticate state</p> <ul style="list-style-type: none"> • Enabled: Host will be reauthenticated after reauthentication period • Disabled: Host will not be reauthenticated after reauthentication period.
Max Hosts	<p>In Multiple Authentication mode, total host number cannot not exceed max hosts number</p>
Common Timer	<ul style="list-style-type: none"> • Reauthentication: After re-authenticate period, host will return to initial state and need to pass authentication procedure again. • Inactive: If no packet from the authenticated host, the inactive timer will increase. After inactive timeout, the host will be unauthorized and corresponding session will be deleted. In multi-host mode, the packet is counting on the authorized host only and not all packets on the port. • Quiet: When port is in Locked state after authenticating fail several times, the host will be locked in quiet period. After this quiet period, the host is allowed to authenticate again.
802.1X Params	<ul style="list-style-type: none"> • TX Period: Number of seconds that the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the supplicant (client) before resending the request. • Supplicant Timeout: The maximum number of EAP requests that can be sent. If a response is not received after the defined period (supplicant timeout), the authentication process is restarted. • Server Timeout: Number of seconds that lapses before EAP requests are resent to the supplicant. • Max Request: Number of seconds that lapses before the device resends a request to the authentication server
Web-Based Param (Max Login)	<p>Allow user login fail number. After login fail number exceed, the host will enter Lock state and is not able to authenticate until quiet period exceed.</p>

Edit Port Setting	
Port	GE1-GE3
Port Control	<input type="radio"/> Disabled <input type="radio"/> Force Authorized <input type="radio"/> Force Unauthorized <input checked="" type="radio"/> Auto
Reauthentication	<input checked="" type="checkbox"/> Enable
Max Hosts	256 (1 - 256, default 256)
Common Timer	
Reauthentication	3600 Sec (300 - 2147483647, default 3600)
Inactive	60 Sec (60 - 65535, default 60)
Quiet	60 Sec (0 - 65535, default 60)
802.1x Parameters	
TX Period	30 Sec (1 - 65535, default 30)
Supplicant Timeout	30 Sec (1 - 65535, default 30)
Server Timeout	30 Sec (1 - 65535, default 30)
Max Request	2 (1 - 10, default 2)
Web-Based Parameters	
Max Login	<input type="checkbox"/> Infinite 3 (3 - 10, default 3)
<input type="button" value="Apply"/> <input type="button" value="Close"/>	

- **Port** : Display selected Port number.
- **Port Control** : Support following authentication port control types.
 - **Disable** : Disable authentication function and all clients have network accessibility.
 - **Force Authorized** : Port is force authorized and all clients have network accessibility.
 - **Force Unauthorized** : Port is force unauthorized and all clients have no network accessibility.
 - **Auto** : Need passing authentication procedure to get network accessibility.
- **Reauthentication** : Set checkbox to enable/disable reauthentication.
- **Max Hosts** : In Multiple Authentication mode, total host number cannot not exceed max hosts number.
- **Common Timer**:
 - **Reauthentication** : After re-authenticate period, host will return to initial state and need to pass authentication procedure again.

- **Inactive** : If no packet from the authenticated host, the inactive timer will increase. After inactive timeout, the host will be unauthorized and corresponding session will be deleted. In multi-host mode, the packet is counting on the authorized host only and not all packets on the port.
- **Quiet** : When port is in Locked state after authenticating fail several times, the host will be locked in quiet period. After this quiet period, the host is allowed to authenticate again.
- **Auto** : Need passing authentication procedure to get network accessibility.

➤ 802.1X Params :

- **TX Period** : Number of seconds that the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the supplicant (client) before resending the request.
- **Supplicant Timeout** : The maximum number of EAP requests that can be sent. If a response is not received after the defined period (supplicant timeout), the authentication process is restarted.
- **Server Timeout**: Number of seconds that lapses before EAP requests are resent to the supplicant.
- **Max Request** : Number of seconds that lapses before the device resends a request to the authentication server.
- **Max Login** : Set checkbox to set max login number to be infinite or specify max login number.

*Click the “**Apply**” button to save your changes or “**Close**” the button to close settings.*

15.5.3 MAC-Based Local Account

Administrator can allow to add/edit/delete MAC-Based authentication local accounts, Setting “add” and “Edit” and “Delete” function for this management.

Security → Authentication Manager → MAC-Based Local Account

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security**
 - RADIUS
 - TACACS+
 - AAA
 - Management Access
 - Authentication Manager
 - Property
 - Port Setting
 - MAC-Based Local Account

MAC-Based Local Account Table

Showing All entries Showing 1 to 1 of 1 entries

	MAC Address	Control	VLAN	Timeout (Sec)	
				Reauthentication	Inactive
<input type="checkbox"/>	8C:4D:EA:FE:05:BE	Force Unauthorized	1	3600	60

Field	Description
MAC Address	Authenticated host MAC address, and each MAC allow only one entry in local database.
Control	Control Type <ul style="list-style-type: none"> Force Authorized: Host will be force authorized. Force Unauthorized: Host will be force unauthorized.
VLAN	Assigned VLAN ID for the authenticated host.
Timeout	<ul style="list-style-type: none"> Reauthentication: Assigned reauthentication period for the authenticated host. Inactive: Assigned inactive timeout for the authenticated host.

Add MAC-Based Local Account


MAC Address	<input type="text" value="8C:4D:EA:FE:05:BE"/>	
Port Control	<input type="radio"/> Force Authorized <input checked="" type="radio"/> Force Unauthorized	
VLAN	<input checked="" type="checkbox"/> User Defined <input type="text" value="1"/> (1 - 4094)	
Assigned Timer		
Reauthentication	<input checked="" type="checkbox"/> User Defined <input type="text" value="3600"/> Sec (300 - 2147483647)	
Inactive	<input checked="" type="checkbox"/> User Defined <input type="text" value="60"/> Sec (60 - 65535)	

- **MAC Address** : Authenticated host MAC address, and each MAC allow only one entry in local database.
- **Port Control** : Support following authentication port control types.
 - **Force Authorized**: Host will be force authorized.
 - **Force Unauthorized** : Host will be force unauthorized.
- **VLAN** : Assigned VLAN ID for the authenticated host.
- **Assigned Timer**:
 - **Timeout (Reauthentication)** : Assigned reauthentication period for the authenticated host.
 - **Timeout (Inactive)** : Assigned inactive timeout for the authenticated host.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

15.5.4 WEB-Based Local Account

Administrator can allow to add/edit/delete WEB-Based authentication local accounts, Setting “add” and “Edit” and “Delete” function for this management.



Field	Description
Username	Authenticating account user name
VLAN	Assigned VLAN ID for the authenticated host.
Timeout(Sec)	<ul style="list-style-type: none">• Reauthentication: Assigned reauthentication period for the authenticated host.• Inactive: Assigned inactive timeout for the authenticated host.

Add WEB-Based Local Account

Username	<input type="text" value="testguest"/>	
Password	<input type="password" value="....."/>	
Confirm Password	<input type="password" value="....."/>	
VLAN	<input checked="" type="checkbox"/> User Defined	
	<input type="text" value="1"/>	(1 - 4094)
Assigned Timer		
Reauthentication	<input checked="" type="checkbox"/> User Defined	
	<input type="text" value="3600"/>	Sec (300 - 2147483647)
Inactive	<input checked="" type="checkbox"/> User Defined	
	<input type="text" value="60"/>	Sec (60 - 65535)

- **Username** : Authenticating account user name.
- **Password** : Authenticating account password.
- **Confirm Password** : Confirm authenticating account password.
- **VLAN** : Assigned VLAN ID for the authenticated host.
- **Assigned Timer**:
 - **Timeout (Reauthentication)** : Assigned reauthentication period for the authenticated host.
 - **Timeout (Inactive)** : Assigned inactive timeout for the authenticated host.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

15.5.5 Sessions

Administrator can check all detail information of authentication sessions and allow user to select specific session to delete by clicking **“Clear ”** button.

Security → Authentication Manager → Sessions

- ✚ Status
- ✚ Network
- ✚ Port
- ✚ POE Setting
- ✚ VLAN
- ✚ MAC Address Table
- ✚ Spanning Tree
- ✚ ERPS
- ✚ Discovery
- ✚ DHCP
- ✚ Multicast
- ✚ IP Configuration
- **Security**
 - RADIUS
 - TACACS+
 - ♥ AAA
 - ♥ Management Access
 - ♥ Authentication Manager
 - Property
 - Port Setting
 - MAC-Based Local Account
 - WEB-Based Local Account
 - Sessions

Sessions Table

Showing entries Showing 0 to 0 of 0 entries

	Session ID	Port	MAC Address	Current Type	Status	VLAN
0 results found						

Sessions Table

Showing entries Showing 0 to 0 of 0 entries

	Session ID	Port	MAC Address	Current Type	Status	Operational Information				Authorized Information		
						VLAN	Session Time	Inactivated Time	Quiet Time	VLAN	Reauthentication Period	Inactive Timeout
0 results found.												

First Previous 1 Next Last

Field	Description
Session ID	Session ID is unique of each session
Port	Port name which the host located
MAC Address	Host MAC address
Current Type	Show current authenticating type <ul style="list-style-type: none"> • 802.1x: Use IEEE 802.1X to do authenticating • MAC-Based: Use MAC-Based authentication to do authenticating • WEB-Based: Use WEB-Based authentication to do authenticating

Status	<p>Show host authentication session status</p> <ul style="list-style-type: none"> • Disable: This session is ready to be deleted • Running: Authentication process is running • Authorized: Authentication is passed and getting network accessibility. • UnAuthorized: Authentication is not passed and not getting network accessibility. • Locked: Host is locked and do not allow to do authenticating until quiet period. • Guest: Host is in the guest VLAN.
Operationl	<ul style="list-style-type: none"> • VLAN: Shows host operational VLAN ID. • Session Time: In “Authorized” state, it shows total time after authorized. • Inactived: In “Authorized” state, it shows how long the host do not send any packet. • Quiet Time: In “Locked” state, it shows total time after locked. • Locked: Host is locked and do not allow to do authenticating until quiet period.
Authorized	<ul style="list-style-type: none"> • VLAN: Shows VLAN ID given from authorized procedure. • Reauthentication Period: Shows reauthentication period given from authorized procedure. • Inactive Timeouts: Shows inactive timeout given from authorized procedure.

Click the “**Clear**” button to clear this page or click the “**Refresh**” button to refresh the page .

15.6 Port Security

Port security examines all traffic received by secure ports to detect violations or to recognize and secure new MAC addresses. When the shutdown violation mode is configured, traffic cannot enter the secure port after a violation has been detected, which removes the possibility that violations might cause excessive CPU load.

Port security monitors received packets. Access to locked ports is limited to users with specific MAC addresses, This page allow user to configure port security settings for each interface. When port security is enabled on interface, action will be perform once MAC address over.

Security → Port Security

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security**
 - RADIUS
 - TACACS+
 - AAA
 - Management Access
 - Authentication Manager
 - Port Security
 - Protected Port
 - Storm Control
 - DoS
 - Dynamic ARP Inspection
 - DHCP Snooping
 - IP Source Guard

State ☒ Enable

Rate Limit Packet / Sec (1 - 600, default 100)

Apply

Port Security Table

	Entry	Port	State	Address Limit	Total	Configured	Violate Number	Violate Action	Sticky
<input type="checkbox"/>	1	GE1	Enabled	20	0	0	0	Protect	Enabled
<input type="checkbox"/>	2	GE2	Enabled	1	0	0	0	Protect	Disabled
<input type="checkbox"/>	3	GE3	Enabled	256	0	0	0	Restrict	Enabled
<input type="checkbox"/>	4	GE4	Disabled	1	0	0	0	Protect	Disabled
<input type="checkbox"/>	5	GE5	Disabled	1	0	0	0	Protect	Disabled
<input type="checkbox"/>	6	GE6	Disabled	1	0	0	0	Protect	Disabled
<input type="checkbox"/>	7	GE7	Disabled	1	0	0	0	Protect	Disabled
<input type="checkbox"/>	8	GE8	Disabled	1	0	0	0	Protect	Disabled
<input type="checkbox"/>	9	GE9	Disabled	1	0	0	0	Protect	Disabled
<input type="checkbox"/>	10	GE10	Disabled	1	0	0	0	Protect	Disabled
<input type="checkbox"/>	11	GE11	Disabled	1	0	0	0	Protect	Disabled

- **State:** Select the status of port security
 - **Disable:** Disable port security function.
 - **Enable:** Enable port security function.
- **Rate Limit :** Set rate limit of 1-600 packets per second.

Note	When the protect or restrict violation modes are configured, port security continues to process traffic after a violation occurs, which might cause excessive CPU load. Configure the port security rate limiter to protect the CPU against excessive load when the protect or restrict violation modes are configured.
-------------	---

Click the **"Apply"** button to save your changes settings.

Field	Description
Port	Port name which the port security.
State	Display port security of Enable or Disable state.
Address Limit	Displays the maximum number of port security of MAC addresses that can be configured on the port.
Total	Displays the number of all port security total MAC addresses on the port.

Configured	Displays the number of all port security MAC addresses configured on the port.
Violate Active	<p>Displays the operational state that the interface applies to packets arriving on the locked interface.</p> <ul style="list-style-type: none"> • Protect. • Restrict. • Shutdown.
Sticky	Display port security sticky of Enable or Disable.

Port	GE1-GE5
State	<input checked="" type="checkbox"/> Enable
Address Limit	<input type="text" value="1"/> (1 - 256, default 1)
Violate Action	<input checked="" type="radio"/> Protect <input type="radio"/> Restrict <input type="radio"/> Shutdown
Sticky	<input checked="" type="checkbox"/> Enable

Apply Close

- **Port:** Display selected Port number.
- **State:** Enable or Un-Enable the port security.
- **Address Limit:** When configuring port security, the maximum number of secure MAC addresses that can be configured in the switch, A secure port has a default of one MAC address. The default can be changed to any value between 1 and 256. The upper limit of 256 guarantees one MAC address per port.
- **Violate Action:** Select the action if learned mac addresses, If Interface Status is locked, select an action to be applied to packets arriving on a locked interface.
 - **Protect:** Drop packets with invalid MAC address.
 - **Restrict:** Drop packets with invalid MAC address and log the event.
 - **Shutdown:** Drop packets with invalid MAC address and shut down the interface of port, and log the event.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

15.7 Protected Port

This page allow user to configure protected port setting to prevent the selected ports from communication with each other. Protected port is only allowed to communicate with unprotected port. In other words, protected port is not allowed to communicate with another protected port. If administrators check enable to make this a protected port. A protected port is also referred as a Private VLAN Edge. It's provide Layer 2 isolation between interfaces (Ethernet ports and Link Aggregation Groups) that share the same Broadcast domain (VLAN). After enable protected port, packets received from protected ports can be forwarded only to unprotected egress ports and unrestricted by VLAN members.

Security → Protected Port

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security**
 - RADIUS
 - TACACS+
 - AAA
 - Management Access
 - Authentication Manager
 - Port Security
 - Protected Port

Protected Port Table

<input type="checkbox"/>	Entry	Port	State
<input type="checkbox"/>	1	GE1	Protected
<input type="checkbox"/>	2	GE2	Protected
<input type="checkbox"/>	3	GE3	Unprotected
<input type="checkbox"/>	4	GE4	Unprotected
<input type="checkbox"/>	5	GE5	Unprotected
<input type="checkbox"/>	6	GE6	Unprotected
<input type="checkbox"/>	7	GE7	Unprotected
<input type="checkbox"/>	8	GE8	Unprotected
<input type="checkbox"/>	9	GE9	Unprotected
<input type="checkbox"/>	10	GE10	Unprotected
<input type="checkbox"/>	11	GE11	Unprotected
<input type="checkbox"/>	12	GE12	Unprotected
<input type="checkbox"/>	13	GE13	Unprotected

Field	Description
Port	Port Name
State	Port protected admin state. <ul style="list-style-type: none"> Protected: Port is protected. Unprotected: Port is unprotected

Edit Protected Port

Port

GE1-GE2

State

☒ Protected

Apply

Close

- **Port:** Display selected Port number.
- **State:** Port protected admin state.
 - **Protected:** Enable protecting function.
 - **Unprotected (deselect):** Disable protecting function

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

15.8 Storm Control

When the rate of Broadcast / unknown Multicast or unknown Unicast frames is higher than the user-defined threshold, this function can to limit the number of frames entering the switch and to define the types of frames that are counted towards this limit. Will be the frames received beyond the threshold are discarded or the interface shuts down.

Security → Storm Control

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security**
 - RADIUS
 - TACACS+
 - AAA
 - Management Access
 - Authentication Manager
 - Port Security
 - Protected Port
 - Storm Control

Mode

☐ Packet / Sec
☒ Kbits / Sec

IFG

☒ Exclude
☐ Include

Apply

Port Setting Table

	Entry	Port	State	Broadcast		Unknown Multicast		Unknown Unicast		Action
				State	Rate (Kbps)	State	Rate (Kbps)	State	Rate (Kbps)	
<input type="checkbox"/>	1	GE1	Disabled	Disabled	10000	Disabled	10000	Disabled	10000	Drop
<input type="checkbox"/>	2	GE2	Enabled	Enabled	10000	Enabled	10000	Enabled	10000	Drop
<input type="checkbox"/>	3	GE3	Disabled	Disabled	10000	Disabled	10000	Disabled	10000	Drop
<input type="checkbox"/>	4	GE4	Disabled	Disabled	10000	Disabled	10000	Disabled	10000	Drop
<input type="checkbox"/>	5	GE5	Enabled	Enabled	10000	Disabled	10000	Disabled	10000	Drop
<input type="checkbox"/>	6	GE6	Disabled	Disabled	10000	Disabled	10000	Disabled	10000	Drop

- **Mode:** Select the unit of storm control.
 - **Packets/sec:** Select by Packets/second of the rate threshold.
 - **Kbits/sec:** Select by Kbits/second of the rate threshold.

- **IFG:** Select the rate calculates w/o preamble & IFG (20 bytes).
 - **Excluded:** exclude preamble & IFG (20 bytes) when count ingress storm control rate.
 - **Include:** include preamble & IFG (20 bytes) when count ingress storm control rate.

Click the **“Apply”** button to save your changes settings.

Field	Description
Port	Port name which the host located.
State	Display enable or disable the storm control function.
Broadcast	Show the storm control for the Broadcast packets. <ul style="list-style-type: none"> • State: Display enable or disable the storm control for broadcast packets. • Rate(Kpps): Displays the bandwidth threshold for broadcast packets.
Unknown Multicast	Show the storm control for the unknown Multicast packets. <ul style="list-style-type: none"> • State: Display enable or disable the storm control for unknown Multicast packets . • Rate(Kpps): Displays the bandwidth threshold for unknown Multicast packets.
Unknown Unicast	Show the storm control for the unknown Unicast packets. <ul style="list-style-type: none"> • State: Display enable or disable the storm control for unknown Unicast packets . • Rate(Kpps): Displays the bandwidth threshold for unknown Unicast packets.
Action	<ul style="list-style-type: none"> • Drop: Shows will Broadcast / unknown Multicast or unknown Unicast frames is higher than the user-defined threshold. • Shutdown: will Broadcast / unknown Multicast or unknown Unicast frames is higher than the user-defined threshold.

Edit Port Setting

Port	GE5,GE7	
State	<input checked="" type="checkbox"/> Enable	
Broadcast	<input checked="" type="checkbox"/> Enable	
	<input type="text" value="10000"/>	Kbps (16 - 1000000, default 10000)
Unknown Multicast	<input type="checkbox"/> Enable	
	<input type="text" value="10000"/>	Kbps (16 - 1000000, default 10000)
Unknown Unicast	<input type="checkbox"/> Enable	
	<input type="text" value="10000"/>	Kbps (16 - 1000000, default 10000)
Action	<input checked="" type="radio"/> Drop <input type="radio"/> Shutdown	

Apply
Close

- **Port:** Display selected Port number.
- **State:** Select the state of setting.
 - **Enable:** Enable the storm control function.
- **Broadcast:** If enable storm control for Broadcast traffic will count Broadcast traffic towards the bandwidth threshold.
 - **Enable:** Enable the storm control function of Broadcast packet, Value of storm control rate, Unit: Kbps (Kbits per-second, range16 - 1000000) depends on global mode setting.
- **Unknown Multicast:** If enable storm control for unknown Multicast will count unknown Multicast traffic towards the bandwidth threshold.
 - **Enable:** Enable the storm control function of Unknown Multicast packet, Value of storm control rate, Unit: Kbps (Kbits per-second, range16 - 1000000) depends on global mode setting.
- **Unknown Unicast:** If enable storm control for unknown Unicast will count unknown Unicast traffic towards the bandwidth threshold.
 - **Enable:** Enable the storm control function of Unknown Unicast packet, Value of storm control rate, Unit: Kbps (Kbits per-second, range16 - 1000000) depends on global mode setting.
- **Action:** Administrator can select Drop or Shutdown will Broadcast / unknown Multicast or unknown Unicast frames is higher than the user-defined threshold.
 - **Drop:** Received beyond the threshold will discard the frames, Packets exceed storm control rate will be dropped
 - **Shutdown:** Received beyond the threshold will shut down the port, Port will be shutdown when packets exceed storm control rate.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

15.9 DoS

DoS attack (denial-of-service) is a cyber-attack where the perpetrator seeks to make a machine or network resource unavailable to its intended users by temporarily or indefinitely disrupting services of a host connected to the Internet. Denial of service is typically accomplished by flooding the targeted machine or resource with superfluous requests in an attempt to overload systems and prevent some or all legitimate requests from being fulfilled.

15.9.1 Property

This default is enabled all DoS protection feature and SYN-FIN / SYN-RST protections. The default threshold is 60 SYN packets per second. The default period of port recovery is 60 seconds.

POD	<input checked="" type="checkbox"/> Enable
Land	<input checked="" type="checkbox"/> Enable
UDP Blat	<input checked="" type="checkbox"/> Enable
TCP Blat	<input checked="" type="checkbox"/> Enable
DMAC = SMAC	<input checked="" type="checkbox"/> Enable
Null Scan Attack	<input checked="" type="checkbox"/> Enable
X-Mas Scan Attack	<input checked="" type="checkbox"/> Enable
TCP SYN-FIN Attack	<input checked="" type="checkbox"/> Enable
TCP SYN-RST Attack	<input checked="" type="checkbox"/> Enable
ICMP Fragment	<input checked="" type="checkbox"/> Enable
TCP-SYN	<input checked="" type="checkbox"/> Enable Note: Source Port < 1024
TCP Fragment	<input checked="" type="checkbox"/> Enable Note: Offset = 1
Ping Max Size	<input checked="" type="checkbox"/> Enable IPv4 <input checked="" type="checkbox"/> Enable IPv6 <input type="text" value="512"/> Byte (0 - 65535, default 512)
TCP Min Hdr size	<input checked="" type="checkbox"/> Enable <input type="text" value="20"/> Byte (0 - 31, default 20)
IPv6 Min Fragment	<input checked="" type="checkbox"/> Enable <input type="text" value="1240"/> Byte (0 - 65535, default 1240)
Smurf Attack	<input checked="" type="checkbox"/> Enable <input type="text" value="0"/> Netmask Length (0 - 32, default 0)

Apply

- **POD:**
 - **Enable:** Enable the Dos attack of avoids ping of death attack function.
- **Land:**
 - **Enable:** Enable the Dos attack of drops the packets if the source IP address is equal to the destination IP address function.
- **UDP Blat:**
 - **Enable:** Enable the Dos attack of drops the packets if the UDP source port equals to the UDP destination port function.
- **TCP Blat:**
 - **Enable:** Enable the Dos attack of drops the packages if the TCP source port is equal to the TCP destination port function.
- **DMAC = SMAC:**
 - **Enable:** Enable the Dos attack of drops the packets if the destination MAC address is equal to the source MAC address function.
- **Null Scan Attack:**
 - **Enable:** Enable the Dos attack of drops the packets with NULL scan function.
- **X-Mas Scan Attack:**
 - **Enable:** Enable the Dos attack of drops the packets if the sequence number is zero, and the FIN, URG and PSH bits are set function.
- **TCP SYN-FIN Attack:**
 - **Enable:** Enable the Dos attack of drops the packets with SYN and FIN bits set function.
- **TCP SYN-RST Attack:**
 - **Enable:** Enable the Dos attack of drops the packets with SYN and RST bits set function.
- **ICMP Fragment:**
 - **Drop:** Enable the Dos attack of drops the fragmented ICMP packets function.
- **TCP- SYN (SPORT<1024):**
 - **Enable:** Enable the Dos attack of drops SYN packets with sport less than 1024 function.
- **TCP Fragment (Offset = 1):**
 - **Enable:** Enable the Dos attack of drops the TCP fragment packets with offset equals to one function.
- **Ping Max Size:**
 - **Enable:** Enable the Dos attack of specify the maximum size of the ICMPv4/ICMPv6 ping packets. The valid range is from 0 to 65535 bytes, and the default value is 512 bytes.
- **IPv4 Ping Max Size:**
 - **Enable:** Enable the Dos attack of checks the maximum size of ICMP ping packets, and drops the packets larger than the maximum packet size function.

- **IPv6 Ping Max Size:**
 - **Enable:** Enable the Dos attack of checks the maximum size of ICMPv6 ping packets, and drops the packets larger than the maximum packet size function.
- **TCP Min Hdr Size:**
 - **Enable:** Enable the Dos attack of checks the minimum TCP header and drops the TCP packets with the header smaller than the minimum size. The length range is from 0 to 31 bytes, and default length is 20 bytes function.
- **IPv6 Min Fragment:**
 - **Enable:** Enable the Dos attack of checks the minimum size of IPv6 fragments, and drops the packets smaller than the minimum size. The valid range is from 0 to 65535 bytes, and default value is 1240 bytes function.
- **Smurf Attack:**
 - **Enable:** Enable the Dos attack of avoids smurf attack. The length range of the netmask is from 0 to 323 bytes, and default length is 0 bytes function.

Click the **“Apply”** button to save your changes settings

15.9.2 Port Setting

Administrator can choose protected ports.

Security → DoS → Port Setting

- ✚ Status
- ✚ Network
- ✚ Port
- ✚ POE Setting
- ✚ VLAN
- ✚ MAC Address Table
- ✚ Spanning Tree
- ✚ ERPS
- ✚ Discovery
- ✚ DHCP
- ✚ Multicast
- ✚ IP Configuration
- **Security**
 - RADIUS
 - TACACS+
 - ✚ AAA
 - ✚ Management Access
 - ✚ Authentication Manager
 - Port Security
 - Protected Port
 - Storm Control
 - ✚ **DoS**
 - Property
 - Port Setting**

Port Setting Table

<input type="checkbox"/>	Entry	Port	State
<input type="checkbox"/>	1	GE1	Enabled
<input type="checkbox"/>	2	GE2	Enabled
<input type="checkbox"/>	3	GE3	Disabled
<input type="checkbox"/>	4	GE4	Disabled
<input type="checkbox"/>	5	GE5	Disabled
<input type="checkbox"/>	6	GE6	Disabled
<input type="checkbox"/>	7	GE7	Disabled
<input type="checkbox"/>	8	GE8	Disabled
<input type="checkbox"/>	9	GE9	Disabled
<input type="checkbox"/>	10	GE10	Disabled
<input type="checkbox"/>	11	GE11	Disabled
<input type="checkbox"/>	12	GE12	Disabled
<input type="checkbox"/>	13	GE13	Disabled
<input type="checkbox"/>	14	GE14	Disabled
<input type="checkbox"/>	15	GE15	Disabled
<input type="checkbox"/>	16	GE16	Disabled

Field	Description
Port	Interface of port number.
State	Display Enable/Disable the DoS protection on the interface.

Edit Port Setting

Port	GE1-GE2
State	<input checked="" type="checkbox"/> Enable

- **Port:** Display selected Port number.
- **State:** Select the state of setting.
 - **Enable:** Enable the DoS protection function.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

15.10 Dynamic ARP Inspection

Dynamic Address Resolution Protocol (ARP) is a TCP/IP protocol for translating IP addresses into MAC addresses. Use the Dynamic ARP Inspection pages to configure settings of Dynamic ARP Inspection.

15.10.1 Property

This page allow user to configure global and per interface settings of Dynamic ARP Inspection.

Security → Dynamic ARP Inspection → Property

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security**
 - RADIUS
 - TACACS+
 - AAA
 - Management Access
 - Authentication Manager
 - Port Security
 - Protected Port
 - Storm Control
 - DoS
 - Dynamic ARP Inspection
 - Property

State ☒ Enable

VLAN

Available VLAN

Selected VLAN

VLAN 1

Apply

Port Setting Table

	Entry	Port	Trust	Source MAC Address	Destination MAC Address	IP Address	Rate Limit
<input type="checkbox"/>	1	GE1	Enabled	Enabled	Enabled	Enabled	50
<input type="checkbox"/>	2	GE2	Enabled	Enabled	Enabled	Enabled	50
<input type="checkbox"/>	3	GE3	Enabled	Enabled	Enabled	Enabled	50
<input type="checkbox"/>	4	GE4	Disabled	Disabled	Disabled	Disabled	Unlimited
<input type="checkbox"/>	5	GE5	Disabled	Disabled	Disabled	Disabled	Unlimited

- **State:** Administrator can enable or disable this Dynamic ARP Inspection. Set checkbox to enable/disable Dynamic ARP Inspection function.
- **VLAN:** In the Enabled VLAN table, users assign static ARP Inspection lists to enabled VLANs. When a packet passes through an untrusted interface that is enabled for ARP Inspection switch will performs the checks, Select VLANs in left box then move to right to enable Dynamic ARP Inspection. Or select VLANs in right box then move to left to disable Dynamic ARP Inspection.

Click the **“Apply”** button to save your changes settings

Field	Description
Port	Port the port ID.
Trust	Display enable/disabled trust attribute of interface.
Source MAC Address	Display enable/disabled source mac address validation attribute of interface.
Destination MAC Address	Display enable/disabled destination mac address validation attribute of interface.

IP Address	Display enable/disabled IP address validation attribute of interface, Allow zero which means allow 0.0.0.0 IP address.
Rate Limit	Display rate limitation value of interface.

Edit Port Setting	
Port	GE1-GE3
Trust	<input checked="" type="checkbox"/> Enable
Source MAC Address	<input checked="" type="checkbox"/> Enable
Destination MAC Address	<input checked="" type="checkbox"/> Enable
IP Address	<input checked="" type="checkbox"/> Enable <input type="checkbox"/> Allow Zero (0.0.0.0)
Rate Limit	50 pps (1 - 50, default 0), 0 is Unlimited

Apply Close

- **Port:** Display selected Port number.
- **Trust:** If enabled, the port or LAG is a trusted interface, and ARP inspection is not performed on the ARP requests or replies sent to or from the interface. If Un-Enable, the port or LAG is not a trusted interface, and ARP inspection is performed on the ARP requests or replies sent to or from the interface. By default, it is disabled.
- **Source MAC Address:** Check Enable to validate the source MAC addresses in ARP requests and replies, Set checkbox to enable or disable source mac address validation of interface. All ARP packets will be checked whether sender mac is same as source mac in Ethernet header if enable source mac address validation. Default is disabled.
- **Destination MAC Address:** Check Enable to validate the destination MAC addresses in ARP replies, Set checkbox to enable or disable destination mac address validation of interface. All ARP packets will be checked whether target mac is same as destination mac in Ethernet header if enable destination mac address validation. Default is disabled.
- **IP Address:** Set checkbox to enable or disable IP address validation of interface. All ARP packets will be checked whether IP address is 0.0.0.0, 255.255.255.255 or multicast address. Default is disabled.
 - **Allow all-zeros IP:** If IP address validation is enabled, check Enable to allow 0.0.0.0 the IP address.
- **Rate Limit:** Enter the maximum rate that is allowed on the interface. The range is 1 to 50pps and the default is 0 Unlimited.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

15.10.2 Statistics

The Statistics page will displays the statistical information for ARP Inspection.

Security → Dynamic ARP Inspection → Statistics									
<ul style="list-style-type: none"> Status Network Port POE Setting VLAN MAC Address Table Spanning Tree ERPS Discovery DHCP Multicast IP Configuration Security <ul style="list-style-type: none"> RADIUS TACACS+ AAA Management Access Authentication Manager Port Security Protected Port Storm Control DoS Dynamic ARP Inspection <ul style="list-style-type: none"> Property Statistics 	Statistics Table								
	<input type="text"/>								
	<input type="checkbox"/>	Entry	Port	Forward	Source MAC Failure	Destination MAC Failure	Source IP Validation Failure	Destination IP Validation Failure	IP-MAC Mismatch Failure
	<input type="checkbox"/>	1	GE1	0	0	0	0	0	0
	<input type="checkbox"/>	2	GE2	0	0	0	0	0	0
	<input type="checkbox"/>	3	GE3	0	0	0	0	0	0
	<input type="checkbox"/>	4	GE4	0	0	0	0	0	0
	<input type="checkbox"/>	5	GE5	0	0	0	0	0	0
	<input type="checkbox"/>	6	GE6	0	0	0	0	0	0
	<input type="checkbox"/>	7	GE7	0	0	0	0	0	0
	<input type="checkbox"/>	8	GE8	0	0	0	0	0	0
	<input type="checkbox"/>	9	GE9	0	0	0	0	0	0
	<input type="checkbox"/>	10	GE10	0	0	0	0	0	0
	<input type="checkbox"/>	11	GE11	0	0	0	0	0	0
	<input type="checkbox"/>	12	GE12	0	0	0	0	0	0
	<input type="checkbox"/>	13	GE13	0	0	0	0	0	0
	<input type="checkbox"/>	14	GE14	0	0	0	0	0	0
	<input type="checkbox"/>	15	GE15	0	0	0	0	0	0
	<input type="checkbox"/>	16	GE16	0	0	0	0	0	0

Field	Description
Port	Interface of port number.
Forward	Display how many packets forwarded normally.
Source MAC Failure	Display how many packets dropped by source MAC validation.
Destination MAC Failure	Display how many packets dropped by destination MAC validation.
Source IP Address Validation Failures	Display how many packets dropped by source IP validation.
Destination IP Address Validation Failures	Display how many packets dropped by destination IP validation.
IP-MAC Mismatch Failures	Display how many packets dropped by IP-MAC doesn't match in IP Source Guard binding table.

15.11 DHCP Snooping

Administrator can use DHCP snooping to help avoid the Denial of Service attacks that result from unauthorized users adding a DHCP server to the network that then provides invalid configuration data to other DHCP clients on the network. DHCP packets received on other switch ports are inspected before being forwarded. Packets from untrusted sources are dropped.

15.11.1 Property

This page allow user to configure global and per interface settings of DHCP Snooping.

Security → DHCP Snooping → Property

- ▼ Status
- ▼ Network
- ▼ Port
- ▼ POE Setting
- ▼ VLAN
- ▼ MAC Address Table
- ▼ Spanning Tree
- ▼ ERPS
- ▼ Discovery
- ▼ DHCP
- ▼ Multicast
- ▼ IP Configuration
- ▼ **Security**
 - RADIUS
 - TACACS+
 - AAA
 - Management Access
 - Authentication Manager
 - Port Security
 - Protected Port
 - Storm Control
 - DoS
 - Dynamic ARP Inspection
 - DHCP Snooping
 - Property

State ☒ Enable

VLAN

Available VLAN

VLAN 1

Selected VLAN

Apply

Port Setting Table

Entry	Port	Trust	Verify Chaddr	Rate Limit
<input type="checkbox"/> 1	GE1	Enabled	Enabled	45
<input type="checkbox"/> 2	GE2	Enabled	Enabled	45
<input type="checkbox"/> 3	GE3	Enabled	Enabled	45
<input type="checkbox"/> 4	GE4	Disabled	Disabled	Unlimited
<input type="checkbox"/> 5	GE5	Disabled	Disabled	Unlimited
<input type="checkbox"/> 6	GE6	Disabled	Disabled	Unlimited

- **State:** Administrator can enable or Un-Enable DHCP Snooping, Set checkbox to enable/disable DHCP Snooping function.
- **VLAN:** Administrator can to enable DHCP Snooping on a VLAN, ensure that DHCP Snooping is globally enabled on the switch, Select VLANs in left box then move to right to enable DHCP Snooping. Or select VLANs in right box then move to left to disable DHCP Snooping.

Click the **"Apply"** button to save your changes settings.

Field	Description
Port	Interface of port number.
Trust	Display enable/disabled trust attribute of interface.
Verify Chaddr	Display enable/disabled chaddr validation attribute of interface.
Rate Limit	Display rate limitation value of interface.

Edit Port Setting

Port	GE1-GE3	
Trust	<input checked="" type="checkbox"/>	Enable
Verify Chaddr	<input checked="" type="checkbox"/>	Enable
Rate Limit	45	pps (1 - 300, default 0), 0 is Unlimited

Apply
Close

- **Port:** Display selected Port number.
- **Trust:** If check Enable will connected to a DHCP server or to other switches or routers as trusted ports, Set checkbox to enable/disabled trust of interface. All DHCP packet will be forward directly if enable trust. Default is disabled
- **Verify Chaddr:** Set checkbox to enable or disable chaddr validation of interface. All DHCP packets will be checked whether client hardware mac address is same as source mac in Ethernet header if enable chaddr validation. Default is disabled.
- **Rate Limit:** Enter the maximum rate that is allowed on the interface. The range is 1 to 300pps and the default is 0 Unlimited.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

15.11.2 Statistics

This page allow user to browse all statistics that recorded by DHCP snooping function.

Security → DHCP Snooping → Statistics

✚ Status
✚ Network
✚ Port
✚ POE Setting
✚ VLAN
✚ MAC Address Table
✚ Spanning Tree
✚ ERPS
✚ Discovery
✚ DHCP
✚ Multicast
✚ IP Configuration
– Security
RADIUS
TACACS+
AAA
Management Access
Authentication Manager
Port Security
Protected Port
Storm Control
DoS
Dynamic ARP Inspection
DHCP Snooping
Property
Statistics

Statistics Table

<input type="checkbox"/>	Entry	Port	Forward	Chaddr Check Drop	Untrust Port Drop	Untrust Port with Option82 Drop	Invalid Drop
<input type="checkbox"/>	1	GE1	0	0	0	0	0
<input type="checkbox"/>	2	GE2	0	0	0	0	0
<input type="checkbox"/>	3	GE3	0	0	0	0	0
<input type="checkbox"/>	4	GE4	0	0	0	0	0
<input type="checkbox"/>	5	GE5	0	0	0	0	0
<input type="checkbox"/>	6	GE6	0	0	0	0	0
<input type="checkbox"/>	7	GE7	0	0	0	0	0
<input type="checkbox"/>	8	GE8	0	0	0	0	0
<input type="checkbox"/>	9	GE9	0	0	0	0	0
<input type="checkbox"/>	10	GE10	0	0	0	0	0
<input type="checkbox"/>	11	GE11	0	0	0	0	0
<input type="checkbox"/>	12	GE12	0	0	0	0	0
<input type="checkbox"/>	13	GE13	0	0	0	0	0
<input type="checkbox"/>	14	GE14	0	0	0	0	0
<input type="checkbox"/>	15	GE15	0	0	0	0	0
<input type="checkbox"/>	16	GE16	0	0	0	0	0

Field	Description
Port	Interface of port number.
Forward	Display how many packets forwarded normally.
Chaddr Check Drop	Display how many packets dropped by chaddr validation.
Untrusted Port Drop	Display how many DHCP server packets that are received by untrusted port dropped.
Untrusted Port with Option82 Drop	Display how many packets dropped by untrusted port with option82 checking.
Invalid Drop	Display how many packets dropped by invalid checking.

15.11.3 Option82 Property

This page allow user to set string of DHCP option82 remote ID filed. The string will attach in option82 if option inserted.

Security → DHCP Snooping → Option82 Property

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security**
 - RADIUS
 - TACACS+
 - AAA
 - Management Access
 - Authentication Manager
 - Port Security
 - Protected Port
 - Storm Control
 - DoS
 - Dynamic ARP Inspection
 - DHCP Snooping
 - Property
 - Statistics
 - Option82 Property

☐ User Defined

Remote ID

Operational Status

Remote ID 8c:4d:ea:30:dd:53 (Switch Mac in Byte Order)

Apply

Port Setting Table

	Entry	Port	State	Allow Untrust
<input type="checkbox"/>	1	GE1	Disabled	Drop
<input type="checkbox"/>	2	GE2	Disabled	Drop
<input type="checkbox"/>	3	GE3	Disabled	Drop
<input type="checkbox"/>	4	GE4	Disabled	Drop
<input type="checkbox"/>	5	GE5	Disabled	Drop
<input type="checkbox"/>	6	GE6	Disabled	Drop
<input type="checkbox"/>	7	GE7	Disabled	Drop
<input type="checkbox"/>	8	GE8	Disabled	Drop
<input type="checkbox"/>	9	GE9	Disabled	Drop
<input type="checkbox"/>	10	GE10	Disabled	Drop

- **Remote ID:** If Option 82 is enabled, select User Defined to manually enter the format remote ID, Set checkbox to enable user-defined remote-ID. By default, remote ID is switch mac in byte order.
- Input user-defined remote ID. Only available when enable user-define remote ID.

Field	Description
Operational Status	Display remote ID information.

Click the **"Apply"** button to save your changes settings.

Field	Description
Port	Interface of port number.
State	Set checkbox to enable/disable option82 function of interface.
Allow untrusted	Display allow untrusted action of interface.

Edit Port Setting

Port	GE1
State	<input checked="" type="checkbox"/> Enable
Allow Untrust	<input type="radio"/> Keep <input checked="" type="radio"/> Drop <input type="radio"/> Replace

Apply
Close

- **Port:** Display selected Port number.
- **State:** Check Enable or Un-Enable, Display option82 enable/disable status of interface.
- **Allow untrusted:** Select the action perform when untrusted port receive DHCP packet has option82 filed. Default is drop.
 - **Keep:** Keep original option82 content.
 - **Drop:** Drop packets with option82.
 - **Replace:** Replace option82 content by switch setting.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

15.11.4 Option82 Circuit ID

Administrator can use the Option82 Port CID Settings page to configure the Option 82 circuit-ID Setting **“add”** and **“Edit”** and **“Delete”** function management, This page allow user to set string of DHCP option82 circuit ID filed. The string will attach in option82 if option inserted.

Security → DHCP Snooping → Option82 Circuit ID

- ✚ Status
- ✚ Network
- ✚ Port
- ✚ POE Setting
- ✚ VLAN
- ✚ MAC Address Table
- ✚ Spanning Tree
- ✚ ERPS
- ✚ Discovery
- ✚ DHCP
- ✚ Multicast
- ✚ IP Configuration
- Security**
 - RADIUS
 - TACACS+
 - AAA
 - Management Access
 - Authentication Manager
 - Port Security
 - Protected Port
 - Storm Control
 - DoS
 - Dynamic ARP Inspection
 - DHCP Snooping
 - Property
 - Statistics
 - Option82 Property
 - Option82 Circuit ID**

Option82 Circuit ID Table

Showing All entries Showing 0 to 0 of 0 entries

<input type="checkbox"/>	Port	VLAN	Circuit ID
0 results found.			

Field	Description
Port	Display port ID of entry.
VLAN	Display associate VLAN of entry.
Circuit ID	Display circuit ID string of entry.

Add Option82 Circuit ID

Port	<input type="text" value="GE1"/>
VLAN	<input type="text"/> (1 - 4094) (Keep empty to set without VLAN)
Circuit ID	<input type="text"/>

- **Port:** Select port from list to associate to CID entry. Only available on Add dialog.
- **VLAN:** Input VLAN ID to associate to circuit ID entry. VLAN ID is not mandatory. Only available on Add dialog.
- **Circuit ID:** Input String as circuit ID. Packets match port and VLAN will be inserted circuit ID.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

15.12 IP Source Guard

IP Source Guard restricts the client IP traffic to those source IP addresses configured in the IP Source binding database, mainly can prevent traffic attacks caused when a host tries to use the IP address of its neighbor.

15.12.1 Port Setting

This page allow user to configure per port settings of IP Source Guard.

Security → IP Source Guard → Port Setting

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security**
 - RADIUS
 - TACACS+
 - AAA
 - Management Access
 - Authentication Manager
 - Port Security
 - Protected Port
 - Storm Control
 - DoS
 - Dynamic ARP Inspection
 - DHCP Snooping
 - IP Source Guard
 - Port Setting
 - IMPV Binding
 - Save Database

Port Setting Table

<input type="checkbox"/>	Entry	Port	State	Verify Source	Current Entry	Max Entry
<input type="checkbox"/>	1	GE1	Disabled	IP	0	Unlimited
<input type="checkbox"/>	2	GE2	Enabled	IP-MAC	0	Unlimited
<input type="checkbox"/>	3	GE3	Disabled	IP	0	Unlimited
<input type="checkbox"/>	4	GE4	Disabled	IP	0	Unlimited
<input type="checkbox"/>	5	GE5	Disabled	IP	0	Unlimited
<input type="checkbox"/>	6	GE6	Enabled	IP-MAC	0	Unlimited
<input type="checkbox"/>	7	GE7	Enabled	IP-MAC	0	Unlimited
<input type="checkbox"/>	8	GE8	Disabled	IP	0	Unlimited
<input type="checkbox"/>	9	GE9	Disabled	IP	0	Unlimited
<input type="checkbox"/>	10	GE10	Disabled	IP	0	Unlimited
<input type="checkbox"/>	11	GE11	Disabled	IP	0	Unlimited
<input type="checkbox"/>	12	GE12	Disabled	IP	0	Unlimited
<input type="checkbox"/>	13	GE13	Disabled	IP	0	Unlimited
<input type="checkbox"/>	14	GE14	Disabled	IP	0	Unlimited
<input type="checkbox"/>	15	GE15	Disabled	IP	0	Unlimited
<input type="checkbox"/>	16	GE16	Disabled	IP	0	Unlimited
<input type="checkbox"/>	17	GE17	Disabled	IP	0	Unlimited
<input type="checkbox"/>	18	GE18	Disabled	IP	0	Unlimited
<input type="checkbox"/>	19	GE19	Disabled	IP	0	Unlimited
<input type="checkbox"/>	20	GE20	Disabled	IP	0	Unlimited

Field	Description
Port	Interface of port number.
State	Display IP Source Guard enable/disable status of interface.
Verify Source	Display mode of IP Source Guard verification.
Current Binding Entry	Display current binding entries of a interface.
Max Binding Entry	Display the number of maximum binding entry of interface.

Edit Port Setting

Port	GE2,GE6-GE7	
State	<input checked="" type="checkbox"/> Enable	
Verify Source	<input type="radio"/> IP <input checked="" type="radio"/> IP-MAC	
Max Entry	<input type="text" value="0"/>	(1 - 50, default 0), 0 is Unlimited

- **Port:** Display selected Port number.
- **State:** Check Enable or Un-Enable this IP Source Guard. Mainly restricts the client IP traffic to those source IP addresses configured. Check Enable to enable IP Source Guard on the interface. Administrator can disable this feature, Default is disabled.
- **Verify Source:** Administrator can select IP only or MAC and IP type of source traffic to be verified.
 - **IP:** Only verify source IP address of packet.
 - **IP-MAC:** Verify source IP and source MAC address of packet
- **Max Entry:** Administrator need enter the maximum number of IP source binding rules. The range is 0 to 50, and 0 is Unlimited.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

15.12.2 IMPV Binding

Use the Binding to query and view information about inactive addresses recorded in the IP Source Guard database, This page allow user to add static IP source guard entry and browse all IP source guard entries that learned by DHCP snooping or statically create by user, Setting “add” and “Edit” and “Delete” for this function management.

Security → IP Source Guard → IMPV Binding

IP-MAC-Port-VLAN Binding Table

Showing **All** entries Showing 1 to 1 of 1 entries

	Port	VLAN	MAC Address	IP Address	Binding	Type	Lease Time
<input type="checkbox"/>	GE1	4094	8C:4D:EA:FE:05:A9	192.168.2.55 / 255.255.255.255	IP-MAC-Port-VLAN	Static	N/A

Add Edit Delete First Previous 1 Next L

Field	Description
Port	Display port ID of entry.
VLAN	Display VLAN ID of entry.
MAC Address	Display MAC address of entry. Only available of IP-MAC binding entry.
IP Address	Display IP address of entry. Mask always to be 255.255.255.255 for IP-MAC binding. IP binding entry display user input
Binding	Display binding type of entry.
Status	Type of existing binding entry: <ul style="list-style-type: none"> Static : Entry added by user manually configured. Dynamic : Entry learned by DHCP snooping.

Lease Time

Lease time of DHCP Snooping learned entry. After lease time entry will be deleted. Only available of dynamic entry.

Add IP-MAC-Port-VLAN Binding

Port	GE1 ▾
VLAN	4094 (1 - 4094)
Binding	<input checked="" type="radio"/> IP-MAC-Port-VLAN <input type="radio"/> IP-Port-VLAN
MAC Address	8C:4D:EA:FE:05:A9
IP Address	192.168.2.55 / 255.255.255.255

- **Port:** Administrator can select port from list of a binding entry.
- **VLAN:** Specify a VLAN ID of a binding entry.
- **Binding:** Administrator can select matching mode of binding entry.
 - **IP-MAC-Port-VLAN:** packet must match IP address 、 MAC address 、 Port and VLAN ID.
 - **IP-Port-VLAN:** packet must match IP address or subnet 、 Port and VLAN ID.
- **MAC Address:** Input MAC address. Only available on IP-MAC-Port-VLAN mode.
- **IP Address:** Input IP address and mask. Mask only available on IP-MAC-Port mode.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

15.12.3 Save Databases

This page allow user to configure DHCP snooping database which can backup and restore dynamic DHCP snooping entries

Security → IP Source Guard → Save Database

Type	<input checked="" type="radio"/> None <input type="radio"/> Flash <input type="radio"/> TFTP
Filename	<input type="text"/>
Address Type	<input checked="" type="radio"/> Hostname <input type="radio"/> IPv4
Server Address	<input type="text"/>
Write Delay	<input type="text" value="300"/> Sec (15 - 86400, default 300)
Timeout	<input type="text" value="300"/> Sec (0 - 86400, default 300)

- **Type:** Administrator can select the type of database agent.
 - **None:** Disable database agent service.
 - **Flash:** Save DHCP dynamic binding entries to flash.
 - **TFTP:** Save DHCP dynamic binding entries to remote TFTP server.
- **Filename:** Set file name of TFTP server, Input filename for backup file. Only available when selecting type “flash” and “TFTP”.
- **Address Type:** Select use Host name or IP address to connection TFTP server.
 - **Hostname:** TFTP server address is hostname.
 - **IPv4:** TFTP server address is IPv4 address.
- **Server Address:** Input remote TFTP server hostname or IP address. Only available when selecting type “TFTP”.
- **Write Delay:** Input delay timer for doing backup after change happened. Default is 300 seconds.
- **Timeout:** Input aborts timeout for doing backup failure. Default is 300 seconds.

Click the “**Apply**” button to save your changes settings.

16. ACL

ACL (Access Control List) is an ordered list of classification filters and actions. Each single classification rule, together with its action, is called an Access Control Element (ACE). Each ACE is made up of filters that distinguish traffic groups and associated actions. A single ACL may contain one or more ACEs, which are matched against the contents of incoming frames. Either a DENY or PERMIT action is applied to frames whose contents match the filter.

Note When a packet matches an ACE filter, the ACE action is taken and that ACL processing is stopped. If the packet does not match the ACE filter, the next ACE is processed. If all ACEs of an ACL have been processed without finding a match, and if another ACL exists, it is processed in a similar manner.

If no match is found to any ACE in all relevant ACLs then ACL default action will dropped the packet.

16.1 MAC ACL

This page mainly creates MAC ACLs profile. The MAC ACLs are used to filter traffic based on Layer 2 fields and defined on the MAC ACE page.

This page allow user to add or delete ACL rule. A rule cannot be deleted if under binding.

Note A port can be either secured with ACLs or configured with advanced QoS policy, but not both.

ACL → MAC ACL

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL**
 - MAC ACL
 - MAC ACE
 - IPv4 ACL
 - IPv4 ACE
 - IPv6 ACL
 - IPv6 ACE
 - ACL Binding

ACL Name

Apply

ACL Table

Showing All entries
Showing 1 to 1 of 1 entries

<input type="checkbox"/>	ACL Name	Rule	Port
<input checked="" type="checkbox"/>	testACL	0	

First Previous 1 Next Last

Delete

- **ACL Name:** Create a name of ACL.

Click the **“Apply”** button to save your changes settings.

Field	Description
ACL Name	Display MAC ACL name.
Rule	Display the number ACE rule of ACL..
Port	L Display the port list that bind this ACL.

Click the **“Delete”** button to delete ACL table list.

16.2 MAC ACE

MAC ACE will check all frames for a match. Setting **“add”** and **“Edit”** and **“Delete”** for this function management, This page allow user to add, edit or delete ACE rule. An ACE rule cannot be edited or deleted if ACL under binding. New ACE cannot be added if ACL under binding .

ACL → MAC ACE

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
 - MAC ACL
 - MAC ACE

ACE Table

ACL Name

Showing entries Showing 1 to 1 of 1 entries

	Sequence	Action	Source MAC		Destination MAC		Ethertype	VLAN	802.1p	
			Address	Mask	Address	Mask			Value	Mask
<input type="checkbox"/>	2	Permit	Any	Any	Any	Any	Any	Any	Any	Any

- **ACL Name:** Select the ACL name to which an ACE is being added.

Field	Description
Sequence	Display the sequence of ACE.
Action	Display the action of ACE
Source MAC	Display the source MAC address and mask of ACE.
Destination MAC	Display the destination MAC address and mask of ACE.
Ethertype	Display the Ethernet frame type of ACE.
VLAN ID	Display the VLAN ID of ACE
802.1p Value	Display the 802.1p value of ACE.
802.1p Mask	Display the 802.1p mask of ACE.

Add ACE

ACL Name	testACL	
Sequence	2	(1 - 2147483647)
Action	<input checked="" type="radio"/> Permit <input type="radio"/> Deny <input type="radio"/> Shutdown	
Source MAC	<input checked="" type="checkbox"/> Any <input type="text"/> / <input type="text"/> (Address / Mask)	
Destination MAC	<input checked="" type="checkbox"/> Any <input type="text"/> / <input type="text"/> (Address / Mask)	
Ethertype	<input checked="" type="checkbox"/> Any 0x <input type="text"/> (0x600 ~ 0xFFFF)	
VLAN	<input checked="" type="checkbox"/> Any <input type="text"/> (1 - 4094)	
802.1p	<input checked="" type="checkbox"/> Any <input type="text"/> / <input type="text"/> (Value / Mask) (0 - 7)	

Apply
Close

- **ACL Name:** Display the ACL name to which an ACE is being added.

- **Sequence:** ACEs with higher sequence are processed first (1 is the highest priority). Only available on Add Dialog.
- **Action:** Administrator can select the action after ACE match packet.
 - **Permit:** Forward packets that meet the ACE criteria.
 - **Deny:** Drop packets that meet the ACE criteria.
 - **Shutdown:** Drop packets that meet the ACE criteria, and disable the port from where the packets were received. Such ports can be reactivated from the Port Settings page.
- **Source MAC:** Select the type for source MAC address.
 - **Any:** All source addresses are acceptable.
 - **User Defined:** Only a source address or a range of source addresses which users define are acceptable. Enter the source MAC address and mask to which will be matched.
- **Destination MAC:** Destination MAC Select the type for Destination MAC address.
 - **Any:** All destination addresses are acceptable.
 - **User Defined:** Only a destination address or a range of destination addresses which users define are acceptable. Enter the destination MAC address and mask to which will be matched.

Note	Set F is show value, 0 is mask value, E.g. If an MAC is 8C:4D:EA:11:22:33 the mask value FF:FF:FF:00:00:00 indicates that only the first three bytes of the destination MAC address are used(8C:4D:EA).
-------------	---

- **Ethertype:** Select the type for Ethernet frame type.
 - **Any:** All Ethernet frame type is acceptable.
 - **User Defined:** Only an Ethernet frame type which users define is acceptable. Enter the Ethernet frame type value to which will be matched.
- **VLAN ID:** Select the type for VLAN ID.
 - **Any:** All VLAN ID is acceptable.
 - **User Defined:** User Defined: Only a VLAN ID which users define is acceptable. Enter the VLAN ID to which will be matched.
- **802.1p:** Select the type for 802.1p value.
 - **Any:** All 802.1p value is acceptable.
 - **User Defined:** User Defined: Only an 802.1p value or a range of 802.1p value which users define is acceptable. Enter the 802.1p value and mask to which will be matched.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

16.3 IPv4 ACL

Mainly creates IPv4 ACLs profile. The IPv4 ACLs are used to check IPv4 packets, This page allow user to add or delete Ipv4 ACL rule. A rule cannot be deleted if under binding.

ACL → IPv4 ACL

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL**
 - MAC ACL
 - MAC ACE
 - IPv4 ACL

ACL Name

Apply

ACL Table

Showing **All** entries Showing 1 to 1 of 1 entries

<input type="checkbox"/>	ACL Name	Rule	Port
<input checked="" type="checkbox"/>	test	0	

Delete **First** **Previous**

➤ **ACL Name:** Create a name of ACL.


Click the **“Apply”** button to save your changes settings.

Field	Description
ACL Name	Display IPv4 ACL name
Rule	Display the number ACE rule of ACL
Port	Display the port list that bind this ACL


Click the **“Delete”** button to delete the table list.

16.4 IPv4 ACE

This page allow user to add, edit or delete ACE rule. An ACE rule cannot be edited or deleted if ACL under binding. New ACE cannot be added if ACL under binding, Setting **“add”** and **“Edit”** and **“Delete”** for this function management.



➤ **ACL Name:** Select the ACL name to which an ACE is being added.



Field	Description
Sequence	Display the sequence of ACE.
Action	Display the action of ACE.
Protocol	Display the protocol value of ACE.
Source IP	Display the source IP address and mask of ACE: <ul style="list-style-type: none">• Address: Display for the IPv4 IP address.• Mask : Display for the Mask address.

Destination IP	<p>Display the destination IP address and mask of ACE:</p> <ul style="list-style-type: none"> • Address: Display for the IPv4 IP address. • Mask : Display for the Mask address.
Source Port	Display single source port or a range of source ports of ACE. Only available when protocol is TCP or UDP.
Destination Port	Display single destination port or a range of destination ports of ACE. Only available when protocol is TCP or UDP.
TCP Flags	Display the TCP flag value if ACE. Only available when protocol is TCP.
Type of Service	Display the ToS value of ACE which could be DSCP or IP Precedence.
ICMP	Display the ICMP type and code of ACE. Only available when protocol is ICMP.

Add ACE

ACL Name	test	
Sequence	<input type="text"/> (1 - 2147483647)	
Action	<input checked="" type="radio"/> Permit <input type="radio"/> Deny <input type="radio"/> Shutdown	
Protocol	<input checked="" type="radio"/> Any <input type="radio"/> Select <input type="text" value="ICMP"/> <input type="button" value="v"/> <input type="radio"/> Define <input type="text"/> (0 - 255)	
Source IP	<input checked="" type="checkbox"/> Any <input type="text"/> / <input type="text"/> (Address / Mask)	
Destination IP	<input checked="" type="checkbox"/> Any <input type="text"/> / <input type="text"/> (Address / Mask)	
Type of Service	<input checked="" type="radio"/> Any <input type="radio"/> DSCP <input type="text"/> (0 - 63) <input type="radio"/> IP Precedence <input type="text"/> (0 - 7)	

- **ACL Name:** Display the ACL name to which an ACE is being added.
- **Sequence:** Specify the sequence of the ACE ,ACEs with higher sequence are processed first (1 is the highest priority). Only available on Add Dialog.

- **Action:** Administrator can select the action for a match.
 - **Permit:** Forward packets that meet the ACE criteria.
 - **Deny:** Drop packets that meet the ACE criteria.
 - **Shutdown:** Drop packets that meet the ACE criteria, and disable the port from where the packets were received. Such ports can be reactivated from the Port Settings page.
- **Protocol:** Administrator can select the type of protocol for a match.
 - **Any (IP):** All IP protocols are acceptable.
 - **Select from list:** Select one of the following protocols from the drop-down list.
(ICMP/IPinIP/TCP/EGP/IGP/UDP/HMP/RDP/IPV6/IPV6:ROUT/IPV6:FRAG/
RSVP/IPV6:ICMP/OSPF/PIM/L2TP)
 - **Protocol ID to match:** Enter the protocol ID.
- **Source IP:** Select the type for source IP address.
 - **Any:** All source addresses are acceptable.
 - **User Defined:** Only a source address or a range of source addresses which users define are acceptable. Enter the source IP address value and mask to which will be matched.
- **Destination IP:** Select the type for destination IP address..
 - **Any:** All destination addresses are acceptable.
 - **User Defined:** Only a destination address or a range of destination addresses which users define are acceptable. Enter the destination IP address value and mask to which will be matched.
- **Type of Service:** Select the type of service for a match.
 - **Any:** All types of service are acceptable.
 - **DSCP to match:** Enter a Differentiated Services Code Point (DSCP) to match.
 - **IP Precedence to match:** Enter a IP Precedence to match.

Source Port	<input checked="" type="radio"/> Any
	<input type="radio"/> Single <input type="text"/> (0 - 65535)
	<input type="radio"/> Range <input type="text"/> - <input type="text"/> (0 - 65535)
Destination Port	<input checked="" type="radio"/> Any
	<input type="radio"/> Single <input type="text"/> (0 - 65535)
	<input type="radio"/> Range <input type="text"/> - <input type="text"/> (0 - 65535)
TCP Flags	Urg: <input type="radio"/> Set <input type="radio"/> Unset <input checked="" type="radio"/> Don't care
	Ack: <input type="radio"/> Set <input type="radio"/> Unset <input checked="" type="radio"/> Don't care
	Psh: <input type="radio"/> Set <input type="radio"/> Unset <input checked="" type="radio"/> Don't care
	Rst: <input type="radio"/> Set <input type="radio"/> Unset <input checked="" type="radio"/> Don't care
	Syn: <input type="radio"/> Set <input type="radio"/> Unset <input checked="" type="radio"/> Don't care
	Fin: <input type="radio"/> Set <input type="radio"/> Unset <input checked="" type="radio"/> Don't care
ICMP Type	<input checked="" type="radio"/> Any
	<input type="radio"/> Select <input type="text" value="Echo Reply"/>
	<input type="radio"/> Define <input type="text"/> (0 - 255)
ICMP Code	<input checked="" type="radio"/> Any
	<input type="radio"/> Define <input type="text"/> (0 - 255)
<input type="button" value="Apply"/> <input type="button" value="Close"/>	

- **Source Port:** Select the type of protocol for a match. Only available when protocol is TCP or UDP.
 - **Any:** All source ports are acceptable.
 - **Single:** Enter a single TCP/UDP source port to which packets are matched.
 - **Range:** Select a range of TCP/UDP source ports to which the packet is matched. There are eight different port ranges that can be configured (shared between source and destination ports). TCP and UDP protocols each have eight port ranges.
- **Destination Port:** Select the type of protocol for a match. Only available when protocol is TCP or UDP.
 - **Any:** All source ports are acceptable.
 - **Single:** Enter a single TCP/UDP source port to which packets are matched.
 - **Range:** Select a range of TCP/UDP destination ports to which the packet is matched. There are eight different port ranges that can be configured (shared between source and destination ports). TCP and UDP protocols each have eight port ranges.
- **TCP Flags:** Select one or more TCP flags with which to filter packets. Filtered packets are either forwarded or dropped. Filtering packets by TCP flags increases packet control, which increases network security. Only available when protocol is TCP.

- **Set:** Match if the flag is SET.
- **Unset:** Match if the flag is Not SET.
- **Don't care:** Ignore the TCP flag.
- **ICMP Type:** Either select the message type by name or enter the message type number. Only available when protocol is ICMP.
 - **Any:** All message types are acceptable.
 - **Select from list:** Select message type by name.
 - **Protocol ID to match:** Enter the number of message type.
- **ICMP Code:** Select the type for ICMP code. Only available when protocol is ICMP.
 - **Any:** All codes are acceptable.
 - **User Defined:** Enter an ICMP code to match.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

16.5 IPv6 ACL

Mainly creates IPv6 ACLs profile. The IPv6 ACLs are used to check IPv6 packets, This page allow user to add or delete Ipv6 ACL rule. A rule cannot be deleted if under binding.

- **ACL Name:** Create a name of ACL.

Click the **“Apply”** button to save your changes settings.

Field	Description
ACL Name	Display IPv6 ACL name
Rule	Display the number ACE rule of ACL
Port	Display the port list that bind this ACL

Click the **“Delete”** button to delete the table list.

16.6 IPv6 ACE

This page allow user to add, edit or delete ACE rule. An ACE rule cannot be edited or deleted if ACL under binding. New ACE cannot be added if ACL under binding, Setting **“add”** and **“Edit”** and **“Delete”** for this function management.

ACL → IPv6 ACE

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL**
 - MAC ACL
 - MAC ACE
 - IPv4 ACL
 - IPv4 ACE
 - IPv6 ACL
 - IPv6 ACE

ACE Table

ACL Name None ▾

Showing All ▾ entries Showing 0 to 0 of 0

	Sequence	Action	Protocol	Source IP		Destination IP	
				Address	Prefix	Address	Prefix

- **ACL Name:** Select the ACL name to which an ACE is being added.

ACE Table

ACL Name

None

Showing

All

 entries

Showing 0 to 0 of 0 entries

Sequence	Action	Protocol	Source IP		Destination IP		Source Port	Destination Port	TCP Flags	Type of Service		ICMP	
			Address	Prefix	Address	Prefix				DSCP	IP Precedence	Type	Code
0 results found.													

First

Previous

Field	Description
Sequence	Display the sequence of ACE.
Action	Display the action of ACE.
Protocol	Display the protocol value of ACE.
Source IP	Display the source IP address and mask of ACE: <ul style="list-style-type: none"> Address: Display for the IPv4 IP address. Mask : Display for the Mask address.
Destination IP	Display the destination IP address and mask of ACE: <ul style="list-style-type: none"> Address: Display for the IPv4 IP address. Mask : Display for the Mask address.
Source Port	Display single source port or a range of source ports of ACE. Only available when protocol is TCP or UDP.
Destination Port	Display single destination port or a range of destination ports of ACE. Only available when protocol is TCP or UDP.
TCP Flags	Display the TCP flag value if ACE. Only available when protocol is TCP.
Type of Service	Display the ToS value of ACE which could be DSCP or IP Precedence.
ICMP	Display the ICMP type and code of ACE. Only available when protocol is ICMP.

Add ACE

ACL Name	test1122	
Sequence	<input type="text"/> (1 - 2147483647)	
Action	<input checked="" type="radio"/> Permit <input type="radio"/> Deny <input type="radio"/> Shutdown	
Protocol	<input checked="" type="radio"/> Any <input type="radio"/> Select <input type="text" value="TCP"/> <input type="button" value="v"/> <input type="radio"/> Define <input type="text"/> (0 - 255)	
Source IP	<input checked="" type="checkbox"/> Any <input type="text"/> / <input type="text"/> (Address / Prefix (0 - 128))	
Destination IP	<input checked="" type="checkbox"/> Any <input type="text"/> / <input type="text"/> (Address / Prefix (0 - 128))	
Type of Service	<input checked="" type="radio"/> Any <input type="radio"/> DSCP <input type="text"/> (0 - 63) <input type="radio"/> IP Precedence <input type="text"/> (0 - 7)	

- **ACL Name:** Display the ACL name to which an ACE is being added.
- **Sequence:** Specify the sequence of the ACE ,ACEs with higher sequence are processed first (1 is the highest priority). Only available on Add Dialog.
- **Action:** Administrator can select the action for a match.
 - **Permit:** Forward packets that meet the ACE criteria.
 - **Deny:** Drop packets that meet the ACE criteria.
 - **Shutdown:** Drop packets that meet the ACE criteria, and disable the port from where the packets were received. Such ports can be reactivated from the Port Settings page.
- **Protocol:** Administrator can select the type of protocol for a match.
 - **Any (IP):** All IP protocols are acceptable.
 - **Select from list:** Select one of the following protocols from the drop-down list.
(ICMP/IPinIP/TCP/EGP/IGP/UDP/HMP/RDP/IPV6/IPV6:ROUT/IPV6:FRAG/
RSVP/IPV6:ICMP/OSPF/PIM/L2TP)
 - **Protocol ID to match:** Enter the protocol ID.
- **Source IP:** Select the type for source IP address.
 - **Any:** All source addresses are acceptable.
 - **User Defined:** Only a source address or a range of source addresses which users define are acceptable. Enter the source IP address value and mask to which will be matched.

- **Destination IP:** Select the type for destination IP address..
 - **Any:** All destination addresses are acceptable.
 - **User Defined:** Only a destination address or a range of destination addresses which users define are acceptable. Enter the destination IP address value and prefix to which will be matched.
- **Type of Service:** Select the type of service for a match.
 - **Any:** All types of service are acceptable.
 - **DSCP to match:** Enter a Differentiated Services Code Point (DSCP) to match.
 - **IP Precedence to match:** Enter a IP Precedence to match.

Source Port	<input checked="" type="radio"/> Any
	<input type="radio"/> Single <input type="text" value=""/> (0 - 65535)
	<input type="radio"/> Range <input type="text" value=""/> - <input type="text" value=""/> (0 - 65535)
Destination Port	<input checked="" type="radio"/> Any
	<input type="radio"/> Single <input type="text" value=""/> (0 - 65535)
	<input type="radio"/> Range <input type="text" value=""/> - <input type="text" value=""/> (0 - 65535)
TCP Flags	Urg: <input type="radio"/> Set <input type="radio"/> Unset <input checked="" type="radio"/> Don't care
	Ack: <input type="radio"/> Set <input type="radio"/> Unset <input checked="" type="radio"/> Don't care
	Psh: <input type="radio"/> Set <input type="radio"/> Unset <input checked="" type="radio"/> Don't care
	Rst: <input type="radio"/> Set <input type="radio"/> Unset <input checked="" type="radio"/> Don't care
	Syn: <input type="radio"/> Set <input type="radio"/> Unset <input checked="" type="radio"/> Don't care
	Fin: <input type="radio"/> Set <input type="radio"/> Unset <input checked="" type="radio"/> Don't care
ICMP Type	<input checked="" type="radio"/> Any
	<input type="radio"/> Select <input type="text" value="Destination Unreachable"/>
ICMP Code	<input type="radio"/> Define <input type="text" value=""/> (0 - 255)
	<input checked="" type="radio"/> Any
<input type="button" value="Apply"/> <input type="button" value="Close"/>	

- **Source Port:** Select the type of protocol for a match. Only available when protocol is TCP or UDP.
 - **Any:** All source ports are acceptable.
 - **Single:** Enter a single TCP/UDP source port to which packets are matched.
 - **Range:** Select a range of TCP/UDP source ports to which the packet is matched. There are eight different port ranges that can be configured (shared between source and destination ports). TCP and UDP protocols each have eight port ranges.
- **Destination Port:** Select the type of protocol for a match. Only available when protocol is TCP or UDP.

- **Any:** All source ports are acceptable.
- **Single:** Enter a single TCP/UDP source port to which packets are matched.
- **Range:** Select a range of TCP/UDP destination ports to which the packet is matched. There are eight different port ranges that can be configured (shared between source and destination ports). TCP and UDP protocols each have eight port ranges.
- **TCP Flags:** Select one or more TCP flags with which to filter packets. Filtered packets are either forwarded or dropped. Filtering packets by TCP flags increases packet control, which increases network security. Only available when protocol is TCP.
 - **Set:** Match if the flag is SET.
 - **Unset:** Match if the flag is Not SET.
 - **Don't care:** Ignore the TCP flag.
- **ICMP Type:** Either select the message type by name or enter the message type number. Only available when protocol is ICMP.
 - **Any:** All message types are acceptable.
 - **Select from list:** Select message type by name.
 - **Protocol ID to match:** Enter the number of message type.
- **ICMP Code:** Select the type for ICMP code. Only available when protocol is ICMP.
 - **Any:** All codes are acceptable.
 - **User Defined:** Enter an ICMP code to match.

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

16.7 ACL Binding

This page allow user to bind or unbind ACL rule to or from interface. IPv4 and Ipv6 ACL cannot be bound to the same port simultaneously , Administrator can from ACL Binding Table to select ports. When an ACL is bound to an interface, its ACE rules are applied to packets arriving at that interface. Packets that do not match any of the ACEs in the ACL are matched to a default rule, whose action is to drop unmatched packets.

ACL → ACL Binding

✦ Status
✦ Network
✦ Port
✦ POE Setting
✦ VLAN
✦ MAC Address Table
✦ Spanning Tree
✦ ERPS
✦ Discovery
✦ DHCP
✦ Multicast
✦ IP Configuration
✦ Security
– ACL
MAC ACL
MAC ACE
IPv4 ACL
IPv4 ACE
IPv6 ACL
IPv6 ACE
ACL Binding

ACL Binding Table

<input type="checkbox"/>	Entry	Port	MAC ACL	IPv4 ACL	IPv6 ACL
<input type="checkbox"/>	1	GE1	testACL		
<input type="checkbox"/>	2	GE2	testACL		
<input type="checkbox"/>	3	GE3	testACL		
<input type="checkbox"/>	4	GE4			
<input type="checkbox"/>	5	GE5			
<input type="checkbox"/>	6	GE6			
<input type="checkbox"/>	7	GE7			
<input type="checkbox"/>	8	GE8			
<input type="checkbox"/>	9	GE9			
<input type="checkbox"/>	10	GE10			
<input type="checkbox"/>	11	GE11			
<input type="checkbox"/>	12	GE12			
<input type="checkbox"/>	13	GE13			
<input type="checkbox"/>	14	GE14			

Field	Description
Port	Display port entry ID.
MAC ACL	Display mac ACL name that bound of interface. Empty means no rule bound.
IPv4 ACL	Display ipv4 ACL name that bound of interface. Empty means no rule bound.
IPv6 ACL	Display ipv6 ACL name that bound of interface. Empty means no rule bound.

Add ACL Binding

Port	GE1-GE3 <small>Note: ACL without any rules cannot be bound</small>
MAC ACL	testACL ▼
IPv4 ACL	None ▼
IPv6 ACL	None ▼

Apply
Close

- **Port:** Displays selected Port number.
- **MAC ACL:** MAC ACLs that are bound to the interface, Select mac ACL name from list to bind.
- **IPv4 ACL:** IPv4 ACLs that are bound to the interface, Select IPv4 ACL name from list to bind.
- **IPv6 ACL:** IPv6 ACLs that are bound to the interface, Select IPv6 ACL name from list to bind.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

17. QoS

The quality of service (QoS) feature is applied throughout the network to ensure that network traffic is prioritized according to required criteria and the desired traffic receives preferential treatment.

17.1 Property

The QoS feature is used to optimize network performance, Use the QoS general pages to configure settings for general purpose

QoS → General → Property

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS**
 - General
 - Property**
 - Queue Scheduling
 - CoS Mapping
 - DSCP Mapping
 - IP Precedence Mapping
 - Rate Limit
- Diagnostics
- Management

State ☒ Enable

Trust Mode

- ☐ CoS
- ☐ DSCP
- ☒ CoS-DSCP
- ☐ IP Precedence

Apply

Port Setting Table

	Entry	Port	CoS	Trust	Remarking		
					CoS	DSCP	IP Precedence
<input type="checkbox"/>	1	GE1	5	Enabled	Enabled	Enabled	Disabled
<input type="checkbox"/>	2	GE2	5	Enabled	Enabled	Enabled	Disabled
<input type="checkbox"/>	3	GE3	0	Enabled	Disabled	Disabled	Disabled
<input type="checkbox"/>	4	GE4	0	Enabled	Disabled	Disabled	Disabled
<input type="checkbox"/>	5	GE5	0	Enabled	Disabled	Disabled	Disabled
<input type="checkbox"/>	6	GE6	0	Enabled	Disabled	Disabled	Disabled
<input type="checkbox"/>	7	GE7	0	Enabled	Disabled	Disabled	Disabled
<input type="checkbox"/>	8	GE8	0	Enabled	Disabled	Disabled	Disabled
<input type="checkbox"/>	9	GE9	0	Enabled	Disabled	Disabled	Disabled

- **State:** Administrator can enable or disable this QoS Feature.
- **Trust Mode:** Administrator can select CoS / DSCP / CoS-DSCP and IP Precedence mode.
 - **CoS:** Traffic is mapped to queues based on the CoS field in the VLAN tag, or based on the per-port default CoS value (if there is no VLAN tag on the incoming packet), the actual mapping of the CoS to queue can be configured on port setting dialog.
 - **DSCP:** All IP traffic is mapped to queues based on the DSCP field in the IP header. The actual mapping of the DSCP to queue can be configured on the DSCP mapping page. If traffic is not IP traffic, it is mapped to the best effort queue..
 - **CoS-DSCP:** Select to use Trust CoS mode for non-IP traffic and Trust DSCP mode for IP traffic.
 - **IP Precedence:** Traffic is mapped to queues based on the IP precedence. The actual mapping of the IP precedence to queue can be configured on the IP Precedence mapping page.

Click the **"Apply"** button to save your changes settings.

Field	Description
Port	Interface of port name.
CoS	Port default CoS priority value for the selected ports.
Trust	Port trust state: <ul style="list-style-type: none"> • Enabled: Traffic will follow trust mode in global setting. • Disabled: Traffic will always use best efforts.
Remarking (CoS)	Remarking (CoS) Port CoS remarking admin state: <ul style="list-style-type: none"> • Enabled: CoS remarking is enabled. • Disabled: CoS remarking is disabled.
Remarking (DSCP)	Port DSCP remarking admin state: <ul style="list-style-type: none"> • Enabled: DSCP remarking is enabled. • Disabled: DSCP remarking is disabled.

Edit Port Setting

Port	GE1-GE2
CoS	5 (0 - 7)
Trust	<input checked="" type="checkbox"/> Enable

Remarking

CoS	<input checked="" type="checkbox"/> Enable
DSCP	<input checked="" type="checkbox"/> Enable
IP Precedence	<input type="checkbox"/> Enable

Apply
Close

- **Port:** Displays selected port number.
- **CoS:** Set default CoS/802.1p priority value for the selected ports, Set the default CoS value to be assigned for incoming packets (that do not have a VLAN tag). The range is 0 to 7.
- **Trust:** Set checkbox to enable/disable port trust state.
- **Remarking:**
 - **CoS:** Set checkbox to enable/disable port CoS remarking, Traffic is mapped to queues based on the VPT field in the VLAN tag, or based on the per-port default CoS value (if there is no VLAN tag on the incoming packet), the actual mapping of the VPT to queue can be configured on the CoS to Queue page.
 - **DSCP:** Set checkbox to enable/disable port DSCP remarking, All IP traffic is mapped to queues based on the DSCP field in the IP header. The actual mapping of the DSCP to queue

can be configured on the DSCP to Queue page. If traffic is not IP traffic, it is mapped to the best effort queue.

- **IP Precedence:** Set checkbox to enable/disable port IP Precedence remarking, Traffic is mapped to queues based on the IP precedence. The actual mapping of the IP precedence to queue can be configured on the IP Precedence to Queue page.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

17.2 Queue Scheduling

The switch supports eight queues for each interface. Queue number 8 is the highest priority queue. Queue number 1 is the lowest priority queue. There are two ways of determining how traffic in queues is handled, Strict Priority (SP) and Weighted Round Robin (WRR).

- Strict Priority (SP)—Egress traffic from the highest priority queue is transmitted first. Traffic from the lower queues is processed only after the highest queue has been transmitted, which provide the highest level of priority of traffic to the highest numbered queue.
- Weighted Round Robin (WRR)—In WRR mode the number of packets sent from the queue is proportional to the weight of the queue (the higher the weight, the more frames are sent).

The queuing modes can be selected on the Queue page. When the queuing mode is by Strict Priority, the priority sets the order in which queues are serviced, starting with queue_8 (the highest priority queue) and going to the next lower queue when each queue is completed.

When the queuing mode is Weighted Round Robin, queues are serviced until their quota has been used up and then another queue is serviced. It is also possible to assign some of the lower queues to WRR, while keeping some of the higher queues in Strict Priority. In this case traffic for the SP queues is always sent before traffic from the WRR queues. After the SP queues have been emptied, traffic from the WRR queues is forwarded. (The relative portion from each WRR queue depends on its weight).

QoS → General → Queue Scheduling

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS**
 - General
 - Property
 - Queue Scheduling

Queue Scheduling Table

Queue	Method				
	Strict Priority	WRR	Weight	WRR Bandwidth (%)	
1	<input type="radio"/>	<input checked="" type="radio"/>	1	33.33%	
2	<input type="radio"/>	<input checked="" type="radio"/>	2	66.67%	
3	<input checked="" type="radio"/>	<input type="radio"/>	3		
4	<input checked="" type="radio"/>	<input type="radio"/>	4		
5	<input checked="" type="radio"/>	<input type="radio"/>	5		
6	<input checked="" type="radio"/>	<input type="radio"/>	9		
7	<input checked="" type="radio"/>	<input type="radio"/>	13		
8	<input checked="" type="radio"/>	<input type="radio"/>	15		

Apply

Field	Description
Queue	Queue ID to configure
Strict Priority	Set queue to strict priority type
WRR	Set queue to Weight round robin type
Weight	If the queue type is WRR, set the queue weight for the queue.
WRR Bandwidth	Percentage of WRR queue bandwidth

Click the **“Apply”** button to save your changes settings.

17.3 CoS Mapping

The CoS to Queue table determines the egress queues of the incoming packets based on the 802.1p priority in their VLAN tags. For incoming untagged packets, the 802.1p priority will be the default CoS/802.1p priority assigned to the ingress ports. Use the Queues to CoS table to remark the CoS/802.1p priority for egress traffic from each queue.

QoS → General → CoS Mapping

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS**
 - General
 - Property
 - Queue Scheduling
 - CoS Mapping**
 - DSCP Mapping
 - IP Precedence Mapping
 - Rate Limit
- Diagnostics
- Management

CoS to Queue Mapping

CoS	Queue
0	2 ▼
1	1 ▼
2	3 ▼
3	4 ▼
4	5 ▼
5	6 ▼
6	7 ▼
7	8 ▼

Apply

Queue to CoS Mapping

Queue	CoS
1	1 ▼
2	0 ▼
3	2 ▼
4	3 ▼
5	4 ▼
6	5 ▼
7	6 ▼
8	7 ▼

Apply

CoS to Queue Mapping

- **CoS:** CoS value.
- **Queue:** Select queue id for the CoS value.

Click the **“Apply”** button to save your changes settings.

Queue to CoS Mapping

- **Queue:** Queue ID.
- **CoS:** Select CoS value for the queue id.

Click the **“Apply”** button to save your changes settings.

CoS (0 to 7) 7 is highest	Queue(1 to 8) 8 is highest priority	Description
0	2	Background
1	1	Best Effort
2	3	Excellent Effort
3	4	Critical Application LVS phone SIP
4	5	Video
5	6	Voice IP phone default
6	7	Interwork Control LVS phone RTP
7	8	Network Control

17.4 DSCP Mapping

The DSCP to Queue table determines the egress queues of the incoming IP packets based on their DSCP values. The original VLAN Priority Tag (VPT) of the packet is unchanged.

This DSCP values range from 0 through 63, whereas the internal forwarding priority values range from 1 through 8. Any DSCP value within a given range is mapped to the same internal forwarding priority value. These include the CS (Class Selector), AF (Assured Forwarding) and EF (Expedited Forwarding). For example, a packet with a DSCP tag value of 1 can be assigned to the High queue.

Use the Queues to DSCP page to remark DSCP value for egress traffic from each queue.

QoS → General → DSCP Mapping

▼ Status
▼ Network
▼ Port
▼ POE Setting
▼ VLAN
▼ MAC Address Table
▼ Spanning Tree
▼ ERPS
▼ Discovery
▼ DHCP
▼ Multicast
▼ IP Configuration
▼ Security
▼ ACL
▼ QoS
General
Property
Queue Scheduling
CoS Mapping
DSCP Mapping

DSCP to Queue Mapping

DSCP	Queue	DSCP	Queue	DSCP	Queue	DSCP	Queue
0 [CS0]	1 ▼	16 [CS2]	3 ▼	32 [CS4]	5 ▼	48 [CS6]	7 ▼
1	1 ▼	17	3 ▼	33	5 ▼	49	7 ▼
2	1 ▼	18 [AF21]	3 ▼	34 [AF41]	5 ▼	50	7 ▼
3	1 ▼	19	3 ▼	35	5 ▼	51	7 ▼
4	1 ▼	20 [AF22]	3 ▼	36 [AF42]	5 ▼	52	7 ▼
5	1 ▼	21	3 ▼	37	5 ▼	53	7 ▼
6	1 ▼	22 [AF23]	3 ▼	38 [AF43]	5 ▼	54	7 ▼
7	1 ▼	23	3 ▼	39	5 ▼	55	7 ▼
8 [CS1]	2 ▼	24 [CS3]	4 ▼	40 [CS5]	6 ▼	56 [CS7]	8 ▼
9	2 ▼	25	4 ▼	41	6 ▼	57	8 ▼
10 [AF11]	2 ▼	26 [AF31]	4 ▼	42	6 ▼	58	8 ▼
11	2 ▼	27	4 ▼	43	6 ▼	59	8 ▼
12 [AF12]	2 ▼	28 [AF32]	4 ▼	44	6 ▼	60	8 ▼
13	2 ▼	29	4 ▼	45	6 ▼	61	8 ▼
14 [AF13]	2 ▼	30 [AF33]	4 ▼	46 [EF]	6 ▼	62	8 ▼

DSCP to Queue Mapping

DSCP to Queue Mapping

DSCP	Queue	DSCP	Queue	DSCP	Queue	DSCP	Queue
0 [CS0]	1 ▼	16 [CS2]	3 ▼	32 [CS4]	5 ▼	48 [CS6]	7 ▼
1	1 ▼	17	3 ▼	33	5 ▼	49	7 ▼
2	1 ▼	18 [AF21]	3 ▼	34 [AF41]	5 ▼	50	7 ▼
3	1 ▼	19	3 ▼	35	5 ▼	51	7 ▼
4	1 ▼	20 [AF22]	3 ▼	36 [AF42]	5 ▼	52	7 ▼
5	1 ▼	21	3 ▼	37	5 ▼	53	7 ▼
6	1 ▼	22 [AF23]	3 ▼	38 [AF43]	5 ▼	54	7 ▼
7	1 ▼	23	3 ▼	39	5 ▼	55	7 ▼
8 [CS1]	2 ▼	24 [CS3]	4 ▼	40 [CS5]	6 ▼	56 [CS7]	8 ▼
9	2 ▼	25	4 ▼	41	6 ▼	57	8 ▼
10 [AF11]	2 ▼	26 [AF31]	4 ▼	42	6 ▼	58	8 ▼
11	2 ▼	27	4 ▼	43	6 ▼	59	8 ▼
12 [AF12]	2 ▼	28 [AF32]	4 ▼	44	6 ▼	60	8 ▼
13	2 ▼	29	4 ▼	45	6 ▼	61	8 ▼
14 [AF13]	2 ▼	30 [AF33]	4 ▼	46 [EF]	6 ▼	62	8 ▼
15	2 ▼	31	4 ▼	47	6 ▼	63	8 ▼

Apply

- **DSCP:** DSCP value.
- **Queue:** Select queue id for DSCP value.

Click the **“Apply”** button to save your changes settings.

Queue to DSCP Mapping

Queue to DSCP Mapping

Queue	DSCP
1	0 [CS0] ▼
2	8 [CS1] ▼
3	16 [CS2] ▼
4	24 [CS3] ▼
5	32 [CS4] ▼
6	40 [CS5] ▼
7	48 [CS6] ▼
8	56 [CS7] ▼

Apply

- **Queue:** DSCP value.
- **DSCP:** Select DSCP value for queue id.

Click the **“Apply”** button to save your changes settings.

17.5 IP Precedence to Queue Mapping

This page allow user to configure IP Precedence to Queue mapping and Queue to IP Precedence mapping , The IP Precedence standard uses the first 3 bits of the ToS byte to mark packets with 8 levels of priority, numbered 0-7, with 0 being the lowest priority and 7 the highest. Because IP Precedence and ToS use different bits in the ToS byte to mark the priority of a packet, they can co-exist in the same packet header without interfering with each other.

QoS → General → IP Precedence Mapping

Status

Network

Port

POE Setting

VLAN

MAC Address Table

Spanning Tree

ERPS

Discovery

DHCP

Multicast

IP Configuration

Security

ACL

QoS

General

Property

Queue Scheduling

CoS Mapping

DSCP Mapping

IP Precedence Mapping

Rate Limit

Diagnostics

Management

IP Precedence to Queue Mapping

IP Precedence	Queue
0	1 ▼
1	2 ▼
2	3 ▼
3	4 ▼
4	5 ▼
5	6 ▼
6	7 ▼
7	8 ▼

Apply

Queue to IP Precedence Mapping

Queue	IP Precedence
1	0 ▼
2	1 ▼
3	2 ▼
4	3 ▼
5	4 ▼
6	5 ▼
7	6 ▼
8	7 ▼

Apply

IP Precedence to Queue mapping

- **IP Precedence:** IP Precedence value.
- **Queue:** Queue value which IP Precedence is mapped.

Click the **"Apply"** button to save your changes settings.

Queue to IP Precedence mapping

- **Queue:** Queue ID.
- **IP Precedence:** IP Precedence value which queue is mapped.

Click the **"Apply"** button to save your changes settings.

17.6 Rate Limit

This page allow user to configure ingress port rate limit and egress port rate limit. The ingress rate limit is the number of bits per second that can be received from the ingress interface. Excess bandwidth above this limit is discarded.

17.6.1 Ingress / Egress Port

The rate limiting function can be configured to limit of Ingress/Egress traffic on a particular interface.

Administrator can set Ingress/Egress rate limiting in Ports. The usage rate is 16 to 10000000 Kbps

QoS → Rate Limit → Ingress / Egress Port

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS**
 - General
 - Property
 - Queue Scheduling
 - CoS Mapping
 - DSCP Mapping
 - IP Precedence Mapping
 - Rate Limit
 - Ingress / Egress Port**
 - Egress Queue

Ingress / Egress Port Table

	Entry	Port	Ingress		Egress	
			State	Rate (Kbps)	State	Rate (Kbps)
<input type="checkbox"/>	1	GE1	Enabled	102400	Enabled	102400
<input type="checkbox"/>	2	GE2	Enabled	102400	Enabled	102400
<input type="checkbox"/>	3	GE3	Disabled		Disabled	
<input type="checkbox"/>	4	GE4	Enabled	102400	Enabled	102400
<input type="checkbox"/>	5	GE5	Enabled	102400	Enabled	102400
<input type="checkbox"/>	6	GE6	Disabled		Disabled	
<input type="checkbox"/>	7	GE7	Disabled		Disabled	
<input type="checkbox"/>	8	GE8	Disabled		Disabled	
<input type="checkbox"/>	9	GE9	Disabled		Disabled	
<input type="checkbox"/>	10	GE10	Disabled		Disabled	
<input type="checkbox"/>	11	GE11	Disabled		Disabled	
<input type="checkbox"/>	12	GE12	Disabled		Disabled	
<input type="checkbox"/>	13	GE13	Disabled		Disabled	
<input type="checkbox"/>	14	GE14	Disabled		Disabled	
<input type="checkbox"/>	15	GE15	Disabled		Disabled	
<input type="checkbox"/>	16	GE16	Disabled		Disabled	

Field	Description
Port	Port name.
Trust	Port ingress rate limit state: <ul style="list-style-type: none"> Enabled: To enabled Ingress rate limit function. Disabled: To disabled the Ingress rate limit function.

Ingress (Rate)	Port ingress rate limit value if ingress rate state is enabled.
Ingress (Rate)	Port ingress rate limit value if ingress rate state is enabled.
IP Precedence	IP Precedence value which queue is mapped.
Trust	Port egress rate limit state: <ul style="list-style-type: none"> • Enabled: To enabled Egress rate limit function. • Disabled: To disabled Egress rate limit function.
Egress (Rate)	Port egress rate limit value if egress rate state is enabled.

Edit Ingress / Egress Port

Port	GE1-GE2,GE4-GE5	
Ingress	<input checked="" type="checkbox"/> Enable	
	<input type="text" value="102400"/>	Kbps (16 - 10000000)
Egress	<input checked="" type="checkbox"/> Enable	
	<input type="text" value="102400"/>	Kbps (16 - 10000000)

- **Port:** Select the checkbox for port list.
- **Ingress :** Set checkbox to enable/disable ingress rate limit. If ingress rate limit is enabled, rate limit value need to be assigned, The control Range is "16-10000000 Kbps".
- **Ingress :** Set checkbox to enable/disable egress rate limit. If egress rate limit is enabled, rate limit value need to be assigned, The control Range is "16-10000000 Kbps".
- **Ingress :** Set checkbox to enable/disable ingre

Click the **"Apply"** button to save your changes or **"Close"** the button to close settings.

17.6.2 Egress Queue

The Egress Queue function can be configured priority Queue by QoS. Egress rate limiting is performed by shaping the output load. Administrator can set Ingress Queue by limiting QoS . The usage rate is 16 to 1000000 Kbps, Please Click "Edit" button to set the Egress Queue Port menu.

QoS → Rate Limit → Egress Queue

✖ Status
✖ Network
✖ Port
✖ POE Setting
✖ VLAN
✖ MAC Address Table
✖ Spanning Tree
✖ ERPS
✖ Discovery
✖ DHCP
✖ Multicast
✖ IP Configuration
✖ Security
✖ ACL
– QoS
✖ General
✖ Property
✖ Queue Scheduling
✖ CoS Mapping
✖ DSCP Mapping
✖ IP Precedence Mapping
✖ Rate Limit
✖ Ingress / Egress Port
✖ Egress Queue

Egress Queue Table

■	Entry	Port	Queue 1		Queue 2		Queue 3		Queue 4	
			State	CIR (Kbps)	State	CIR (Kbps)	State	CIR (Kbps)	State	CIR (Kbps)
<input type="checkbox"/>	1	GE1	Enabled	51200	Enabled	51200	Enabled	62496	Disabled	
<input type="checkbox"/>	2	GE2	Enabled	51200	Enabled	51200	Enabled	62496	Disabled	
<input type="checkbox"/>	3	GE3	Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	4	GE4	Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	5	GE5	Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	6	GE6	Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	7	GE7	Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	8	GE8	Enabled	51200	Enabled	51200	Enabled	62496	Disabled	
<input type="checkbox"/>	9	GE9	Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	10	GE10	Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	11	GE11	Enabled	51200	Enabled	51200	Enabled	62496	Disabled	
<input type="checkbox"/>	12	GE12	Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	13	GE13	Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	14	GE14	Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	15	GE15	Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	16	GE16	Disabled		Disabled		Disabled		Disabled	

Egress Queue Table

■	Entry	Port	Queue 1		Queue 2		Queue 3		Queue 4		Queue 5		Queue 6		Queue 7		Queue 8	
			State	CIR (Kbps)	State	CIR (Kbps)	State	CIR (Kbps)	State	CIR (Kbps)	State	CIR (Kbps)	State	CIR (Kbps)	State	CIR (Kbps)	State	CIR (Kbps)
<input type="checkbox"/>	1	GE1	Enabled	51200	Enabled	51200	Enabled	62496	Disabled		Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	2	GE2	Enabled	51200	Enabled	51200	Enabled	62496	Disabled		Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	3	GE3	Disabled		Disabled		Disabled		Disabled		Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	4	GE4	Disabled		Disabled		Disabled		Disabled		Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	5	GE5	Disabled		Disabled		Disabled		Disabled		Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	6	GE6	Disabled		Disabled		Disabled		Disabled		Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	7	GE7	Disabled		Disabled		Disabled		Disabled		Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	8	GE8	Enabled	51200	Enabled	51200	Enabled	62496	Disabled		Disabled		Disabled		Disabled		Disabled	
<input type="checkbox"/>	9	GE9	Disabled		Disabled		Disabled		Disabled		Disabled		Disabled		Disabled		Disabled	

Field

Description

Port

Interface of port number.

Queue 1 (State)

Port egress queue 1 rate limit state

- **Enabled:** Egress queue rate limit is enabled.
- **Disabled:** Egress queue rate limit is disabled.

Queue 1 (CIR)

Queue 1 egress committed information rate.

Queue 2 (State)

Port egress queue 2 rate limit state.

- **Enabled:** Egress queue rate limit is enabled.
- **Disabled:** Egress queue rate limit is disabled.

Queue 2 (CIR)

Queue 2 egress committed information rate.

Queue 3 (State)	Port egress queue 3 rate limit state. <ul style="list-style-type: none"> • Enabled: Egress queue rate limit is enabled. • Disabled: Egress queue rate limit is disabled.
Queue 3 (CIR)	Queue 3 egress committed information rate.
Queue 4 (State)	Port egress queue 4 rate limit state. <ul style="list-style-type: none"> • Enabled: Egress queue rate limit is enabled. • Disabled: Egress queue rate limit is disabled.
Queue 4 (CIR)	Queue 4 egress committed information rate.
Queue 5 (State)	Port egress queue 5 rate limit state. <ul style="list-style-type: none"> • Enabled: Egress queue rate limit is enabled. • Disabled: Egress queue rate limit is disabled.
Queue 5 (CIR)	Queue 5 egress committed information rate.
Queue 6 (State)	Port egress queue 6 rate limit state. <ul style="list-style-type: none"> • Enabled: Egress queue rate limit is enabled. • Disabled: Egress queue rate limit is disabled.
Queue 6 (CIR)	Queue 6 egress committed information rate.
Queue 7 (State)	Port egress queue 7 rate limit state. <ul style="list-style-type: none"> • Enabled: Egress queue rate limit is enabled. • Disabled: Egress queue rate limit is disabled.

Edit Egress Queue

Port	GE1-GE2,GE8,GE11	
Queue 1	<input checked="" type="checkbox"/> Enable	<input type="text" value="51200"/> Kbps (16 - 10000000)
Queue 2	<input checked="" type="checkbox"/> Enable	<input type="text" value="51200"/> Kbps (16 - 10000000)
Queue 3	<input checked="" type="checkbox"/> Enable	<input type="text" value="1128000"/> Kbps (16 - 10000000)
Queue 4	<input type="checkbox"/> Enable	<input type="text" value="10000000"/> Kbps (16 - 10000000)
Queue 5	<input type="checkbox"/> Enable	<input type="text" value="10000000"/> Kbps (16 - 10000000)
Queue 6	<input type="checkbox"/> Enable	<input type="text" value="10000000"/> Kbps (16 - 10000000)
Queue 7	<input type="checkbox"/> Enable	<input type="text" value="10000000"/> Kbps (16 - 10000000)
Queue 8	<input type="checkbox"/> Enable	<input type="text" value="10000000"/> Kbps (16 - 10000000)

Apply Close

Set checkbox to enable/disable ingress priority queue 1 to~ queue 8 level , The control range is "16-1000000 Kbps"

- **Port:** Select one or multiple ports for the configure.
- **Queue 1:** Set checkbox to enable/disable egress queue 1 rate limit.
 - **Enable:** If egress rate limit is enabled, rate limit value need to be assigned.
- **Queue 2:** Set checkbox to enable/disable egress queue 2 rate limit.
 - **Enable:** If egress rate limit is enabled, rate limit value need to be assigned.
- **Queue 3:** Set checkbox to enable/disable egress queue 3 rate limit.
 - **Enable:** If egress rate limit is enabled, rate limit value need to be assigned.
- **Queue 4:** Set checkbox to enable/disable egress queue 4 rate limit.
 - **Enable:** If egress rate limit is enabled, rate limit value need to be assigned.
- **Queue 5:** Set checkbox to enable/disable egress queue 5 rate limit.
 - **Enable:** If egress rate limit is enabled, rate limit value need to be assigned.
- **Queue 6:** Set checkbox to enable/disable egress queue 6 rate limit.
 - **Enable:** If egress rate limit is enabled, rate limit value need to be assigned.
- **Queue 7:** Set checkbox to enable/disable egress queue 7 rate limit.
 - **Enable:** If egress rate limit is enabled, rate limit value need to be assigned.
- **Queue 8:** Set checkbox to enable/disable egress queue 8 rate limit.
 - **Enable:** If egress rate limit is enabled, rate limit value need to be assigned.

Click the "**Apply**" button to save your changes or "**Close**" the button to close settings.

18. Diagnostics

18.1 Logging

18.1.1 Property

This function support log message includes Console / RAM / Flash message send to remote log server. Administrator can enable or disable this function. Use the Diagnostics pages to configure settings for the switch diagnostics feature or operating diagnostic utilities.

Diagnostics → Logging → Property

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS
- Diagnostics**
 - Logging
 - Property**
 - Remote Server
 - Mirroring
 - Ping
 - Traceroute
 - Copper Test
 - Fiber Module
 - UDLD
- Management

State	<input checked="" type="checkbox"/> Enable
Aggregation	<input checked="" type="checkbox"/> Enable
Aging Time	300 Sec (15 - 3600, default 300)
Console Logging	
State	<input checked="" type="checkbox"/> Enable
Minimum Severity	Notice <small>Note: Emergency, Alert, Critical, Error, Warning, Notice</small>
RAM Logging	
State	<input checked="" type="checkbox"/> Enable
Minimum Severity	Notice <small>Note: Emergency, Alert, Critical, Error, Warning, Notice</small>
Flash Logging	
State	<input type="checkbox"/> Enable
Minimum Severity	Notice <small>Note: Emergency, Alert, Critical, Error, Warning, Notice</small>

- **State:** When the logging service is enabled, logging configuration of each destination rule can be individually configured. If the logging service is disabled, no messages will be sent to these destinations.
 - **Enable:** Enable/Disable the global logging services.
- **Aggregation:**
 - **Enable:** Enable/Disable the aggregation services.
 - **Aging:** 15~3600 Second. The default is 300 second.
- **Console Logging:**
 - **State:** Enable/Disable the Console Logging services.
 - **Minimum Severity:** The minimum severity for the Console Logging. Including selection of events such as Emergency, Alert, Critical, Error, Warning, Notice, Information, Debug, etc.
- **RAM Logging:**
 - **State:** Enable/Disable the RAM Logging services.
 - **Minimum Severity:** The minimum severity for the RAM logging. Including selection of events such as Emergency, Alert, Critical, Error, Warning, Notice, Information, Debug, etc.
- **Flash Logging:**
 - **State:** Enable/Disable the Flash Logging services.
 - **Minimum Severity:** The minimum severity for the flash logging. Including selection of events such as Emergency, Alert, Critical, Error, Warning, Notice, Information, Debug, etc.

Note

- Emergency—System is not usable.
- Alert—Action is needed.
- Critical—System is in a critical condition.
- Error—System is in error condition.
- Warning—System warning has occurred.
- Notice—System is functioning properly, but a system notice has occurred.
- Informational—Device information.
- Debug—Detailed information about an event.

Click the **“Apply”** button to save your changes settings.

18.1.2 Remote Server

Use the Remote Log Servers page to define the remote SYSLOG servers where log messages are sent (using the SYSLOG protocol). For each server, you can configure the severity of the messages that it receives, Setting **“add”** and **“Edit”** and **“Delete”** for this function management.

Diagnostics → Logging → Remote Server

▼ Status

▼ Network

▼ Port

▼ POE Setting

▼ VLAN

▼ MAC Address Table

▼ Spanning Tree

▼ ERPS

▼ Discovery

▼ DHCP

▼ Multicast

▼ IP Configuration

▼ Security

▼ ACL

▼ QoS

– Diagnostics

Logging

Property

Remote Server

Remote Server Table

<input type="checkbox"/>	Entry	Server Address	Server Port	Facility	Minimum Severity
<input type="checkbox"/>	1	192.168.2.99	514	Local 7	Notice
<input type="checkbox"/>	2	192.168.2.101	514	Local 7	Warning

Add

Edit

Delete

Field	Description
Server Address	The IP address of the remote logging server.
Server Ports	The port number of the remote logging server.
Facility	The facility of the logging messages. It can be one of the following values: local0, local1, local2, local3, local4, local5, local6, and l7.
Minimum Severity	<p>The minimum severity.</p> <ul style="list-style-type: none"> • Emergency: System is not usable. • Alert: Immediate action is needed. • Critical: System is in the critical condition. • Error: System is in error condition. • Warning: System warning has occurred. • Notice: System is functioning properly, but a system notice has occurred. • Informational: Device information. • Debug: Provides detailed information about an event.

Add Remote Server

Address Type	<input type="radio"/> Hostname <input checked="" type="radio"/> IPv4 <input type="radio"/> IPv6
Server Address	192.168.2.101
Server Port	514 (1 - 65535, default 514)
Facility	Local 7 ▼
Minimum Severity	Warning ▼

Note: Emergency, Alert, Critical, Error, Warning

Apply
Close

- **Address Type:** Administrator can select use Hostname or IPv4/6 connection remote log server.
- **Server Address:** Enter the IP address of the server.
- **Server Port:** Enter service port to which the log messages are sent.
- **Facility:** Select a facility from which system logs are sent to the remote server. Only one facility can be assigned to a server.
- **Minimum Severity:** Select the minimum level of system log messages to be sent to the server.

- **Emergence:** System is not usable.
- **Alert:** Immediate action is needed.
- **Critical:** System is in the critical condition.
- **Error:** System is in error condition.
- **Warning:** System warning has occurred.
- **Notice:** System is functioning properly, but a system notice has occurred.
- **Informational:** Device information.
- **Debug:** Provides detailed information about an event..

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

18.2 Mirroring

Mirroring function can mirror Rx/Tx traffic, Packet can mirror to destination port and for analysis.

Session ID	State	Monitor Port	Ingress Port	Egress Port
1	Disabled	---	---	---
2	Enabled	GE2 (Normal*)	GE3	GE3-GE4
3	Disabled	---	---	---
4	Disabled	---	---	---

Allow the monitor port to send or receive normal packets

Field	Description
Session ID	Select mirror session ID
State	Select mirror session state : port-base mirror or disable <ul style="list-style-type: none"> • Enabled: Enable port based mirror • Disabled: Disable mirror.

Monitor Port	Select mirror session monitor port, and select whether normal packet could be sent or received by monitor port.
Ingress port	Select mirror session source rx ports
Egress ports	Select mirror session source tx ports

Click the **“Edit”** button to edit your settings.

- **Session ID:** Display selected mirror session ID.
- **State:**
 - **Enable:** Enable/Disable the mirroring function.
- **Mirroring Port:** Administrator can choose a mirroring Port.
- **Ingress Port:** Administrator can choose mirrored ports for ingress.
- **Egress Port:** Administrator can choose mirrored ports for egress

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

18.3 Ping

The Ping utility tests if a remote host can be reached and measures the round-trip time for packets sent from the device to a destination device.

Ping operates by sending Internet Control Message Protocol (ICMP) echo request packets to the target host and waiting for an ICMP response, sometimes called a pong. It measures the round-trip time and records any packet loss. Administrators can use this ping function to check connected device whether is active. This ping function support IPv4 and IPv6 protocol.

Diagnostics → Ping

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS
- Diagnostics**
 - Logging
 - Mirroring
 - Ping**
 - Traceroute
 - Copper Test
 - Fiber Module
 - UDLD
- Management

Address Type
☒ Hostname
☐ IPv4
☐ IPv6

Server Address

Count
 (1 - 32)

Ping
Stop

Ping Result

Packet Status	
Status	Success.
Transmit Packet	4
Receive Packet	4
Packet Lost	0 %

Round Trip Time	
Min	0 ms
Max	10 ms
Average	2 ms

- **Address Type:** Specify the address type to “Hostname”, “IPv6”, or “IPv4”.
- **Server Address:** Specify the Hostname/IPv4/IPv6 address for the remote logging server.
- **Count:** Specify the numbers of each ICMP ping request.

Click the “**Ping**” button to ping result appears.

Field	Description
	Displays whether the ping succeeded or failed. <ul style="list-style-type: none"> • Status: Displays the ping result status of “Success” or “Ping failed (timeout)”.
Packet Status	<ul style="list-style-type: none"> • Transmit Packet: Number of packets sent by ping. • Receive Packet: Number of packets received by ping. • Packet Lost: Percentage of packets lost in ping process.
Round Trip Time	Displays the ping round trip time . <ul style="list-style-type: none"> • Min: Shortest time for packet to return. • Max: Longest time for packet to return. • Average: Average time for packet to return

18.4 Traceroute

Traceroute discovers the IP routes along which packets were forwarded by sending an IP packet to the target host and back to the switch. The Traceroute page displays each hop between the switch and a target host and the round-trip time to each hop.

Diagnostics → Traceroute

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS
- Diagnostics**
 - Logging
 - Mirroring
 - Ping
 - Traceroute
 - Copper Test
 - Fiber Module
 - UDLD
- Management

Address Type

☒ Hostname
☐ IPv4

Server Address

162.159.200.1

Time to Live

☒ User Defined

30 (2 - 255, default 30)

Apply

Stop

Traceroute Result

```

traceroute to 162.159.200.1 (162.159.200.1), 30 hops max, 38 byte packets
 1 192.168.101.254 (192.168.101.254) 0.000 ms 0.000 ms 0.000 ms
 2 60.248.167.254 (60.248.167.254) 10.000 ms 10.000 ms 10.000 ms
 3 168.95.82.206 (168.95.82.206) 0.000 ms 0.000 ms 10.000 ms
 4 220.128.2.226 (220.128.2.226) 0.000 ms 10.000 ms 0.000 ms
 5 220.128.1.125 (220.128.1.125) 10.000 ms 10.000 ms 10.000 ms
 6 203.75.230.125 (203.75.230.125) 10.000 ms 10.000 ms 10.000 ms
 7 162.159.200.1 (162.159.200.1) 10.000 ms 10.000 ms 10.000 ms
Trace complete
                
```

- **Address Type:** Specify the address type to “Hostname”, or “IPv4”.
- **Server Address:** Specify the Hostname/IPv4 address for the remote logging server.
- **Time to Live :** Enter the maximum number of hops that Traceroute permits. This is used to prevent a case where the sent frame gets into an endless loop. The Traceroute command terminates when the destination is reached or when this value is reached. To use the default value (30), select Use Default.

Click the **“Apply”** button to Traceroute result appears.

18.5 Copper Test

Administrator can use this function check port Result whether is working, if working then display it.

Cable Status	
Port	GE28
Result	Open Cable
Length	0.87 M

Field	Description
Port	Specify the interface for the copper test.

Click the **“Copper Test”** button to Copper Test result appears.

Cable Status

Field	Description
Port	The interface for the copper test.
Result	<p>The status of copper test. It include:</p> <ul style="list-style-type: none"> • OK: Correctly terminated pair. • Short Cable: Shorted pair. • Open Cable: Open pair, no link partner. • Impedance Mismatch: Terminating impedance is not in the reference range. • Line Drive:
Length	Distance in meter from the port to the location on the cable where the fault was discovered.

18.6 Fiber Module

Display Fiber module messenger. The Optical Module Status page displays the operational information reported by the Small Form-factor Pluggable (SFP) transceiver. Some information may not be available for SFPs without the supports of digital diagnostic monitoring standard SFF-8472.

Diagnostics → Fiber Module

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS
- Diagnostics**
 - Logging
 - Mirroring
 - Ping
 - Traceroute
 - Copper Test
 - Fiber Module

Fiber Module Table

Port	Temperature (C)	Voltage (V)	Current (mA)	Output Power (mW)	Input Power (mW)	OE Present	Loss of Signal
0 results found.							

Field	Description
Port	Interface or port number.
Temperature	Internally measured transceiver temperature.
Voltage	Internally measured supply voltage.
Current	Measured TX bias current.
Output Power	Measured TX output power in mill watts.
Input Power	Measured RX received power in mill watts.
Transmitter Fault	State of TX fault.
OE Present	Indicate transceiver has achieved power up and data is ready.
Loss of Signal	Loss of signal.
Refresh	Refresh the page.
Detail	The detail information on the specified port.

Click the “**Refresh**” button to refresh this page or click the “**Detail**” button to check detail information.

18.7 UDLD

Uni-Directional Link Detection (UDLD) monitors a link between two devices and brings the ports on both ends of the link down if the link goes down at any point between the two devices, Use the UDLD pages to configure settings of UDLD function.

18.7.1 Property

This page allow user to configure global and per interface settings of UDLD.

Diagnostics → UDLD → Property

Status

Network

Port

POE Setting

VLAN

MAC Address Table

Spanning Tree

ERPS

Discovery

DHCP

Multicast

IP Configuration

Security

ACL

QoS

– Diagnostics

Logging

Mirroring

Ping

Traceroute

Copper Test

Fiber Module

UDLD

Property

Neighbor

Management

Message Time

15

Sec (1 - 90, default 15)

Apply

Port Setting Table

	Entry	Port	Mode	Bidirectional State	Operational Status	Neighbor
<input type="checkbox"/>	1	GE1	Normal	Unknown	Link down	0
<input type="checkbox"/>	2	GE2	Normal	Unknown	Link down	0
<input type="checkbox"/>	3	GE3	Disabled	Unknown		0
<input type="checkbox"/>	4	GE4	Disabled	Unknown		0
<input type="checkbox"/>	5	GE5	Disabled	Unknown		0
<input type="checkbox"/>	6	GE6	Disabled	Unknown		0
<input type="checkbox"/>	7	GE7	Disabled	Unknown		0
<input type="checkbox"/>	8	GE8	Disabled	Unknown		0
<input type="checkbox"/>	9	GE9	Disabled	Unknown		0
<input type="checkbox"/>	10	GE10	Disabled	Unknown		0
<input type="checkbox"/>	11	GE11	Disabled	Unknown		0
<input type="checkbox"/>	12	GE12	Disabled	Unknown		0
<input type="checkbox"/>	13	GE13	Disabled	Unknown		0
<input type="checkbox"/>	14	GE14	Disabled	Unknown		0

- **Message Time:** To use the UDLD protocol all connected switches and interfaces have to be configured for it. A UDLD configured switch sends UDLD advertisements, "hello" packets to its neighbors and expects to receive one in the designated hold time (the default hold time is 15mins). If this doesn't happen the UDLD disables the unresponsive interface..

Click the **“Apply”** button to save your changes settings.

Field	Description
Port	Display port ID of entry.
Mode	Display UDLD running mode of interface.
Bidirectional State	Display bidirectional state of interface.
Operational Status	Display operational status of interface
Neighbor	Display the number of neighbor of interface

Edit Port Setting

Port	GE1-GE2
Mode	<input type="radio"/> Disabled <input checked="" type="radio"/> Normal <input type="radio"/> Aggressive

Apply Close

- **Port:** Select one or multiple ports for the configure.
- **Mode:** Select UDLD running mode of interface.
 - **Disabled:** Disable UDLD function.
 - **Normal:** Running on normal mode that port goes to Link Up One phase after last neighbor ages out.
 - **Aggressive:** Running on aggressive mode that port goes to Re-Establish phase after last neighbor ages out.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

18.7.2 Neighbor

Each switch port that is configured for UDLD exchanges UDLD protocol packets that include information about the port's device and port ID, and the port also sends the same device and port ID information that it knows about its connected neighbor.

Because of this, a port should receive its own device and port ID information from its neighbor if the link is bi-directional. If a port does not receive information about its own device and port ID from its neighbor, the link is considered to be unidirectional.

This can occur when the link is up on both sides, but one side is not receiving packets, or when wiring mistakes occur, causing the transmit and receive wires to not be connected to the same ports on both ends of a link.

Diagnostics → UDLD → Neighbor

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS
- Diagnostics**
 - Logging
 - Mirroring
 - Ping
 - Traceroute
 - Copper Test
 - Fiber Module
 - UDLD
 - Property
 - Neighbor**
- Management

Neighbor Table

Entry	Expiration Time	Current Neighbor State	Device ID	Device Name	Port ID	Message Interval	Timeout Interval
0 results found.							

Refresh

Field	Description
Entry	Display entry index.
Expiration Time	Display expiration time before age out.
Current Neighbor State	Display neighbor current state
Device ID	Display neighbor device ID.
Device Name	Display neighbor device name.
Port ID	Display neighbor port ID that connected.
Message Interval	Display neighbor message interval.
Timeout Interval	Display neighbor timeout interval

19. Management

19.1 User Account

The default username/password is root/default. Administrator can modify login password or create new username / password and defined Privilege, Setting “add” and “Edit” and “Delete” function for this management.

	Username	Privilege
<input type="checkbox"/>	root	Admin
<input type="checkbox"/>	mis	Admin
<input type="checkbox"/>	number1	User

Field	Description
Username	User name of the account
Privilege	Display privilege level for new account. <ul style="list-style-type: none"> Admin: Allow to change switch settings. Privilege value equals to 15. User: See switch settings only. Not allow to change it. Privilege level equals to 1.

Add User Account

Username	<input type="text"/>
Password	<input type="password"/>
Confirm Password	<input type="password"/>
Privilege	<input checked="" type="radio"/> Admin <input type="radio"/> User

Apply Close

- **Username:** User name of the account.
- **Password:** Set password of the account.
- **Confirm Password:** Set the same password of the account as in “Password” field.
- **Privilege:** Select privilege level for new account.
 - **Admin:** Allow to change switch settings. Privilege value equals to 15.
 - **User:** See switch settings only. Not allow to change it. Privilege level equals to 1.

Click the “**Apply**” button to save your changes or “**Close**” the button to close settings.

19.2 Firmware

19.2.1 Upgrade / Backup

Administrator can upgrade or backup firmware, method can choose use TFTP or HTTP protocol. If choose backup then administrator can choose firmware image to backup.

Management → Firmware → Upgrade / Backup

Action	<input checked="" type="radio"/> Upgrade <input type="radio"/> Backup
Method	<input type="radio"/> TFTP <input checked="" type="radio"/> HTTP
Filename	選擇檔案 未選擇任何檔案

Apply

- **Action:** Firmware operations.
 - **Upgrade:** Upgrade firmware from remote host to DUT.
 - **Backup:** Backup firmware image from DUT to remote host.
- **Method:** Firmware upgrade / backup method.
 - **TFTP:** Using TFTP to upgrade/backup firmware.
 - **HTTP:** Using WEB browser to upgrade/backup firmware.
- **Filename:** Use browser to upgrade firmware, you should select firmware image file on your host PC.

Click the **"Apply"** button to save your changes settings.

Action	<input type="radio"/> Upgrade <input checked="" type="radio"/> Backup
Method	<input checked="" type="radio"/> TFTP <input type="radio"/> HTTP
Firmware	<input checked="" type="radio"/> Image
Address Type	<input checked="" type="radio"/> Hostname <input type="radio"/> IPv4 <input type="radio"/> IPv6
Server Address	<input type="text"/>
Filename	<input type="text"/>

Apply

- **Action:** Firmware operations.
 - **Upgrade:** Upgrade firmware from remote host to DUT.
 - **Backup:** Backup firmware image from DUT to remote host.
- **Method:** Firmware upgrade / backup method.
 - **TFTP:** Using TFTP to upgrade/backup firmware.
 - **HTTP:** Using WEB browser to upgrade/backup firmware.
- **Firmware:** Firmware image in default flash.
- **Address Type:** Specify TFTP server address type
 - **Hostname:** Use domain name as server address.
 - **IPv4:** Use IPv4 as server address.
 - **IPv6:** Use IPv6 as server address
- **Server Address:** Specify TFTP server address.
- **Filename:** Firmware image file name on remote TFTP server.

Click the **"Apply"** button to save your changes settings.

19.3 Configuration

19.3.1 Upgrade / Backup

Administrator can backup system configuration file to PC or upload configuration file to Switch system, This page allow user to upgrade or backup firmware image through HTTP or TFTP server.

Management → Configuration → Upgrade / Backup	
Action	<input checked="" type="radio"/> Upgrade <input type="radio"/> Backup
Method	<input type="radio"/> TFTP <input checked="" type="radio"/> HTTP
Configuration	<input checked="" type="radio"/> Running Configuration <input type="radio"/> Startup Configuration <input type="radio"/> Backup Configuration <input type="radio"/> RAM Log <input type="radio"/> Flash Log
Filename	<input type="button" value="選擇檔案"/> 未選擇任何檔案

Upgrade Configuration

- **Action:** Configuration operations.
 - **Upgrade:** Upgrade firmware from remote host to DUT.
 - **Backup:** Backup firmware image from DUT to remote host.
- **Method:** Configuration upgrade method.
 - **TFTP:** Using TFTP to upgrade firmware.
 - **HTTP:** Using WEB browser to upgrade firmware.
- **Configuration:** Configuration Type.
 - **Running Configuration:** Merge to current running configuration file.
 - **Startup Configuration:** Replace startup configuration file.
 - **Backup Configuration:** Replace backup configuration file.
- **Address Type:** Specify TFTP server address type
 - **Hostname:** Use domain name as server address.
 - **IPv4:** Use IPv4 as server address.

- **IPv6:** Use IPv6 as server address
- **Server Address:** Specify TFTP server address.
- **Filename:** Configuration file name on remote TFTP server.

Click the **“Apply”** button to save your changes settings.

Backup Configuration

Action	<input type="radio"/> Upgrade <input checked="" type="radio"/> Backup
Method	<input type="radio"/> TFTP <input checked="" type="radio"/> HTTP
Configuration	<input checked="" type="radio"/> Running Configuration <input type="radio"/> Startup Configuration <input type="radio"/> Backup Configuration <input type="radio"/> RAM Log <input type="radio"/> Flash Log

Apply

- **Action:** Configuration operations.
 - **Upgrade:** Upgrade firmware from remote host to DUT.
 - **Backup:** Backup firmware image from DUT to remote host.
- **Method:** Configuration backup method.
 - **TFTP:** Using TFTP to backup firmware.
 - **HTTP:** Using WEB browser to backup firmware.
- **Configuration:** Configuration Type.
 - **Running Configuration:** Backup running configuration file.
 - **Startup Configuration:** Backup start configuration file.
 - **Backup Configuration:** Backup backup configuration file.
 - **RAM Log:** Backup log file stored in RAM.
 - **Flash Log:** Backup log files store in Flash.

Click the **“Apply”** button to save your changes settings.

19.3.2 Save Configuration

When administrator to click Apply on any window, changes that you made to the switch configuration settings are stored only in the Running Configuration. To preserve the parameters in the Running Configuration, the Running Configuration must be copied to another configuration type or saved as a file on another device, This page allow user to manage configuration file saved on DUT and click “Restore Factory Default” button to restore factory defaults.

- **Source File:** Source file types
 - **Running Configuration:** Copy running configuration file to destination.
 - **Startup Configuration:** Copy startup configuration file to destination.
 - **Backup Configuration:** Copy backup configuration file to destination.
- **Destination File:** Destination file types.
 - **Startup Configuration:** Save file as startup configuration.
 - **Backup Configuration:** Save file as backup configuration.


Click the “**Apply**” button to save your changes or **Click “Restore Factory Default” the button to back to factory default setting.**

19.4 SNMP

The SNMP supports SNMP v1, v2, and v3. It also reports system events to trap receivers using the traps defined in the Management Information Base (MIB) that it supports.

19.4.1 View

A view is a user-defined label for a collection of MIB tree subtrees. Each subtree ID is defined by the OID of the root of the relevant subtrees. You can either use well-known names to specify the root of the desired subtree or enter an OID. Setting “add” or “Delete” to management.



Field	Description
View	The SNMP view name. Its maximum length is 30 characters.
Subtree OID	Specify the ASN.1 subtree object identifier (OID) to be included or excluded from the SNMP view.
View Type	Include or exclude the selected MIBs in the view.

Add View

View	<input type="text"/>
OID Subtree	<input type="text"/>
Type	<input checked="" type="radio"/> Included <input type="radio"/> Excluded

- **View:** Enter a unique view name.
- **Object Subtree:** Select User Defined to manually define an OID, or select an existing OID from the list. All descendent of this node will be included or excluded in the view.
- **Type:**
 - Include: Check to include the selected MIBs in this view.
 - Excluded: Check to Excluded the selected MIBs in this view.

19.4.2 Group

In SNMPv1 and SNMPv2, a community string is sent along with the SNMP frames. The community string acts as a password to gain access to an SNMP agent. However, neither the frames nor the community string are encrypted. So SNMPv1 and SNMPv2 are not secure. In SNMPv3 can configure Authentication and Privacy is more secure. Setting “add” and “Edit” and “Delete” function for this management

Management → SNMP → Group

- ✚ Status
- ✚ Network
- ✚ Port
- ✚ POE Setting
- ✚ VLAN
- ✚ MAC Address Table
- ✚ Spanning Tree
- ✚ ERPS
- ✚ Discovery
- ✚ DHCP
- ✚ Multicast
- ✚ IP Configuration
- ✚ Security
- ✚ ACL
- ✚ QoS
- ✚ Diagnostics
- **Management**
 - User Account
 - 🔒 Firmware
 - 🔒 Configuration
 - 🔒 SNMP
 - View
 - Group

Group Table

Showing All entries Showing 0 to 0 of 0 entries

	Group	Version	Security Level	View		
				Read	Write	Notify
0 results found.						

Configure to associate a non-default view with a group.

Field	Description
Group	Specify SNMP group name, and the maximum length is 30 characters.
Version	Specify SNMP version <ul style="list-style-type: none"> • SNMPv1: SNMP Version 1. • SNMPv2: Community-based SNMP Version 2c. • SNMPv3: User security model SNMP version 3.
Security Level	Specify SNMP security level <ul style="list-style-type: none"> • No Security : Specify that no packet authentication is performed. • Authentication: Specify that no packet authentication without encryption performed. • Authentication and Privacy: Specify that no packet authentication with encryption is performed.
Version	Specify SNMP version <ul style="list-style-type: none"> • SNMPv1: SNMP Version 1. • SNMPv2: Community-based SNMP Version 2c. • SNMPv3: User security model SNMP version 3.
Security Level	Specify SNMP security level <ul style="list-style-type: none"> • No Security : Specify that no packet authentication is performed. • Authentication: Specify that no packet authentication without encryption performed. • Authentication and Privacy: Specify that no packet authentication with encryption is performed.
View	Specify SNMP version <ul style="list-style-type: none"> • Read: Group read view name.. • Write: Group write view name. • Notify: The view name that sends only traps with contents that is included in SNMP view selected for notification.
Read	Group read view name
Write	Group write view name.
Notify	The view name that sends only traps with contents that is included in SNMP view selected for notification.

- **Group:** Specify SNMP group name, and the maximum length is 30 characters.
- **Version:** Specify SNMP version.
 - **SNMPv1:** SNMP Version 1.
 - **SNMPv2:** Community-based SNMP Version 2c.
 - **SNMPv3:** User security model SNMP version 3.
- **Security Level:** Specify SNMP security level.
 - **No Security :** Specify that no packet authentication is performed.
 - **Authentication:** Specify that no packet authentication without encryption is performed.
 - **Authentication and Privacy:** Specify that no packet authentication with encryption is performed.
- **View:**
 - **Read :** Select read view name if Read is checked.
 - **Write:** Select write view name, if Write is checked.
 - **Notify:** Select notify view name, if Notify is checked.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

19.4.3 Community

Communities are only defined in SNMPv1 and v2 because SNMPv3 works with users instead of communities. The users belong to groups that have access rights assigned to them, Setting “add” and “Edit” and “Delete” function for this management.

Management → SNMP → Community

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS
- Diagnostics
- Management**
 - User Account
 - Firmware
 - Configuration
 - SNMP
 - View
 - Group
 - Community

Community Table

Showing **All** entries Showing 1 to 1 of 1 entries

<input type="checkbox"/>	Community	Group	View	Access
<input type="checkbox"/>	public		all	Read-Only

First

The access right of a community is defined by a group under ad
Configure to associate a group with a community.

Add Edit Delete

Field	Description
Community	The SNMP community name. Its maximum length is 20 characters.
Community	SNMP Community mode. <ul style="list-style-type: none"> Basic: snmp community specifies view and access right. Advanced: snmp community specifies group.
Group	Specify the SNMP group configured by the command SNMP group to define the object available to the community.
View	Specify the SNMP view to define the object available to the community.

Access	SNMP access mode
	<ul style="list-style-type: none"> • Read-Only: Read only. • Read-Write: Read and write.

- **Community:** The SNMP community name. Its maximum length is 20 characters.
- **Type:** Specify SNMP version.
 - **Basic:** SNMP community specifies view and access right ,The access rights of a community can configure with Read Only or Read Write. In addition, Administrator can restrict the access to the community to only certain MIB objects by selecting a view.
 - **Advanced:** SNMP community specifies group, The access rights of a community are defined by a group. You can configure the group with a specific security model. The access rights of a group are Read, Write, and Notify.
 - **View:** Specify the SNMP view to define the object available to the community.
- **Access:** SNMP access mode.
 - **Read Only:** Read only , Management access is restricted to read-only. Changes cannot be made to the community.
 - **Read Write:** Read and write , Management access is read-write. Changes can be made to the switch configuration, but not to the community.
- **Group:** **If set Type for specify SNMP version to “Advanced” type,** Must be set specify the SNMP group configured by user to define the object available to the community.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

19.4.4 User

An SNMP user is defined by the login credentials (username, passwords, and authentication method) and by the context and scope in which it operates by association with a group and an Engine ID. The configured user has the attributes of its group, having the access privileges configured within the associated view.

Groups enable network managers to assign access rights to a group of users, instead of a single user. A user can only be a member of a single group.

Administrator need to create a SNMPv3 user, a SNMPv3 group must be available, Setting “add” and “Edit” and “Delete” function for this management.

Management → **SNMP** → **User**

- Status
- Network
- Port
- POE Setting
- VLAN
- MAC Address Table
- Spanning Tree
- ERPS
- Discovery
- DHCP
- Multicast
- IP Configuration
- Security
- ACL
- QoS
- Diagnostics
- Management**
 - User Account
 - Firmware
 - Configuration
 - SNMP
 - View
 - Group
 - Community
 - User
 - Engine ID
 - Trap Event
 - Notification
 - RMON

User Table

Showing **All** entries Showing 1 to 3 of 3 entries

	User	Group	Security Level	Authentication Method	Privacy Method
<input type="checkbox"/>	number1	test2	Authentication	SHA	None
<input type="checkbox"/>	number2	test2	Authentication	SHA	None
<input type="checkbox"/>	snmp test	test	No Security	None	None

First Previous 1 Next

Configure to associate an SNMPv3 group with an SNMPv3 user.

Field	Description
User	Specify the SNMP user name on the host that connects to the SNMP agent. The max character is 30 characters. For the SNMP v1 or v2c, the user name must match the community name
Group	Specify the SNMP group to which the SNMP user belongs.
Security Level	SNMP privilege mode <ul style="list-style-type: none"> • No Security : Specify that no packet authentication is performed. • Authentication: Specify that no packet authentication without encryption is performed. • Authentication and Privacy: Specify that no packet authentication with encryption is performed.
Authentication Method	Authentication Protocol which is available when Privilege Mode is Authentication or Authentication and Privacy . <ul style="list-style-type: none"> • None: No authentication required. • MD5: Specify the HMAC-MD5-96 authentication protocol. • SHA: Specify the HMAC-SHA-96 authentication protocol.
Privacy Method	Encryption Protocol <ul style="list-style-type: none"> • None: No privacy required. • DES: DES gorithm

Add User

User	<input type="text" value="number2"/>
Group	<input type="text" value="test2"/>
Security Level	<input type="radio"/> No Security <input checked="" type="radio"/> Authentication <input type="radio"/> Authentication and Privacy
Authentication	
Method	<input type="radio"/> None <input type="radio"/> MD5 <input checked="" type="radio"/> SHA
Password	<input type="text" value="1234567890"/>
Privacy	
	<input checked="" type="radio"/> None <input type="radio"/> DES
	<input type="text"/>

Apply
Close

- **User:** Specify the SNMP user name on the host that connects to the SNMP agent. The max character is 30 characters.
- **Security Level:** SNMP privilege mode.
 - **No Security:** Specify that no packet authentication is performed.
 - **Authentication:** Specify that no packet authentication without encryption is performed.
 - **Authentication and Privacy:** Specify that no packet authentication with encryption is performed.

Authentication

- **Method:** Authentication Protocol which is available when Privilege Mode is Authentication or Authentication and Privacy.
 - **None:** No authentication required.
 - **MD5:** Specify the HMAC-MD5-96 authentication protocol.
 - **SHA:** Specify the HMAC-SHA-96 authentication protocol.
- **Password:** The authentication password, The number of character range is 8 to 32 characters.

Privacy

- **Method:** Encryption Protocol.
 - **None:** No privacy required.
 - **DES:** DES algorithm.
 - **SHA:** Specify the HMAC-SHA-96 authentication protocol.
- **Password:** The privacy password, The number of character range is 8 to 64 characters.

*Click the “**Apply**” button to save your changes or “**Close**” the button to close settings.*

19.4.5 Engine ID

The Engine ID is only used by SNMPv3 entities to uniquely identify them. An SNMP agent is considered an authoritative SNMP engine. This means that the agent responds to incoming messages (Get, GetNext, GetBulk, Set), and sends trap messages to a manager.

Each SNMP agent maintains local information that is used in SNMPv3 message exchanges. The default SNMP Engine ID is comprised of the enterprise number and the default MAC address. The SNMP Engine ID must be unique for the administrative domain, so that no two devices in a network have the same Engine ID, Setting “**add**” and “**Edit**” and “**Delete**” function for this management.

Local Engine ID

- **Engine ID:** If checked “User Defined”, the local engine ID is configure by user, else use the default Engine ID which is made up of MAC and Enterprise ID, The user defined engine ID is range 10 to 64 hexadecimal characters, and the hexadecimal number must be divided by 2.

Click the **“Apply”** button to save your changes settings.

Remote Engine ID Table

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

Field	Description
Server Address	Remote host.
Engine ID	Specify Remote SNMP engine ID. The engine ID is range10 to 64 hexadecimal characters, and the hexadecimal number must be divided by 2.

Add Remote Engine ID

Address Type	<input checked="" type="radio"/> Hostname <input type="radio"/> IPv4 <input type="radio"/> IPv6
Server Address	<input type="text"/>
Engine ID	<input type="text"/> (10 - 64 Hexadecimal Characters)

Apply
Close


- **Address Type:** Remote host address type for Hostname/IPv4/IPv6.
- **Server Address:** Remote host.
- **Engine ID:** Specify Remote SNMP engine ID. The engine ID is range 10 to 64 hexadecimal characters, and the hexadecimal number must be divided by 2.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

19.4.6 Trap Event

Administrator can choose SNMP Trap Event Type to monitor

Trap messages are generated to report system events, as defined in RFC 1215. The system can generate traps defined in the MIB that it supports.




Field	Description
Authentication Failure	SNMP authentication failure trap, when community not match or user authentication password not match.
Link Up/Down	Port link up or down trap
Cold Start	Device reboot configure by user trap
Warm Start	Device reboot by power down trap

Click the **“Apply”** button to save your changes settings.

19.4.7 Notification

Notification is network nodes where the trap messages are sent by the switch. A list of notification recipients are defined as the targets of trap messages. A trap receiver entry contains the IP address of the node and the SNMP credentials corresponding to the version that will be included in the trap message. When an event arises that requires a trap message to be sent, it is sent to every node listed in the Notification Recipient Table, , Setting “add” and “Edit” and “Delete” function for this management.



Field	Description
Server Address	IP address or the hostname of the SNMP trap recipients.
Server Port	Recipients server UDP port number
Timeout	Specify the SNMP informs timeout
Retry	Specify the retry counter of the SNMP informs.
Version	Specify SNMP notification version <ul style="list-style-type: none">• SNMPv1: SNMP Version 1 notification.• SNMPv2: SNMP Version 2 notification.• SNMPv3: SNMP Version 3 notification.

Type	<p>Notification Type</p> <ul style="list-style-type: none"> • Trap: Send SNMP traps to the host. • Inform: Send SNMP informs to the host.
Community/User	SNMP community/user name for notification. If version is SNMPv3 the name is user name, else is community name
UDP Port	Specify the UDP port number.
Timeout	Specify the SNMP informs timeout
Security Level	<p>SNMP trap packet security level</p> <ul style="list-style-type: none"> • No Security: Specify that no packet authentication is performed. • Authentication: Specify that no packet authentication without encryption is performed. • Authentication and Privacy: Specify that no packet authentication with

Add Notification

Address Type	<input checked="" type="radio"/> Hostname <input type="radio"/> IPv4 <input type="radio"/> IPv6
Server Address	192.168.2.101
Version	<input checked="" type="radio"/> SNMPv1 <input type="radio"/> SNMPv2 <input type="radio"/> SNMPv3
Type	<input checked="" type="radio"/> Trap <input type="radio"/> Inform
Community / User	public ▼
Security Level	<input checked="" type="radio"/> No Security <input type="radio"/> Authentication <input type="radio"/> Authentication and Privacy
Server Port	<input checked="" type="checkbox"/> Use Default 162 (1 - 65535, default 162)
	<input checked="" type="checkbox"/> Use Default 15 Sec (1 - 300, default 15)
	<input checked="" type="checkbox"/> Use Default 3 (1 - 255, default 3)

Apply
Close

- **Address Type:** Remote host address type for Hostname/IPv4/IPv6.
- **Server Address:** IP address or the hostname of the SNMP trap recipients.
- **Version:** Specify SNMP notification version.
 - **SNMPv1:** SNMP Version 1 notification.
 - **SNMPv2:** SNMP Version 2 notification.
 - **SNMPv3:** SNMP Version 3 notification.
- **Type:** Notification Type.
 - **Trap:** Send SNMP traps to the host.
 - **Inform:** Send SNMP informs to the host.(version 1 have no inform).
- **Community/User:** SNMP community/user name for notification. If version is SNMPv3 the name is user name, else is community name.
- **Security Level:** SNMP notification packet security level, the security level must less than or equal to the community/user name.
 - **No Security:** Specify that no packet authentication is performed.
 - **Authentication:** Specify that no packet authentication without encryption is performed.
 - **Authentication and Privacy:** Specify that no packet authentication with encryption is performed.
- **Server Port:** Recipients server UDP port number, if “use default” checked the value is 162, else user configure.
- **Timeout:** Specify the SNMP informs timeout, if “use default” checked the value is 15, else user configure.
- **Retry:** Specify the SNMP informs retry count, if “use default” checked the value is 3, else user configure.

*Click the “**Apply**” button to save your changes or “**Close**” the button to close settings.*

19.5 RMON

19.5.1 Statistics

The page displays traffic statistics per interface. The refresh rate of the information can be selected. This page is useful for analyzing the amount of traffic that is both sent and received and its dispersion (Unicast, Multicast, and Broadcast) Click the **“Clear”** button to clear this page or click the **“Refresh”** button to refresh and click the **“View”** button to view the page .

Management → RMON → Statistics

Statistics Table									
Refresh Rate <input type="text" value="0"/> sec									
<input type="checkbox"/>	Entry	Port	Bytes Received	Drop Events	Packets Received	Broadcast Packets	Multicast Packets	CRC & Align Errors	
<input type="checkbox"/>	1	GE1	0	0	0	0	0	0	
<input type="checkbox"/>	2	GE2	0	0	0	0	0	0	
<input type="checkbox"/>	3	GE3	0	0	0	0	0	0	
<input type="checkbox"/>	4	GE4	0	0	0	0	0	0	
<input type="checkbox"/>	5	GE5	0	0	0	0	0	0	
<input type="checkbox"/>	6	GE6	0	0	0	0	0	0	
<input type="checkbox"/>	7	GE7	0	0	0	0	0	0	
<input type="checkbox"/>	8	GE8	0	0	0	0	0	0	
<input type="checkbox"/>	9	GE9	0	0	0	0	0	0	
<input type="checkbox"/>	10	GE10	0	0	0	0	0	0	
<input type="checkbox"/>	11	GE11	0	0	0	0	0	0	
<input type="checkbox"/>	12	GE12	0	0	0	0	0	0	
<input type="checkbox"/>	13	GE13	0	0	0	0	0	0	
<input type="checkbox"/>	14	GE14	0	0	0	0	0	0	
<input type="checkbox"/>	15	GE15	0	0	0	0	0	0	
<input type="checkbox"/>	16	GE16	0	0	0	0	0	0	
<input type="checkbox"/>	17	GE17	0	0	0	0	0	0	

Statistics Table

Refresh Rate sec

<input type="checkbox"/>	Entry	Port	Bytes Received	Drop Events	Packets Received	Broadcast Packets	Multicast Packets	CRC & Align Errors	Undersize Packets	Oversize Packets	Fragments
<input type="checkbox"/>	1	GE1	491071	0	2953	458	545	0	0	0	0
<input type="checkbox"/>	2	GE2	0	0	0	0	0	0	0	0	0
<input type="checkbox"/>	3	GE3	0	0	0	0	0	0	0	0	0
<input type="checkbox"/>	4	GE4	0	0	0	0	0	0	0	0	0
<input type="checkbox"/>	5	GE5	0	0	0	0	0	0	0	0	0
<input type="checkbox"/>	6	GE6	0	0	0	0	0	0	0	0	0
<input type="checkbox"/>	7	GE7	0	0	0	0	0	0	0	0	0
<input type="checkbox"/>	8	GE8	0	0	0	0	0	0	0	0	0


Jabbers	Collisions	Frames of 64 Bytes	Frames of 65 to 127 Bytes	Frames of 128 to 255 Bytes	Frames of 256 to 511 Bytes	Frames of 512 to 1023 Bytes	Frames Greater than 1024 Bytes
0	0	1215	1044	237	7	442	8
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0

Field	Description
Port	The port for the RMON statistics.
Bytes Received	Number of octets received, including bad packets and FCS octets, but excluding framing bits.
Drop Events	Number of packets that were dropped.
Packets Received	Number of packets received, including bad packets, Multicast packets, and Broadcast packets.
Broadcast Packets	Number of good Broadcast packets received. This number does not include Multicast packets.
Multicast Packets	Number of good Multicast packets received.
CRC & Align Errors	Number of CRC and Align errors that have occurred.
Undersize Packages	Number of undersized packets (less than 64 octets) received.
Oversize Packages	Number of oversized packets (over 1518 octets) received.
Fragments	Number of fragments (packets with less than 64 octets, excluding framing bits, but including FCS octets) received.

Jabbers	<p>Number of received packets that were longer than 1632 octets. This number excludes frame bits, but includes FCS octets that had either a bad FCS (Frame Check Sequence) with an integral number of octets (FCS Error) or a bad FCS with a non-integral octet (Alignment Error) number. A Jabber packet is defined as an Ethernet frame that satisfies the following criteria:</p> <ul style="list-style-type: none"> • Packet data length is greater than MRU. • Packet has an invalid CRC. • RX error event has not been detected.
Collision	Number of collisions received. If Jumbo Frames are enabled, the threshold of Jabber Frames is raised to the maximum size of Jumbo Frames.
Frames of 64 Bytes	Number of frames, containing 64 bytes that were received.
Frames of 65 to 127 Bytes	Number of frames, containing 65 to 127 bytes that were received.
Frames of 128 to 255 Bytes	Number of frames, containing 128 to 255 bytes that were received.
Frames of 256 to 511 Bytes	Number of frames, containing 256 to 511 bytes that were received.
Frames of 512 to 1024 Bytes	Number of frames, containing 512 to 1023 bytes that were received.
Frames Greater than 1024 Bytes	Number of frames, containing 1024 to 1518 bytes that were received

19.5.2 History

Use the History Control Table page to define the sampling frequency, amount of samples to store, and the interface from where to gather the data. After the data is sampled and stored, it appears on the History Table page that can be viewed by clicking History Table, , Setting “add” and “Edit” and “Delete” and “View” function for this management.



Field	Description
Port	The port for the RMON history.
Interval	The number of seconds for each sample.
Owner	The owner name of event (0~31 characters).
Sample	The maximum number of buckets.
	<ul style="list-style-type: none">• Maximum : The maximum number of buckets.• Current: The current number of buckets.

Add History

Entry	1	
Port	GE1 ▾	
Max Sample	50	(1 - 50, default 50)
Interval	1800	(1 - 3600, default 1800)
Owner		

Apply
Close

- **Port:** Select ports for the configure.
- **Max Sample:** Specify the maximum number of buckets.
- **Interval:** Enter the time in seconds that samples were collected from the interface, Specify the number of seconds for each sample
- **Owner:** Enter the RMON station or user that requested the RMON information, Specify the owner name of event (0~31 characters).

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

19.5.3 Event

Events page to configure events that are actions performed when an alarm is generated (alarms are defined on the Alarms page). An event can be any combination of logs and traps. If the action includes logging of the events, they are displayed on the Event Log Table page, Setting **“add”** and **“Edit”** and **“Delete”** and **“View”** function for this management.

Management → RMON → Event

- ▼ Status
- ▼ Network
- ▼ Port
- ▼ POE Setting
- ▼ VLAN
- ▼ MAC Address Table
- ▼ Spanning Tree
- ▼ ERPS
- ▼ Discovery
- ▼ DHCP
- ▼ Multicast
- ▼ IP Configuration
- ▼ Security
- ▼ ACL
- ▼ QoS
- ▼ Diagnostics
- **Management**
 - User Account
 - ♥ Firmware
 - ♥ Configuration
 - ♥ SNMP
 - ♥ RMON
 - Statistics
 - History
 - Event
 - Alarm

Event Table

Showing All entries Showing 0 to 0 of 0 entries

<input type="checkbox"/>	Entry	Community	Description	Notification	Time	Owner
0 results found.						
						First Previous 1
Add		Edit		Delete		View

Field	Description
Port	Specify port for the RMON history.
Max Sample	Specify the maximum number of buckets.
Interval	Specify the number of seconds for each sample.
Owner	Specify the owner name of event (0~31 characters).

Add Event

Entry	1
Notification	<input checked="" type="radio"/> None <input type="radio"/> Event Log <input type="radio"/> Trap <input type="radio"/> Event Log and Trap
Community	Default Community
Description	Default Description
Owner	


Apply
Close

- **Community:** The SNMP community name. Its maximum length is 20 characters.
- **Notification:** Specify the notification type for the event, and the possible value are.
 - **None:** Nothing for notification.
 - **Event Log:** Logging the event in the RMON Event Log table.
 - **Trap:** Send a SNMP trap.
 - **Event Log and Trap:** Logging the event and send the SNMP trap
- **Community:** Specify the SNMP community when the notification type is specified as “Trap” and “Event Log and Trap”.
- **Description:** Specify the description for the event.
- **Owner:** Specify owner for the event.

Click the **“Apply”** button to save your changes or **“Close”** the button to close settings.

19.5.4 Alarm

RMON alarms provide a mechanism for setting thresholds and sampling intervals to generate exception events on any counter or any other SNMP object counter maintained by the agent. Both the rising and falling thresholds must be configured in the alarm. After a rising threshold is crossed, no rising events are generated until the companion falling threshold is crossed. After a falling alarm is issued, the next alarm is issued when a rising threshold is crossed, Setting **“add”** and **“Edit”** and **“Delete”** function for this management.



Field	Description
Port	The port configuration for the RMON alarm.
Counter	<div>The counter for sampling<ul style="list-style-type: none">• DropEvents (Drop Event): Total number of events received in which the packets were dropped.• Octes (Received Bytes): Octets.• Pkts (Received Packets): Number of packets.• BroadcastPkts (Broadcast Packets Received): Broadcast packets.• MulticastPkts (Multicast Packets Received): Multicast packets.• CRCALError (CRC and Align Error): CRC alignment error.• UndersizePkts (Undersize Packets): Number of undersized packets.• OversizePkts (Oversize Packets): Number of oversized packets.• Fragments (Fragments): Total number of packet fragment.• Jabbers (Jabbers): Total number of packet jabber.• Collisions (Collisions): Collision.• Pkts64Octetes (Frames of 64 Bytes): Number of packets size 64 octets.• Pkts65to127Octetes (Frames of 65 to 127 Bytes): Number of packets size 65 to 127 octets.</div>

	<ul style="list-style-type: none"> • Pkts128to255Octetes (Frames of 128 to 255 Bytes): Number of packets size 128 to 255 octets. • Pkts256to511Octetes (Frames of 256 to 511 Bytes): Number of packets size 256 to 511 octets. • Pkts512to1023Octetes (Frames of 512 to 1023 Bytes): Number of packets size 512 to 1023 octets. • Pkts1024to1518Octets (Frames Greater than 1024 Bytes): Number of packets size 1024 to 1518 octets.
Version	<p>The sampling type including:</p> <ul style="list-style-type: none"> • Absolute: The selected variable value is compared directly with the thresholds at the end of the sampling interval • Delta: The selected variable value of the last sample is subtracted from the current value and the difference is compared with the thresholds.
Interval	The number of seconds for each sample.
Owner	The owner for the alarm entry.
Trigger	The type of event triggering.
Rising Threshold	The threshold for firing rising event.
Rising Event	The rising event when alarm was fired.
Falling Threshold	The threshold for firing falling event.
Falling Event	The falling event when alarm was fired.